

出 図	-				
配 布 先	年				
	月				
日					
船 主					
監 督					
本 船					
協会・本部					
協会・支部					
船 営 本 部	営業部				
	業務部				
資 材 部	アター				
	管理				
品 保 部	購買				
	造船				
艦 装 部	艦艇				
	鉄構・機				
	工事				
修 繕 部	船装1				
	船装2				
	機装				
造 兵 部	塗装				
	工事				
	船体				
造 兵 部	機関				
	電装				
	電気				
造 兵 部	造兵				
	SD				
	SN				
造 船 設 計 部	SC				
	SF1				
	SF2				
	SM1				
	SM2				
	SE				
生 産 技 術 部	SS				
本 船	1				
船 主	2				
控	1				
合 計	4				

OASIS RIVER

S761/762

Main Diesel
Generator Engine

(FINISHED PLAN)

CLASS : ABS (ACCU)

SCALE : —

SASEBO HEAVY INDUSTRIES CO., LTD.



DEPT. CHIEF

K. Ueda

D. DEP. CHIEF

T. Satorahi

SECT. CHIEF

A. Yoshida

IN CHARGE

M. Yamawaki

CHECKED BY

DRAWN BY

T. Oshiro

DATE DRAWN

September 1, 2008

WORK NO.

1000761/1000762


DRAWING NO.

SASEBO HEAVY INDUSTRIES CO., LTD.

DIESEL GENERATOR ENGINE
DOCUMENT LIST

Approval plans Please confirm documents in this list and return each one of this list & documents with your signature for approval by **11th Jan.2008.**

Working plans Please receive documents in this list and return one of this list with your signature.



Finish plans Please receive documents in this list and return one of this list with your signature.

customer signature

DAIHATSU DIESEL MFG. CO., LTD.
TECHNICAL DEPARTMENT
JAPAN

HULL No.	SNO. 761/762	DRAWN BY	<i>M. Ochi</i>
TYPE	6DK-20	CHECKED BY	<i>N. Satou</i>
LIST No.	AQA10005005C		
DATE	2007.9.27	APPROVED BY	<i>[Signature]</i>
REVISION	B : P2,3 C : P3	2008.2.26 F.S 2008.4.22 F.S	

ADK20-5044-6

DOCUMENTS LIST						LIST No. AQA10005005 C 3/3												
SHIPYARD SHIP No.		SASEBO HEAVY INDUSTRIES CO., LTD. SNO. 761/762				ENGINE MODEL 6DK-20												
No.	NAME.	DRAWING No.	REMARK	FOR APPROVAL				FOR WORKING				AS BUILT						
				COPY	APPLY	REV	DATE	COPY	APPLY	REV	DATE	COPY	APPLY	REV	DATE			
1	SPARE PARTS LIST																	
2	DIESEL ENGINE	AQA10005015	B		7	○	B		○									
3	TURBO CHARGER	B684300030F	A	TPS48D		7	○			○	A							
4	GOVERNOR	NN00035001A	A	RHD6		7	○			○	A							
5	LO PRIMING PUMP	AQA20002219	A			7	○			○								
6	LO PRIMING PUMP STARTER	AQA10005018	A			7	○			○								
7																		
8																		
9																		
10																		
11	TOOL LIST																	
12	DIESEL ENGINE	Q7LT320300F	E			7	○			○								
13	TURBO CHARGER	B684300130F	Z	TPS48D		7	○			○								
14	DIESEL ENGINE (2)	QE19302190F	Z			7	○			○								
15																		
16																		
17																		
18																		
19																		
20																		
21	TESTING METHOD	Q7LT318450F	Z			7	○											
22																		
23	INSTRUCTION MANUAL																	
24	SPEED SWITCH UNIT	Q7LT333490F	Z	ENG.											4	○		
25	TURBO CHARGER	TPS48D		ENG.											4	●		
26	GOVERNOR	RHD6		ENG.											4	●		
27																		
28																		
29																		
30																		
31																		
32																		
33																		
34																		
35																		

REPRODUCIBLE MYLAR TRACING, EACH ONE (1)

This document is the property of daihatsu diesel Mfg. Co., Ltd. Reproduction, use or disclosure to third parties without express authority of Daihatsu is strictly forbidden.

Purchaser		Ship owner	
Shipyard	SASEBO HEAVY INDUSTRIES CO.,LTD	Vessel type	115,000DWT Tanker
SNo.	761/762	Rule, Flag	ABS-ACCU, SINGAPORE

6 DK-20

Specifications for Main Generator Engine

AC Generator	875	kVA(700)kW	
Diesel engine	760	kW	X		900 min ⁻¹

DAIHATSU

Daihatsu Diesel Mfg. Co., Ltd.

Total 17 pages

Revise	B : P7,9 2007.10.19 F.S		
	C : P4,7 2007.11.14 M.O.		
Product No.	SNo.	761 ... ADK20-5044-6	Technical dept. engineering Gr. 2
	SNo.	762 ... ADK20-5047-9	Draw <i>M. Ochi</i>
	SNo.	...	Check <i>N. Satou</i>
First delivery	Apr-08		
Q'ty	3 sets/ship × 2 ships = 6 sets		Approval <i>A. Takahashi</i>
Dwg. No.	ADK20-5044-6		Date 2007/7/18

1 — 1. Principal particular

AQA10005007C (2/17)

1	Type		In-line, single action, 4 cycle, direct injection turbocharged and intercooled, water-cooled diesel engine
2	Engine type		6DK-20
3	Rated output	kW	760
4	Revolution	min ⁻¹	900
5	Cylinder numbers		6
6	Bore x Stroke	mm	200 X 300
7	Break mean effective pressure	MPa	1.80
8	Maximum pressure	MPa	Below 17.0
9	Piston speed	m/s	9.0
10	Over load		10% over load : 60min (every 12hrs)
11	Rotation		Clockwise (right) (view from flywheel side)
12	Fuel oil consumption	g/kW·h	197 5% margin, fuel oil low calorific value : 42700kJ/kg
13	Lub oil consumption	g/kW·h	0.8 Standard value on 100% load
14	Speed variation		Momentary : within 10% Permanently : within 5%, 5sec Load variation : 100→0→50→100%
15	Working condition		Ambient temperature : 5-45deg.C Relative humidity : ~85% Sea water temperature : upto 32deg.C Cooling fresh water temp. : 70°C at engine inlet Cooling fresh water press. : 0.25~0.35MPa at engine inlet Max. exhaust gas pressure : 3.0kPa(300mmAq) at full load F.O. viscosity : 14±1.5mm ² /s [65±5sec.R.W.NO.1] at engine inlet F.O. injection pump inlet press : 0.5~0.6MPa
16	Recommendable low load (Gen. Output)		140kW

Rev		

17	Combustion air volume (room temp. 25deg.C)		m ³ /h	5000
18	Exhaust gas (at 100% load)	Volume	Nm ³ /h (at 0deg.C)	4800
		Temperature at T/C outlet	°C	370
19	Necessary volume of cooling sea water		m ³ /h/1eng.	36
20	Lubricating oil	Engine system oil : API service grade CD class SAE#30 TBN 30-40mg KOH/g Turbocharger : supplied from engine system oil Governor : same as engine system oil		
21	Capacity (L)	Cooling water	Engine : 85, air cooler : 23, LO cooler : 11	
		Lub. Oil	Engine : 86, LO cooler : 22, governor : 1.3 Sumptank : 1100 Volume of LO cooler should be added into sumptank volume for initial volume.	

1-2. AC Generator

1	Manufacturer	Nishishiba electric co., ltd.
2	Type	NTAKL-VE
3	Output	875 kVA 700 kW AC450V, 3Φ, 60Hz
4	Necessary engine output	approx. 741kW Power factor : 0.8, generator efficiency : 94.5%
5	Bearing	Single sleeve bearing
6	Cooling method	Self ventilation air cooling type
7	Lubricating method	Forced lubricating
8	Exciting method	Self-exciting brushless
9	Insulation	F class
10	Generator supplier	Shipyard supply

Rev		

2. Specifications

AQA10005007C (4/17)

	Item	Specification
1	Starting, stopping method	Remote start/stop, automatic start/stop, manual start/stop, emergency auto stop Start : Compressed air 2.94MPa Automatic stop : control air 0.69MPa and DC24V
2	Control of NOX emission	Statement of compliance by ABS
3	Fuel oil	380mm ² /s at 50°C (ISO RMH 380) During initial running (150hrs) MDO to be used ※HFO may be used during sea trial
4	Fuel oil change-over	Marine diesel oil change-over at start/stop and low load (below 140kW – based on generator output)
5	Fuel oil supply system	Pressurization
6	Lub oil system	Sumptank incorporated in common bed, batch purification
7	Cooling method	Jacket Fresh water
		Cooler Sea water
		Nozzle Non cool
8	Installation method	Rigid
9	Coupling method to generator	Rigid

Rev	C: 2.3 Rev. Note	
-----	------------------	--

3 . Accessories

AQA10005007C (5/17)

Q'ty : Quantity /1eng. Sco : Scope of Supply Ins : Installation Place

D : to be supplied by Daihatsu S : to be supplied by Shipyard O : to be supplied by Owner

E : with Engine H : to be installed on the Hull

3-1. Cooling Water System

	Item	Q'ty	Sco	Ins	Specification
1	Cooling fresh water pump (Jacket)	1	D	E	Engine driven centrifugal type 36m ³ /h x 25m
2	CW piping internal treatment	1 set	D	E	Fresh water : Parkerizing Sea water : Zn plating (STPG370, SCH40)
3					
4	Air vent	1	D	E	5K-15A, with ball valve
5	LO and air cooler internal treatment	1 set	D	E	Tar-epoxy coating
6	Anode (LO and air cooler)	1 set	D	E	Zn
7	Chemical cleaning port	1	D	E	Air cooler inlet and LO cooler outlet
8					
9	Butterfly valve	2	D	E	Air cooler outlet (Sea water cooling)
10	Orifice	each 1	D	H	φ 20,30/80A: for cooling fresh water outlet φ 5/15A: for cooling fresh water expansion line φ 10/15A: for warming line φ 40/80A: for auto cooling water valve by-pass

Rev		

	Item	Qty	Sco	Ins	Specification
1					
2	Fuel filter (eng inlet)	1	D	E	Duplex manual back wash notch wire type with ragging, 200mesh
3	Fuel oil high press pipe	6	D	E	Block type (equivalent to double wall)
4	Nozzle cooling system	1	D	E	Non cool
5					
6					
7	Level switch box	1	D	E	FO leaked oil detect, 15L
8	FO relief valve (engine outlet)	1	D	E	Setting pressure : 0.1~0.2MPa
9	FO piping heat treatment	1	D	E	Ragging and steam trace
10					
11	FO damper	2	D	E	Engine inlet and outlet
12					

Rev		
-----	--	--

	Item	Q'ty	Sc	Ins	Specification	
1	Lub. Oil pump	1	D	E	Gear pump, engine driven Capacity : 14.8m3/h Normal press. : 0.4~0.5MPa	
2						
3	Lub. Oil filter (pump inlet)	1	D	E	Punching board type	
4	Lub. Oil filter (pump outlet)	1	D	E	Duplex manual back wash notch wire type, with cover 200mesh	C
5	Lub. Oil filter for turbocharger	1	D	E	Duplex manual back wash notch wire type, with cover 350mesh	C
6	Lub. Oil by-pass filter	2	D	E	Centrifugal type, GF-2	
7	Sump tank	1	D	E	without overflow port, incorporated in common bed 1100L	
8	Charge/discharge port	1	D	E	5K-40A	
9						B
10						
11	Lub. Oil cooler	1	D	E	Multi-tubular type, 12.0m2	
12	Lub. Oil thermostat valve	1	D	E	Wax type, setting temp. 55deg.C, size50	
13	Lub. Oil priming pump (continuous priming during engine stop)	1	D	E	Electric motor driven Capacity { pump : 2.5m3/h × 0.2MPa motor : AC440V, 3φ, 60HZ 0.94kW, class F, 2.0A	
14	Lub. Oil purifier		S	H	Please purify Lub.Oil as long as possible in order to keep Lub.Oil characteristics in proper condition.	

Rev	B : 3-3.9 Del.Note	
	C : 3-3.4.5 Add.Note	

	Item	Q'ty	Sc	Ins	Specification

3-4. Governing device

	Item	Q'ty	Sc	Ins	Specification
1	Governor	1	D	E	Bosch made hydraulic type : RHD6-MC
2	Governor motor	1	D	E	Woodward made, speed changing time 8-12 seconds/Hz DC 24V, 3W
3	Governor control unit	1	D	H	Input AC100V, 8W, output DC24V to be installed into MSB

3-5. Intake/Exhaust system

	Item	Q'ty	Sc	Ins	Specification
1	Air cooler	1	D	E	Fin tube type DH39(Box type)
2	Turbocharger	1	D	E	ABB made, radial turbine, anti-coupling side TPS48D
3	Exh. Gas expansion joint (for T/C outlet)	1	D	E	Stainlass steel bellows (inlet)250A x 350A(outlet)
4	T/C blower cleaning device	1	D	E	Water cleaning by syringe, detachable piping syringe to be supplied as tool
5	Exh. Gas pipe cover	1	D	E	
6					
7	T/C turbine cleaning device	1	D	E	Water cleaning gauge unit to be supplied as tool
8	Exhaust pipe treatment	1	D	E	Expansion joint inside exhaust pipe cover Lagging covering on the flange

Rev		

	Item	Q'ty	Sc	Ins	Specification
1	SA piping internal treatment	1	D	E	Parkerizing
2					
3					
4					
5					
6					
7					

3-7. Installed and coupling parts

	Item	Q'ty	Sc	Ins	Specification
1	Common bed	1	D	E	Sounding pipe, maintenance hole, center height 1000mm
2	Jack bolt for common bed	1	D	E	
3	Step	1	D	E	FO injection pump side, with handrail and ladder
4	Turning device	1	D	E	Ratchet type
5					
6	Flywheel cover	1	D	E	with generator shaft cover

B

Rev	B : 3-7.3 Add. Ladder	

	Item	Q'ty	Sco	Ins	Specification
1	Gam shaft	1	D	E	Mono-block type
2	Rack indicator	1	D	E	
3	Engine frame safety valve	1	D	E	Quantity by rule requirement, Frame arrest type
4	Oil pan for strainer	1	D	E	Welded steel plate with drain hole
5	Name plate	1	D	E	Engine, panel valves Unit : SI Caution plate : English/Japanese, English
					Caution plate : Drain cock for inlet air duct to be kept 1/4 open
6	Special parts for rule	1	D	E	Thermal switch with pocket Connection plug for press switch test Fire protection of SOLAS 2000 PL caution plate
7	Counter flange	1	S	H	JIS
8	Connection plug for press switch test	1	D	E	PF3/8 with plug
9	Fire prevention	1	D	E	
10	Cylinder head cover	6	D	E	With check window
11	F.O. /L.O. piping spec	1	D	E	Steal pipe unable to use union joint
12	Cylinder indicator & safety valve	6	D	E	With cover

Rev		

	Item	Qty	Qty	Ins	Specification
1	Gauge board	1	D	E	Elastic mounting type, L.O.・T/CL.O.・F.O.is located other position
2	Pressure gauge (bourdon tube type)	1	D	E	φ 60, anti-vibration type Glycerin filled type
	(1) Lub. Oil	1	D	E	1.0MPa Blue mark:0.4~0.5MPa
	(2)T/C lub. Oil	1	D	E	1.0MPa Blue mark:0.2~0.5MPa
	(3)Boost	1	D	E	0.3MPa with damper
	(4)Jacket cooling water	1	D	E	0.6MPa Blue mark:0.25~0.35MPa
	(5)Fuel oil	1	D	E	1.0MPa Blue mark:0.5~0.6MPa with damper and seal pot
	(6)				
	(7) Cooler cooling water	1	D	E	0.4MPa
	(8)				
3	Tachometer	1	D	E	300~1500min ⁻¹ Red mark : 750~810min ⁻¹

Rev		

	Item	Qty	Sco	Ins	Specification
4	Thermometer				
	(1)Lub. Oil				
	1. Engine inlet	1	D	E	Alcohol type, 100deg.C, PF1/2
	2.				
	(2)Boost air				
	1. Air cooler outlet	1	D	E	Alcohol type, 100deg.C, PF1/2
	(3)Jacket cooling water				
	1. Engine inlet	1	D	E	Alcohol type, 100deg.C, PF1/2
	2. Engine outlet	1	D	E	Alcohol type, 100deg.C, PF1/2
	3.				
	(4)Fuel oil				
	1. Engine inlet	1	D	E	Mercury type, 200deg.C, PF1/2, L=100
	(5) Cooler cooling water				
	1. LO cooler inlet	1	D	E	Alcohol type, 100deg.C, PF1/2
	2.				
	3.				
	(6)				
	1.				
	2.				
	(7)Exhaust gas				
	1. Each cylinder outlet	6	D	E	Mercury type, 520deg.C, PF1/2
	2. Turbo charger inlet	1	D	E	Mercury type, 620deg.C, PF1/2
	3.				

Rev		
-----	--	--

	Item	Q'ty	SCO	INS	Specification
1	Pressure transmitter				Power DC24V, output 4~20mA/0~F.S.
	(1) LO engine inlet	1	D	E	Range : 0-1.0MPa Alarm setting 0.25MPa below Daihatsu supply
	(2) Cooling fresh water engine inlet	1	D	E	Range : 0-0.6MPa Alarm setting 0.15MPa below Daihatsu supply
	(3) FO engine inlet	1	D	E	Range : 0-1.0MPa Alarm setting 0.35MPa below Daihatsu supply
	(4) Starting Air engine inlet	1	D	E	Range : 0-4.0MPa Alarm setting 1.5MPa below Daihatsu supply
2	Thermometr sensor (thermo-resistance bulb)				Pt100 R100/R0=1.3850
	(1) LO engine inlet	1	D	E	install size PF3/4, L=100 Alarm setting 65deg.C over Daihatsu supply
	(2) Cooling fresh water engine outlet	1	D	E	install size PF3/4, L=100 Alarm setting 85deg.C over Daihatsu supply
	(3)				
	(4)				
	(5)				
	(6) Exhaust gas T/C inlet	1	D	E	install size PF3/4, L=100 Alarm setting 600deg.C over Daihatsu supply
	(7)				

Rev		

Item	Q'ty	Score	Ins	Specification
(8)				

3-11. Protective device

Item	Q'ty	Score	Ins	Specification
1 Switch for alarm				Abnormal contact OFF
(1)				
(2) T/C LO pressure	1	D	E	0.2MPa below 63QT
(3)				
(4)				
(5)				
(6)				
(7)				
(8)				
(9)				
(10) FO injection pipe leakage	1	D	E	High level alarm in the leakage oil tank 33F
(11)				

Rev		

	Item	Q'ty	Sc	Ins	Specification
	(12)				
2	Switch for shut-down				Abnormal contact ON
	(1) LO pressure	1	D	E	0.2MPa below 63Q2
	(2) Cooling water temp.	1	D	E	90deg.C over 26W2
	(3) Overspeed	1	D	E	112-115% 12
3	Junction box	1	D	E	
4	Wiring of electrical equipment	1	D	E	Between each equipment and junction box

Rev		

	Item	Q'ty	Sc	Ins	Specification							
1	Speed sensing device	1	D	E	Pulse type	TS						
2	Speed switch unit	1	D	H	to be installed into MSB Alarm setting <table border="0" style="margin-left: 20px;"> <tr> <td style="border-left: 1px solid black; border-right: 1px solid black; padding: 0 5px;">Low speed : 300min-1</td> <td style="padding-left: 10px;">13,14</td> </tr> <tr> <td style="border-left: 1px solid black; border-right: 1px solid black; padding: 0 5px;">LL speed : 30min-1</td> <td style="padding-left: 10px;">14L</td> </tr> <tr> <td style="border-left: 1px solid black; border-right: 1px solid black; padding: 0 5px;">Over speed : 112-115%</td> <td style="padding-left: 10px;">12</td> </tr> </table> Electric source:DC24V±25%、2.5W、with bracket	Low speed : 300min-1	13,14	LL speed : 30min-1	14L	Over speed : 112-115%	12	
Low speed : 300min-1	13,14											
LL speed : 30min-1	14L											
Over speed : 112-115%	12											
3	Starting solenoid valve	1	D	E	Electric source:DC24Vx15W Control air:0.69MPa shipyard supply	88V						
4	Shutdown device	1	D	E	Air piston type, G type with FO control device							
5	Shutdown solenoid valve	1	D	E	Exciting trip, Electric source:DC24VX15W, Control air:0.69MPa shipyard supply	Control system Safety system 5V						
6	Each cylinder fuel cut devices	6	D	E	Bosch made, air piston type							
7	Shutdown solenoid valve for each cylinder fuel cut devices	1	D	E	Exciting trip, Electric source:DC24VX15W Control air:0.69MPa shipyard supply	Safety system 5S						
8	FO control solenoid valve	1	D	E	for fuel control in process of starting Electric source:DC24VX15W Control air:0.69MPa shipyard supply	88L						
9	Handle switch	1	D	E	DC30VX6A	HS						
10	Turning safety switch	1	D	E	DC30VX6A	TC						
11	Automatic cooling water valve	1	D	E	φ 70, 3 ports, with control valve Tar-epoxy coating	20W						
12												
13	Starter for LO priming pump	1/ ship	D	H	Continuous priming during engine stop Start/stop controlled by 14/low speed							
14	Engine side control switch box	1	D	E	Start push switch Change over switch	START COS						
15												

Rev		

3-13. Spare parts and tools

1. Standard spare parts

Spare parts will be supplied in accordance with the requirement of classification society.

Details will be described in "Spare parts list" for delivery plan.

2. Tools

Tools will be supplied in accordance with Daihatsu standard practice.

Details will be described in "Tools list" for delivery plan.

3-14. Shop trials

Details will be described in "Shop trial procedure" for delivery plan.

4. Etceteras

4-1. Generator:shipyard supply(including setting bolts, taper pins, adjusting bolts and plates)

4-2. Painting color:Engine : Mansell7.5BG7/2

4-3. Drawings for engine

1. Delivery : 7sets


2. Working : 5sets

3. Finished : 4sets



Rev		

DIESEL ENGINE		AC GENERATOR	
TYPE	6DK-20	TYPE	NTAKL-VE
NO. OF CYL	6	OUTPUT	875 kVA
REVOLUTION	900 min ⁻¹	FREQUENCY	60 Hz
M A S S	8650 kg	M A S S	3750 kg
DAIHATSU DIESEL MFG. CO., LTD.		NISHISHIBA ELECTRIC CO., LTD.	

COMMON BED MASS APPROX. 1970 kg
 ACCESSORY MASS APPROX. 1620 kg
 SET TOTAL MASS APPROX. 15990 kg (DRY)





注) 船体側のリブの位置は出来るだけ共通台板のリブの位置に合す様に御配慮願います。
 Remark: Ribs of hull construction should be arranged to meet each Rib of common bed.



ADD. Ladder	2007. 10. 19	F. S
FIRST DRAWING	2007. 10. 1	M. O
本図はダイハツディーゼル株式会社所有物です。This drawing is the property of Daihatsu Diesel Mfg. Co., Ltd. Reproduction, use or disclosure to third parties without express authority of Daihatsu is strictly forbidden.		

APPROVED	ISE WAKISHI	LIST NO.	ADK20-5044-6	MATERIAL	APRV	GROUP	0	SCALE=1:25
CHECKED	HATANO NAOKAZU	BEFORE		MASS.	A	QTY.		⊙ 3 A3
DRAWN	OCHI MASARU	REF.	-	TYPE	DK-20	NAME		
DATE	2007/10/19	DAIHATSU DIESEL MFG. CO., LTD. OSAKA JAPAN			OUT LINE::			
					PARTS NO.	AQA10005008	B	*

No.	N A M E	SIZE	F7	LEAKED OIL DRAIN	20A	L1	LO CHARGE & DISCHARGE PORT	40A	L8	CRANK CASE VENT	65A	C5	COOLER COOLING WATER INLET	80A		
F1	EXHAUST GAS OUTLET	350A				△						C6	COOLER COOLING WATER OUTLET	80A		
F2	FUEL OIL INLET	25A	F9	STEAM INLET (PIPE TRACE)	φ10							C7	COOLER CW OUTLET TO BY-PASS	80A		
F3	FUEL OIL OUTLET	25A	F10	STEAM OUTLET (PIPE TRACE)	φ10							C8	CHEMICAL CLEANING (SW SIDE) BLANK	25A		
			S1	STARTING AIR INLET	25A	L6	LO FILTER BLOW OFF DRAIN	15A	C3	JACKET CW AIR VENT	15A					
			S2	CONTROL AIR INLET	φ10	L7	T/C LO FILTER BLOW OFF DRAIN	φ10	C4	JACKET CW DRAIN	φ27.2					




Remarks for (C1) connection;
 (1) 芯ずれによる冷却水ポンプケーシング損傷を防ぐ為、
 冷却水ポンプ吸込み配管を揺さぶって船体側配管に強引に取付けしないでください。
 (1) CW pump suction pipe should not be shaken before bolted down with hull-side pipe flange in order to protect the pump casing from piping stress.

△	Chg. C5, C7, C8 dimension, Rev. T/C LO FILTER POSITION	2008.02.20	M. O
△	Rev. F7 (Leak oil drain pipe fitting), Del. L2 (LO Return from purifier piping)	2007.10.19	F. S
△	FIRST DRAWING	2007.10.19	M. O

本図はダイハツディーゼル株式会社の所有物です。This drawing is the property of Daihatsu Diesel Mfg. Co., Ltd. Reproduction, use or disclosure 許可無く複製、転載及び第三者への開示を禁止します。to third parties without express authority of Daihatsu is strictly forbidden.



Z	
y	
X	
w	
v	
u	
t	
s	
r	
q	
p	
o	
n	MAIN AIR STARTING VALVE
m	START SWITCH/CONTROL POSITION CHANGE-OVER SWITCH
l	
k	SWITCH AND/OR TRANSMITTER
j	JUNCTION BOX
i	CONTROL VALVE BOX
h	
g	LEVEL SWITCH (FOR FO LEAK ALARM)
f	HANDLE SWITCH
e	TURNING SAFETY SWITCH
d	TURNING BAR HOLDER
c	TURNING DEVICE
b	FUEL SHUT DOWN DEVICE (G TYPE)
a	
Z	GAUGE BOARD
Y	
X	PRESSURE GAUGE (FO, LO, T/C LO)
W	SEA WATER VALVE
V	I/C BUTTERFLY VALVE
U	JACKET COOLING WATER PUMP
T	LO TANK CLEANING HOLE
S	LO TANK LEVEL GAUGE
R	LO BY-PASS FILTER (GF2)
Q	LO PRIMING PUMP (MOTOR DRIVEN)
P	T/C LUB. OIL FILTER
O	LUB. OIL FILTER
N	LUB. OIL RELIEF VALVE
M	LO THERMOSTAT VALVE
L	LUB. OIL COOLER
K	
J	LUB. OIL PUMP
I	
H	EXPANSION JOINT
G	GOVERNOR
F	LEVEL SWITCH BOX
E	FUEL OIL RELIEF VALVE
D	FUEL OIL INJECTION PUMP
C	FUEL OIL LINE SEAL POT
B	FUEL OIL FILTER
A	
MARK	N A M E

APPROVED	ISE WAKISHI	LIST NO.	ADK20-5044-6	MATERIAL	APRV	GROUP	0	SCALE=	1:40	
CHECKED		BEFORE		MASS.	A	QTY.			A3	
		REF.	-	TYPE	DK-20					
DRAWN	HATANO NAOKAZU	DAIHATSU DIESEL MFG. CO., LTD. OSAKA JAPAN			NAME					ギソウズ: :
DATE	OCHI MASARU				ARRANGMENT OF FITTING: :					
	2008/02/20				PARTS NO.					AQA10005009 C *



Detail "A"
(S=1:2)

NAME OF PARTS	MASS OF PARTS
PISTON&CONNECTING ROD ASSY.	97 Kg
CYLINDER LINER ASSY.	66 Kg
CYLINDER HEAD ASSY.	126 Kg
CAMSHAFT ASSY. (6DK)	160 Kg
CAMSHAFT ASSY. (8DK)	200 Kg
L. O. PUMP ASSY.	37 Kg
C. W. PUMP ASSY.	35 Kg




F	(2-B) Add: (4~5-C~D) T/C TPS480&TPS52D (DK-20-1792)	AUG. 24. '01	N.N.
E	Change (1-B): 1170 (930) → 1040 (800) (2-A): 745 → 650 (2-B) Add: Rod&Torque wrench=875 (DK-20-1431)	Feb. 15. '99	T.Aiko


APPROVED	S. Kanno	LIST NO.	E20005	MATERIAL	KUMI	GROUP	0	SCALE	(1:20)
CHECKED	R. Miki	BEFORE		MASS.	A QTY.				A3
DRAWN	T. Aiko	REF.		TYPE	DK-20				
DATE	K. IWAMI			NAME	ENGINE DISASSEMBLING SPACE				
	JAN. 25. '94			PARTS NO.	E200050510	Z	F		

DAIHATSU DIESEL MFG. CO., LTD.
OSAKA JAPAN

DWG. NO. 801632



- (1) DOタンクの取出口の位置は機関クランク軸中心より1.5m以上の高さに設けて下さい。
Outlet of DO tank to be arranged higher than 1.5m from the center of crankshaft.
- (2) 過給機空気取入口付近にはベンチレータからの通気口を設けて下さい。
Air outlet from the ventilator to be arranged near the turbocharger air inlet.
- (3) 排気伸縮接手の出口に出来るだけ近い所で、排気管は移動しないように船体側から固定して下さい。
Exhaust gas piping should be fixed immovably with hull part as close as expansion joint on turbocharger.
- (4) 排気伸縮接手を含めた船体側排気管の防熱処理は、造船所にて実施ください。
Heat insulation for exhaust gas piping of hull side including the expansion joint should be carried out by shipyard.



Remarks			
+	Flange	IXI	Valve (with flange)
	Union joint	X	Valve (Union)
+	Bite joint	IXI	Check valve
o	Banio joint	X	Cock
~	Flexible tube	STP	Steel pipe
—	By DAIHATSU	CUP	Copper pipe
---	By SHIPYARD	(P)	Press. gauge
		(T)	Thermometer
		⊗	Thermo bulb conn
		⊞	Press. switch test conn PF3/8
	Steam trace with lagging		

(注) JIS標準の相フランジは支給しません。
(NOTICE) JIS Companion flanges are not supplied by DAIHATSU.

ドレン配管、共通台板下部まで施行。
Drain pipes on engine bed are to be led to bottom of common bed by DAIHATSU.

APPROVED	ISE WAKISHI	LIST NO.	ADK20-5044-6	MATERIAL	APRV	GROUP	0	SCALE	-
CHECKED	HATANO NAOKAZU	BEFORE	-	MASS.	A	QTY.	3		A3
DRAWN	OCHI MASARU	REF.	-	TYPE	DK-20				
DATE	2007/07/18			NAME	FO & EXH. ガス ケイトウズ : :				
					F.O. & EXH. GAS PIPING SYSTEM : :				
				PARTS NO.	AQA10005010				*


△ FIRST DRAWING
2007. 10. 1 M.O
本図はダイハツディーゼル株式会社の所有物です。This drawing is the property of Daihatsu Diesel Mfg. Co., Ltd. Reproduction, use or disclosure to third parties without express authority of Daihatsu is strictly forbidden.

圧力SWテスト用座 (PF3/8)

起動空気圧力SW (63AS)


Remarks

+	Flange	II	Valve (with flange)
	Union joint	X	Valve (Union)
#	Bite joint	⊗	Valve (Needle)
○	Banjo joint		
~	Flexible tube	STP	Steel pipe
—	By DAIHATSU	CUP	Copper pipe
---	By SHIPYARD	(P)	Press. gauge
		□	Press. switch test conn PF3/8



(注) JIS標準の相フランジは支給しません。
(NOTICE) JIS Companion flanges are not supplied by DAIHATSU.

(注) デットシップ時の始動用に制御空気を供給ください。
(NOTICE) It is necessary to be supplied control air for Dead Ship Start.



only main pipe
Parkerizing

(注) 機側始動は、始動押しボタンスイッチ (電気式) による SA 入口フランジ 30K-25A 使用


△	FIRST DRAWING	2007. 7. 23	F. S
本図はダイハツディーゼル株式会社の所有物です。This drawing is the property of Daihatsu Diesel Mfg. Co., Ltd. Reproduction, use or disclosure without express authority of Daihatsu is strictly forbidden.			

APPROVED	ISE WAKISHI	LIST NO.	ADK20-5044-6	MATERIAL	APRV	GROUP	0	SCALE	-
CHECKED		BEFORE		MASS.	A	QTY.			3 A3
		REF.	-	TYPE	DK-20				
DRAWN	HATANO NAOKAZU	DAIHATSU DIESEL MFG. CO., LTD. OSAKA JAPAN		NAME S.A. ケイトウズ : :					
DATE	OCHI MASARU			S. A. PIPING SYSTEM : :					
	2007/07/18			PARTS NO.	AQA10005011	A	*		

Remarks

+	Flange	II	Valve (with flange)
	Union joint	X	Valve (Union)
#	Bite joint	II	Check valve
	Spectacle flange	X	Cock
o	Banjo joint	STP	Steel pipe
~	Flexible tube	CUP	Copper pipe
>	Reducer	P	Press. gauge
		T	Thermometer
—	By DAIHATSU	⊗	Thermo bulb conn PF3/4
---	By SHIPYARD	⊞	Press. switch test conn PF3/8

(注) JIS標準の相フランジは支給しません.
(NOTICE) JIS Companion flanges are not supplied by DAIHATSU.




ドレン配管、共通台板下部まで施行。
Drain pipes on engine are to be led to bottom of common bed by DAIHATSU.

⚠	Del. LO. Return from purifier piping	2007. 10. 19	F. S
⚠	FIRST DRAWING	2007. 10. 15	M. O
本図はダイハツディーゼル株式会社の所有物です。This drawing is the property of Daihatsu Diesel Mfg. Co., Ltd. Reproduction, use or disclosure 許可無く複写、転載及び第三者への開示を禁止します。to third parties without express authority of Daihatsu is strictly forbidden.			


APPROVED	ISE WAKISHI	LIST NO.	ADK20-5044-6	MATERIAL	APRV	GROUP	0	SCALE	-
CHECKED	HATANO NAOKAZU	BEFORE		MASS.	A	QTY.			A3
DRAWN	OCHI MASARU	REF.	-	TYPE	DK-20				
DATE	2007/10/19			NAME	LOケイトウズ: : L. O. PIPING SYSTEM: :				
				PARTS NO.	AQA10005012		B	*	

DAIHATSU DIESEL MFG. CO., LTD.
OSAKA JAPAN

圧力SWテスト座 (PF3/8) 20W (3方) ケミカル座 (入口側/出口側) クーラ系入口圧力計 FW圧力発信器 (PT2) クーラ系冷却管 (SCH40, Zn)



Remarks			
+	Flange	II	Valve (with flange)
	Union joint	X	Valve (Union)
#	Bite joint	II	Check valve
	Orifice	X	Cock
o	Banjo joint	STP	Steel pipe
~	Flexible tube	CUP	Copper pipe
∞	Flex-master	P	Press. gauge
⊠	Butterfly valve	T	Thermometer
—	By DAIHATSU	⊗	Thermo bulb conn PF3/4
---	By SHIPYARD	⊠	Press. switch test conn PF3/8



(注) JIS標準の相フランジは支給しません。
 (NOTICE) JIS Companion flanges are not supplied by DAIHATSU.

Sea water pipe
 Zn plating
 Fresh water pipe
 Parkerizing

Cooler line

Jacket line

ドレン配管、共通台板下部まで施行。
 Drain pipes on engine are to be led to bottom of common bed by DAIHATSU.

△	FIRST DRAWING	2007. 7. 23	F. S
本図はダイハツディーゼル株式会社の所有物です。This drawing is the property of Daihatsu Diesel Mfg. Co., Ltd. Reproduction, use or disclosure to third parties without express authority of Daihatsu is strictly forbidden.			


APPROVED	ISE WAKISHI	LIST NO.	ADK20-5044-6	MATERIAL	APRV	GROUP	0	SCALE	-
CHECKED	HATANO NAOKAZU	BEFORE		MASS.	A	QTY.			A3
DRAWN	OCHI MASARU	REF.	-	TYPE	DK-20				
DATE	2007/07/18			NAME	CWケイトウズ: :				
					C. W. PIPING SYSTEM: :				
				PARTS NO.	AQA10005013		A	*	

DAIHATSU DIESEL MFG. CO., LTD.
OSAKA JAPAN

遠隔温度センサー配線は1回ループのこと

F入口差圧圧力 ガバサ RHD (DC24V)


1				2				3				4				5				6				7			
MARK	NAME	USE	NOTE		NAME	USE	NOTE	REMARKS	MARK	NAME	USE	NOTE	REMARKS	MARK	NAME	USE	NOTE	REMARKS	MARK	NAME	USE	NOTE	REMARKS				
TB1	Exh. gas T/C inlet temp.	IND. & Alarm	Over 600 °C	DAIHATSU SUPPLY	63Q2	L.O. Press. switch	Stop	Below 0.2 MPa (1-2) ON	Normal open	GM	Governor motor	Speed control	Hydraulic constant speed governor control DC 24V														
TB2	L.O. engine inlet temp.	IND. & Alarm	Over 65 °C	DAIHATSU SUPPLY	26W2	F.W. Thermal switch	Stop	Over 90 °C (1-4) ON		88V	Start air magnet. valve	Start	DC 24V, about 0.3A														
TB3	F.W. engine outlet temp.	IND. & Alarm	Over 85 °C	DAIHATSU SUPPLY	COS	Change Over Switch	Local/Remote	Select remote start position contact (1-2) ON		14, 13	Low speed contact	Control	Over 300min ⁻¹ , contact (14C-14A) ON, (13C-13A) OFF														
					START	Start switch	Start	When pushing the switch, contact (3-4) ON		14L	Contact for interlock	Start interlock	Over 30min ⁻¹ , contact..! (14LC-14LA) ON OFF delay 8 seconds														
					33F	Level switch (Leaked oil tank)	Alarm	When F.O. High press. pipe broken contact (2-2) OFF		12	Over speed contact	Stop	Over 112~115%, contact... (12C-12A) ON														
PT1	L.O. engine inlet press.	IND. & Alarm	Below 0.25 MPa	DAIHATSU SUPPLY	63QT	T/C LO Press. switch	Alarm	Below 0.2 MPa (1-3) OFF	Normal close	TS	Speed sensor	Speed detect	Pulse sensor type														
PT2	F.W. engine inlet press.	IND. & Alarm	Below 0.15 MPa	DAIHATSU SUPPLY						5V	Fuel shut down magnetic valve	Control & safety	DC 24V, 0.7A, Fuel shut down when solenoid magnetized	Exciting trip													
PT3	F.O. engine inlet press.	IND. & Alarm	Below 0.35 MPa	DAIHATSU SUPPLY						5S	Fuel shut down magnetic valve	Safety	DC 24V, 0.7A, Fuel shut down when solenoid magnetized														
PT4	S.A. engine inlet press.	IND. & Alarm	Below 1.5 MPa	DAIHATSU SUPPLY						88L	Fuel control piston magnetic valve	Fuel control	DC24V, 0.7A FO control in starting process when solenoid magnetized														
										TC	Turning safety switch	Stand-by	When turning bar used contact (3-4)...OFF	Normal close													
										HS	Handle switch	Stand-by	At running position contact (2-4)..ON, (1-2)..OFF														
										PM	L.O. Priming pump motor		AC 440V, 3φ, 60Hz, 0.94kW, 2.0A														



- Note:
- This drawing shows the normal running.
 - Wiring between each device and junction box should be carried out by the engine maker.
 - * Marked cable and the wiring works should be carried out by the ship builder.
 - Diode for magnetic valve: correspond 10DDA40/NIHON INTER CO., LTD.
 - Surge killer from governor motor: ENC390D-10B/FUJII ELECTRIC CO., LTD.


APPROVED	ISE WAKISHI	LIST NO.	ADK20-5044-6	MATERIAL	APRV	GROUP	0	SCALE	-
CHECKED	HATANO NAOKAZU	BEFORE		MASS.	A	QTY.			A3
DRAWN	OCHI MASARU	REF.		TYPE			DK-20		
DATE	2007/11/12			NAME	ケッセンズ: : WIRING DIAGRAM: :				
				PARTS NO.	AQA10005014		B	*	

△ Add. Relay, Chg. Terminal No. 2007.11.12 M.O
 △ FIRST DRAWING 2007.10.1 M.O
 本図はダイハツディーゼル株式会社所有物です。This drawing is the property of Daihatsu Diesel Mfg. Co., Ltd. Reproduction, use or disclosure 許可無く複写、転載及び第三者への開示を禁止します。to third parties without express authority of Daihatsu is strictly forbidden.




電源	POWER VOLTAGE	DC24V (±25%) リップル10%以下	24VDC (±25%) RIPPLE 10% OR LESS
消費電力	POWER CONSUMPTION	最大3.2W	3.2W MAX.
計測精度	MEASURING ACCURACY	0.05%±1digit atF.S. ±0.5% atF.S. (アナログ出力)	0.05%1digit atF.S. ±0.5% atF.S. (analog output)
計測範囲	MEASURING RANGE	2Hz~7kHz/0~9990min ⁻¹	2Hzto7kHz/0to9990min ⁻¹
入力 INPUT		パルスセンサ出力信号 (ロー:8V以下) (ハイ:15V以上)	PULSE SENSOR OUTPUT SIGNAL (LOW:under 8V) (HI.:Over 15V)
出力 OUTPUT	アナログ出力 ANALOG	4~20mA (負荷抵抗最大500Ω)	4to20mA (load resistance500Ω MAX.)
	接点出力 CONTACT	AC・DC100V 0.1A (無電圧半導体接点)	100VAC/VDC 0.1A (voltage free contact)
	周波数出力 FREQUENCY	1Hz/1回転(60Hz以下は除く) 0~15V(負荷抵抗5kΩ以上)	1Hz/1ROTATION(without under 60Hz) 0to15V(load resistance5kΩover)
表示 DISPLAY	デジタル表示 DIGITAL DISPLAY	7セグメントLED(赤)×4桁(輝度調整有り)	7SEGMENTS LED×4DIGITS(WITH DIMMER)
	LED表示 LED LAMP	#12(赤), #13(緑) #14(緑), #14L(緑)	#12(RED), #13(GREEN) #14(GREEN), #14L(GREEN)
絶縁抵抗	INSULATION RESISTANCE	導体部-箱体間 20MΩ以上 DC50V	CONDUCTOR-BODY OVER20MΩ 50VDC
耐電圧	DIELECTRIC STRENGTH	接点出力-箱体間 AC1500V 1分間	CONTACT OUTPUT-BODY 1500VAC 1min.
使用温度	OPERATING TEMP.	+5~+55℃	+5to+55℃
保存温度	STORAGE TEMP.	-20~+65℃	-20to+65℃
相対湿度	RELATIVE HUMIDITY	95%以内(但し、結露がないこと)	WITHIN 95%(NON CONDENSATION)
雰囲気	ATMOSPHERE	腐食性ガスがないこと	WITHOUT CORROSIVE GAS
振動	VIBRATION RESISTANCE	5~13.2Hz ±1mm, 13.2~100Hz 0.7G	
衝撃	SHOCK RESISTANCE	10G以内	WITHIN 10G
材質	MATERIALS	グラスファイバー強化樹脂	PLASTIC WITH GLASS FIBER
塗装色	BODY COLOR	樹脂自然色(黒)	BLACK(PLASTIC NATURAL COLOR)
重量	WEIGHT	0.2kg	

入出力コネクタ
I/O CONNECTOR




上側コネクタ
UPPER CONNECTOR
下側コネクタ
LOWER CONNECTOR

取付具(付属品)
MOUNTING PART(ACCESSORIES)



パネルカット
PANEL CUT




端子番号
TERMINAL NUMBER

端子番号	用途	用途
TERMINAL NUMBER	OBJECT	OBJECT
FG	: フレームグラウンド	FRAME GRAND
P	: DC24V	
N	: 0V	
+	: DC24V	PULSE INPUT
S	: パルス入力	} センサ SENSOR
-	: COM	
F+	: 周波数出力	FREQUENCY OUTPUT
F-	: COM	
M+	: 電流出力	CURRENT OUTPUT
M-	: COM	} オプション OPTION

- 12a : #12 検知接点 #12 DETECTION CONTACT OUTPUT
- 12c : #12 検知接点 #12 DETECTION CONTACT OUTPUT
- 13a : #13 検知接点 #13 DETECTION CONTACT OUTPUT
- 13c : #13 検知接点 #13 DETECTION CONTACT OUTPUT
- 14a : #14 検知接点 #14 DETECTION CONTACT OUTPUT
- 14c : #14 検知接点 #14 DETECTION CONTACT OUTPUT
- 14La : #14L タイマー接点 #14L TIMER CONTACT OUTPUT
- 14Lc : (※使用にあたっては「マニュアル」参照のこと REFER TO THE MANUAL.)

パルスセンサ接続図
PULSE SENSOR CONNECTION



※パルスセンサの検出異常を利用する時は、リレーを使用して下さい。リレーはオムロンMY4-D相当品(コイル定格電流30mA以下)のものを選定下さい。




※Please use a relay, when you use the sensor failure output on the pulse sensor. A relay should select the "OMRON MY4-D" or equivalent it (30mA or less of relay coil rated current).

E	(6~7-E) CHANGE	(E005098)	2007/02/23	T. N
D	(6~7-E) CHANGE		2006/03/15	T. NAKAMITSU
C	(4-D) ADD. "UP", "DN", φ6→φ5, 15→17		2005/12/08	K. YOSHIDA
B	(1~4-D) MDP-REV-D→MDP-REV, 6xφ6, (4~7-A~D) CHANGE		2005/02/14	K. YOSHIDA
A	FIRST DRAWING		2004/06/21	K. YOSHIDA


APPROVED	MOCHIDUKI MASARU	LIST NO.	NN00262	MATERIAL	ASSY.	GROUP	9	SCALE=	1:1
		BEFORE		MASS.	-	A	QTY.	-	⊙ 3 A3
CHECKED		REF.	-	TYPE	MES				
DRAWN	CHUJYOU JYUNYA			NAME	カンビセン:ソクドスイッチユニット:-D				
DATE	(H)NAKAMITSU TOSHIO			ASSY.:	SPEED SWITCH UNIT:-D				
	2007/02/23			PARTS NO.	NN00262001A	E	*		

DAIHATSU DIESEL MFG. CO., LTD.
OSAKA JAPAN

1 2 3 4 5 6 7



端子接続図 Terminal connection



仕様 Specifications

- 1)重量 WEIGHT about 0.6kg
- 2)塗装色 COLOR MUNSELL 1.5N


【注記】【NOTE】

- 当ブラケットは“ソクドスイッチユニット2”を“ソクドスイッチユニット-D”へ換装する為のブラケットである。
This bracket is for changing the “speed switch unit2” into the “speed switch unit-D”.
- ソクドスイッチユニット-Dの詳細は、“カンピヒン：ソクドスイッチユニット：-D (NN00262001A)を参照のこと。
The detail of the “speed switch unit-D” refer to “ASSY :SPEED SWITCH UNIT:-D” (NN00262001A).

APPROVED	MOCHIDUKI MASARU	LIST NO.	NN00262	MATERIAL	KUMI	GROUP	O	SCALE=	1:2
CHECKED		BEFORE		MASS.	-	A	QTY.	-	⊙ 3 A3
		REF.	-	TYPE	MES				
	CHUJYOU JYUNYA	DAIHATSU DIESEL MFG. CO., LTD. OSAKA JAPAN			NAME ショウニズ:ゴカンソクドスイッチ2:ソクドスイッチ-D				
	YOSHIDA KENTAROU				APPROVAL:INTERCHANGEABLE SPEED SWITCH2:SPEED SWITCH-D				
		DATE	2004/07/01	PARTS NO.	NN00262K005		A	*	

△ FIRST DRAWING

2004/07/02 K.YOSHIDA



電圧調整トリマー
V. ADJ: Voltage Adjustable Trimmer

SPECIFICATIONS


INPUT : AC100Vrms (85~132Vrms : 47~440Hz)
OUTPUT : DC20±20% (TO PM MOTOR)
(DC16~24V)

NOTE)

1. The Governor speed rise/lower change over switch should be arranged in between this unit and the motor.
(ガバナスピードの上げ下げ切りかえは、本装置の2次側にスイッチを設けて行ってください。)

CAUTION)

1. Do not stall the motor for a long time, it could burn out the motor or this unit
(長時間ガバナモータをストールさせた状態で放置するとモータや本装置の故障の原因となります。)



APPROVED	CHUJYOU JYUNYA	LIST NO.	NN00031	MATERIAL	KUMI	GROUP	0	SCALE=	1:1															
CHECKED		BEFORE		MASS.	-	A	QTY.	-	⊙ 3 A3															
		REF.	-	TYPE	MES																			
	CHUJYOU JYUNYA	DAIHATSU DIESEL MFG. CO., LTD.			NAME ショウニズ:ガバナコントロールユニット B:AC100V																			
	(H)WITSUTAKE KYOKO				APPROVAL:GOVN. CONTROL UNIT B:AC100V																			
DRAWN		DATE 2007/08/08			PARTS NO. NN00031K011 C *																			
<table border="1"> <tr> <td>C</td> <td>ADD INPUT ALLOWABLE RANGE</td> <td>(E005839)</td> <td>2007/08/08</td> <td>K. M</td> </tr> <tr> <td>B</td> <td>CHANGE OF DRAWING</td> <td>(E005811)</td> <td>2007/08/01</td> <td>T. N</td> </tr> <tr> <td>△</td> <td>FIRST DRAWING</td> <td></td> <td>2006/08/22</td> <td>T. N</td> </tr> </table>										C	ADD INPUT ALLOWABLE RANGE	(E005839)	2007/08/08	K. M	B	CHANGE OF DRAWING	(E005811)	2007/08/01	T. N	△	FIRST DRAWING		2006/08/22	T. N
C	ADD INPUT ALLOWABLE RANGE	(E005839)	2007/08/08	K. M																				
B	CHANGE OF DRAWING	(E005811)	2007/08/01	T. N																				
△	FIRST DRAWING		2006/08/22	T. N																				
<p>本図はダイハツディーゼル株式会社の所有物です。This drawing is the property of Daihatsu Diesel Mfg. Co., Ltd. Reproduction, use or disclosure 許可無く複製、転載及び第三者への開示を禁止します。to third parties without express authority of Daihatsu is strictly forbidden.</p>																								



DIESEL GENERATOR ENGINE
 L.O.PRIMING PUMP(16)
 L.O.プライミングポンプ(16)
 TYPE: ACD 025N61VBP
 PUMP: 2.5m³/h × 0.2MPa
 MOTOR: AC440V, 3φ, 60HZ, 0.94kW, 2.0A, F

DAIHATSU DIESEL MFG. CO., LTD.
 TECHNICAL DEPARTMENT
 JAPAN

SHIP No.		DRAWN BY	<i>H. Yamane</i>
TYPE		CHECKED BY	<i>K. Fujii</i>
LIST No.	B106605010ZZ		
DATE	MAR. 21, 2007	APPROVED BY	<i>S. Miyamoto</i>
REVISION			


B1066#016

Drawing Type - No. **MS-24572** Rev.




40 Space for dismantling

40 Space for dismantling



AC 440 V 60.HZ



M25 - 20b. Cable gland

Terminal box

Dimensions in mm.

Weight approx. 16kg

Mounting: M00-9

Subject to change without notice. Not binding unless certified.

Applicable to the following version codes.

Housing mtrl.	I N
Shaft seal	T V
Mounting	B
Valve arr.	P

Article No.	Name/Designation	Material Blank	Pattern No./Note
	IMO AB Stockholm Sweden		
Title		IMO-Pump unit	
		Pump: ACD 025L6, ACD 025N6	
		Motor: Siemens 1LA09 073	
Symbol	Draw Date/Sign	Scale	First angle Projection
- for tolerances: SS-ISO 280-1	01.10.19 LN	1:2.5	
- for form and position: SS-ISO 901	Checked and approved D/S	Complementary Drawing No.	
- for surface roughness: ISO 1312	01.10.19 JS		
Tolerances if not otherwise stated	Production checked D/S		
- machined surfaces: ISO 2768-mS-E			
- castings: ISO 8062 CT10			
Burrs removed, edges 0,4x45° or R 0,5	Rol for manufacturing D/S		
Drawing Type/No.		MS-24572	
		Rev.	

Only in the extent expressly agreed by us this document may constitute a contractual obligation on our part.

This document is not to be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording, or otherwise, without the prior written permission of IMO AB.

B106605010ZZ (2/8)

Rev.	Revision	Revised Date/Sign	Appr.

Replaces drawing No.:

2

3

4

5

6



IMO AB
Stockholm
Sweden

SECTIONAL DRAWING


ACD 025N6 IVBP

Drawing Type-No.

A-ACD-003B


Sheet 1 of 1

Scale 1:2



Only to the extent expressly agreed by us this document may constitute a contractual obligation on our part.

This document and its contents are our exclusive property and must not be copied, reproduced, transmitted or communicated to any other party or used for purposes not expressly permitted by us.



B	Omritad på CAD	99.12.27 LN	
A	RÅ105689	96.09.11 LN	AL
	Original	95.06.21 LN	AL
Rev.	Revision	Revised (Date/Sign)	Appr.

Drawing Type-No.

A-ACD-003

Rev.

B

Pos NO	NAME	PCS.
1020	Power rotor	1
134	Locking screw	1
162	Nylon sleeve socket	1
202	Idler rotor	2
401	Pump body	1
418	Gasket	1
443	Drip nipple	1
451	Screw	8
501	Front cover	1
506	O-ring alt. Gasket	1
509	Shaft seal	1
551	Rear cover	1
556	Gasket	1
601	Valve cover	1
602	Sealing washer	1
605	O-ring	1
612	Regulating screw	1
612A	Retaining ring	1
614	Valve piston	1
615	Valve spring	1


SPECIFICATION	
CAPACITY	2.5m ³ /h
TOTAL HEAD	0.2Mpa
SUCTION HEAD	-0.04Mpa
SETTING PRESS. OF SAFETY VALVE	0.22Mpa
SIEMENS MOTOR	0.94KW, 440V, 60HZ 2P, 3300rpm. Rated Current 2.0 A Starting Current 9.6 A
START METHOD	DIRECT START
PROTECTION	IP55
INSULATION CLASS	F

Dimensions
Maße

Type IMB5 and IMV1

Bauform IMB5 und IMV1

Frame sizes 56M to 200L
1LA9 - Baugrößen 56 M bis 200 L




For motor Für Motor: Size Baugröße	Type Typ	No. of poles Polzahl	Dimension drawing Maßbezeichnung nach														
			IEC DIN	Flange size Flanschgröße	AC 1)	AD	AG	AG	AD	BE	BE	HH	HK	L	LA	LC	LE
56 M	1LA9 050* 1LA9 053*	2 und 4	A 120	116	101	75	77,5		32	14	69,5	39	169	8	200	20	75
53 M	1LA9 060 1LA9 063	2 und 4	A 140	118	101	75	77,5	125	32	14	69,5	39	202,5 228,5	9	232 258	23	75
71 M	1LA9 070 1LA9 073	2 und 4 and	A 160	145	111	75	87,5	125	32	14	63,5	39	240	9	278	30	75

MOTOR REAR & FRONT COVER : CAST IRON


1) Über die Schraubenköpfe gemessen
Measured across the screw

Dimensions
Maße




Type IMB5 and IMV1


LM	M	N	D	P	S	T	Z	Drive-end shaft extension AS-Wellenende					Non-drive-end shaft extension BS-Wellenende						
								D	DB	E	EB	E	GA	DA	DC	EA	EC	FA	GC
-	100	80	M16x1,5 M25x1,5	120	7	3	4	9	M3	20	14	3	10,2	9	M3	20	14	3	10,2
236	115	95	M16x1,5 M25x1,5	140	10	3	4	11	M4	23	16	4	12,5	11	M4	23	16	4	12,5
262																			
269	130	110	M16x1,5 M25x1,5	160	10	3,5	4	14	M5	30	22	5	16	14	M5	30	22	5	16




With cover plates 3-20mm
ned skyddsplåtar,
3-20 mm



With one cover plate, type Z
Med en skyddsplåt,
utörande Z



With two cover plates, type ZZ
Med två skyddsplåtar,
utörande ZZ



Main dimensions Huvudmått			Carrying capacity Bæreevne dyn. C stat. C ₀	Exhaustion load Utmatt- ningsbe- lastning P ₀	Basic speed (RPM) Bærevrtal Smørrning fett olja	Mass Masse kg	Designation, bearing Beteckningar Lager med en skyddsplåt with one cover plate		with two skyddsplåtar cover plates	
d	D	B					N	N	r/min	
3	10	4	485	146	6	80 000	70 000	0,0015	623-Z	623-ZZ
4	13	5	975	305	14	48 000	56 000	0,0031	624-Z	624-ZZ
	16	5	1 110	380	16	43 000	50 000	0,0054	634-Z	634-ZZ
5	16	5	1 110	380	16	43 000	50 000	0,0056	625-Z	625-ZZ
	19	6	1 720	620	26	36 000	43 000	0,0090	635-Z	635-ZZ
6	19	6	1 720	620	26	36 000	43 000	0,0084	626-Z	626-ZZ
	7	19	6	1 720	620	26	36 000	45 000	0,0075	607-Z
22		7	3 250	1 370	57	32 000	38 000	0,013	627-Z	627-ZZ
8	22	7	3 250	1 370	57	36 000	43 000	0,012	608-Z	608-ZZ
	9	24	7	3 710	1 660	71	32 000	38 000	0,014	609-Z
26		8	4 620	1 960	83	28 000	34 000	0,020	629-Z	629-ZZ
10	28	8	4 820	1 980	83	30 000	36 000	0,019	6000-Z	6000-ZZ
	30	9	5 070	2 380	100	24 000	30 000	0,032	6200-Z	6200-ZZ
	35	11	8 080	3 400	143	20 000	26 000	0,053	6300-Z	6300-ZZ
12	28	8	5 070	2 360	100	28 000	32 000	0,022	6001-Z	6001-ZZ
	32	10	6 890	3 100	132	22 000	28 000	0,037	6201-Z	6201-ZZ
	37	12	9 750	4 150	178	19 000	24 000	0,060	6301-Z	6301-ZZ
15	32	8	5 590	2 850	120	27 000	31 000	0,025	6002-Z	6002-ZZ
	32	9	5 590	2 850	120	22 000	28 000	0,030	6002-Z	6002-ZZ
	35	11	7 800	3 750	160	19 000	24 000	0,045	6202-Z	6202-ZZ
	42	13	11 400	5 400	228	17 000	20 000	0,082	6302-Z	6302-ZZ

d	d ₁	D ₂	r _{1,2}	d _a	D _a	r _a
mm	mm	mm	mm	mm	mm	mm
3	5,2	8,2	0,15	4,2	8,8	0,1
4	6,7	11,2	0,2	5,5	11,4	0,2
	8,4	13,3	0,3	6	14	0,3
5	8,4	13,3	0,3	7	14	0,3
	10,7	16,5	0,3	7	17	0,3
6	10,7	16,5	0,3	8	17	0,3
	7	10,7	16,5	0,3	9	17
11,8		19	0,3	9	20	0,3
8	11,8	19	0,3	10	20	0,3
	9	14,2	21,2	0,3	11	22
14,4		22,8	0,3	11	24	0,3
10	14,4	22,8	0,3	12	24	0,3
	15,7	24,8	0,5	14	26	0,6
	17,5	28,7	0,6	14	31	0,6
12	16,7	24,8	0,3	14	26	0,3
	18,2	27,4	0,6	16	28	0,6
	19,5	31,5	1	17	32	1
15	20,2	28,2	0,3	17	30	0,3
	20,2	28,2	0,3	17	30	0,3
	21,5	30,4	0,6	19	31	0,6
	23,7	36,3	1	20	37	1

SIEMENS

Data sheet for three-phase Squirrel-Cage-Motors

Kunden-Auftrags-Nr./Client-Order-Nr.:

Item-Nr./Item-No.:

Siemens-Auftragsnr./Order-No.:

Komm.-Nr./Consignment-No.:

Bestell-Daten/ Ordering Data

Allgemeine Daten/ General Data

Hersteller **Siemens**
 Motortyp **1LA9073-2LA91**
 Kurzangaben **LIY**

Baugröße **71 M**
 Bauform **IM B3**
 Gewicht in kg **7.2 kg**
 Gehäusematerial **Aluminium/ Aluminium-ali.**
 Gehäusefülle **angegossen/ cast**
 Schutzart **IP 55**
 Kühlart, TEFC **IC 41**
 Vibrationsklasse **N**
 Isolierung **F, ausgenutzt B/E, utilized B**
 Betriebsart **S1**
 Anlaufart **direkt/ direct**
 Drehrichtung **bi-direktional/ bi-directional**
 Schaltung **Y STAR**

Elektrische Daten/ Electrical Data

Nennspannung **440 V** **Y**
 Frequenz **50 Hz**
 Nennleistung **0.94 kW**
 Nenn Drehzahl **3300 min-1**
 Nennmoment **3.22 Nm**
 Nennstrom **2.0 A**
 Anzugs-/Nennstrom **9.6**
 kipp-/Nennmoment **2.4**
 Anzugs-/Nennmoment **2.5**
 Wirkungsgrad bei 100% Pn **73 %**
 bei 75% Pn **73 %**
 bei 50% Pn **70 %**
 Leistungsgradklasse **nicht definiert/ undefined**
 Leistungsfaktor bei 100% Pn **0.82**
 bei 75% Pn **0.77**
 bei 50% Pn **0.67**

Klemmenkasten/ Terminal box

Klemmenkastenmaterial **Aluminium/ Aluminium-ali.**
 Typ **gk 030**
 Gewinde Kontaktschraube **M4**
 Max. Leiterquerschnitt **2.5 mm²**
 Max. Kabeldurchmesser **4.5 - 10 mm; 9 - 17 mm**
 Kabelführung **1xM16x1.5; 1xM25x1.5**
 Zweifelh. Platte; max. Dm **---**
 Anordnung **(Oben/ On the top of motor)**

Mechanische Daten/ Mechanical Data

Geräusch **52 dB(A)**
 Drehmoment **4.00058 kgm²**
 Lager AS **COUPLING SIDE 6202 2C3**
 Lager BS **ANTI COUPLING SIDE 6202 2ZC3**
 Festlager/ Kondenswasserfühler **nein/ no / nein/ no**
 Nachschmierung **nein/ no**
 Schmiermittel **Unirex N3, Fa. Essö**
 Fettgebrauchsdauer: 30°C/25% **10000 h / 20000 h**
 Äußere Erdungsklemme **nein/ no**
 Anstrich **Sonderanstrich RAL 7030/**
 Paintwork **Special paintwork RAL 7030**

Sonderausführungen/ Special configurations

LIY = 3 AC 60 Hz, 440 V, Pn=1.1 kW
 bei KT=40 °C, Höhe=1000 m

Explosionsschutz/ Explosion protection

Zündschutzart **kein Ex-Schutz/ no Ex-protection**
 t_{ex}Zeit, T₁, T₂ bzw. T₃ **---**
 n-nom, 11, T₂ resp. T₃ **---**



Umgebungsbedingungen/ Site conditions

Umgebungstemperatur **50 °C**
 Höhe über Meeresspiegel **1000 m**

Normen und Vorschriften **IEC, DIN, EN, VDE, ISO.**
 Standards and Specifications


Bemerkungen/ Remarks:

B106605010ZZ (8/8)



③ DETAIL
(LINER・内筒)

4 x M16 ⑥
L = 220
出荷時、取付寸法で固定、
取付完了後除去のこと
(TO BE REMOVED
AFTER INSTALLTION)



許容変位線図
(ALLOWABLE MOVE CURVE)

仕様 SPECIFICATIONS		
AXIAL MOVE ΔX (SET LENGTH BASE) 軸方向変位量 ΔX (取付寸法基準)	EXTENSION 伸び 5 mm	CONTRACTION 縮み 30 mm
LATERAL MOVE ΔY 横変位量 ΔY	偏心 ECCENTRIC 5 mm	
WORKING P. 使用圧力	0.003	MPaG
WORKING T. 使用温度	MAX. 550	°C
SPRING RATON バネ定数	62.8	N/mm

用途 APPLICATIONS	機関・排気ガス ENGINE EXHAUST GAS
-----------------	----------------------------

ITEM 部品番号	PAPT NAME 部品名	MATERIAL 材質	REQD 数量	WEIGHT 重量	REMARK 備考
10					
9					
8					
7	HOLDER	SS400	4x2		
6	SHIPPING BOLTS	SS400	4		
5	FLANGE	SS400	1		JIS5K 相当
4	WELD BAND	SUS304	1		t0.8x20
3	LINER	SUS304	1		
2	BELLOWS	SUS321	1		
1	FLANGE	SS400	1		JIS5K

APPROVED	MIYAZAKI SYUJI	LIST NO.	NN00271	MATERIAL	PCHS	GROUP	7	SCALE	1:5
CHECKED		BEFORE		MASS.	36.6kg	QTY.	1/Eng		
		REF.	日本ダイハツ M-16687(B2597)	TYPE	ALL				
DRAWN	SAIDA SYUICHI	DAIHATSU DIESEL MFG. CO., LTD. OSAKA JAPAN		NAME ハイキシンシュクセツシュ: 250A x 350A					
DATE	2004/10/08			EXPANSION JOINT: 250A x 350A					
				PARTS NO.	NN00271011B			B	*

DIESEL GENERATOR ENGINE
L.O. PRIMING PUMP STARTER

SASEBO HEAVY INDUSTRIES CO., LTD.

DAIHATSU DIESEL MFG. CO., LTD.
TECHNICAL DEPARTMENT
OSAKA, JAPAN

SHIP No.	761/762	DRAWN BY	<i>M. Ochi</i>
TYPE	6DK-20	CHECKED BY	<i>N. Katon</i>
LIST No.	AQA10005017A		
DATE	Jul. 20, 2007	APPROVED BY	<i>[Signature]</i>
REVISION			

ADK20-5047-9



SASEBO HEAVY INDUSTRIES CO., LTD

S.No.761
S.No.762

DAIHATSU DIESEL MFG. CO., LTD.

DIESEL GENERATOR ENGINE
L.O. PRIMING PUMP STARTER

RULE : ABS-ACCU

6DK-20

Kyosan Electric Mfg. Co., Ltd.

△ 10.SEP.2007

DWG. No. KS2007027

S.No.762 : ADK20-5047-9
S.No.761 : ADK20-5044-6

AQA10005017A





(2/8)



**Kyosan
Electric Mfg.
Co., Ltd.**

9-4 MARUNOUCHI, CHIYODA-KU, TOKYO JAPAN
Cable Address: SIGNALKYOSAN TOKYO

AQA10005017A (3/8)




PROTECTION GRADE IP44
 PAINT COLOR
 MUNSELL 7.5BG7/2

WEIGHT ABOUT 50Kg


1 SET PER VESSEL

12		⚠ CAUTION ELECTRIC HAZARD	PL LABEL
11		THE SELECTOR SWITCH SHOULD BE ALWAYS KEPT AT "ON" POSITION.	CAUTION PLATE
10	SW1 SW2 SW3	AUTO. OFF — ON	SELECTOR SWITCH
9		SOURCE AC440V	NAME PLATE
8	DS1 DS2 DS3	OFF — ON	DISCON. SWITCH
7	RL1 RL2 RL3	ABNORMAL	LAMP (RED)
6	GL1 GL2 GL3	RUNNING	• (GREEN)
5	WL1 WL2 WL3	SOURCE	• (WHITE)
4		No. 3 G/E	NAME PLATE
3		No. 2 G/E	"
2		No. 1 G/E	"
1		L. O. PRIMING PUMP STARTER	"
No.	MARK	NAME PLATE	NOTE


△						DIESEL GENERATOR ENGINE L.O. PRIMING PUMP STARTER OUT LINE	
△							
△							
MARK	REVISION	BY	DATE	SCALE	DWG. NO.		
T.K			19. JUL. '07	1/10	KS2007027-1		




△						DIESEL GENERATOR ENGINE L.O. PRIMING PUMP STARTER SEQUENCE DIAGRAM (No.1 G/E)
△						
△			T.Konishi	10.SEP.2007		
MARK	REVISION	BY	DATE	SCALE	DWG.NO.	
DESIGNED	CHECKED	APPROVED	DATE	SCALE	DWG.NO.	KS2007027-201
T.K	[Signature]	[Signature]	19.JUL.'06	/		



△						
△						
△			T.Konishi	10.SEP.2007		
MARK	REVISION	BY	DATE	SCALE	DWG.NO.	
T.K			19.JUL.'06	/	KS2007027-202	




L.O. PRIMING PUMP
(FOR No.3 G/E)








THERMAL RELAY Δ

ADJUSTING SCOPE	SETTING	MOTOR
1.7~2.5A	2A	0.94KW





SHEET No.

Δ				DIESEL GENERATOR ENGINE L.O. PRIMING PUMP STARTER SEQUENCE DIAGRAM (No.3 G/E)	
Δ					
Δ			T.Konishi	10.SEP.2007	
MARK	REVISION	BY	DATE	SCALE	DWG.NO.
T.K			19.JUL.'06	/	KS2007027-203

SHIP No.	SPARE PARTS LIST FOR		U S E			SETS PER VESSEL	
761 762	L.O. PRIMING PUMP STARTER		DIESEL GENERATOR ENGINE			1	
ITEM No.	NAME OF PART	OUTLINE	QUANTITY			REMARKS	
			WORKING		SPARE		
PER SET	PER VESS						
1	PILOT LAMP GLOBE		3	3	1	WHITE	FOR APN118 IDEC
2	PILOT LAMP GLOBE		3	3	1	GREEN	FOR APN118 IDEC
3	PILOT LAMP GLOBE		3	3	1	RED	FOR APN118 IDEC
4	PILOT LAMP		9	9	9	E-12, 18V, 2W	
5	FUSE ELEMENT		12	12	12	UC-1, 3A UTSUNOMIYA ELEC.	
6							
7							
8							
9							
10							
MFR'S NAME		KYOSAN ELECTRIC MANUFACTURING CO., LTD		DRW. No.	KS2007027-3		

HISTORY OF DRG.		DATE
<input checked="" type="checkbox"/>	New Drawing	Oct. 14, '97
<input checked="" type="checkbox"/>	Assy No. 訂正	1997.1.13

2007/10/23 TECHNICAL DEPARTMENT




SIZE
 φ90 under square flanges
 φ100 over round flanges

MAX. DIFFERENTIAL PRESS. $\times 10^5 \text{ cm}^2$ (Lub. oil press. $3.5 \times 10^5 \text{ cm}^2$)		
SIZE	PORT 1 → 2	PORT 1 → 3
φ70	7.0	2.0
φ80	4.5	1.5
φ90	3.5	1.2
φ100	3.0	1.0

No	ASSY No.	SIZE	D	d	L	h1	h2	H	A	B	C	R	M
1													
2	S100719162B	φ70	2 1/2 B	65	200	78	62	397	φ85	φ114	122	φ	H12
3	S100719163B	φ80	3 B	80	240	78	78	364	φ110	φ146	156	φ	H16
4	S100719164B	φ90	3 1/2 B	95	280	115	85	408	φ126	φ162	172	φ	H16
5	S100719165B	φ100	4 B	103	350	110	110	426	φ165	φ200	220	φ	H16
6													

NO.	NAME OF PARTS	PARTS NO.	MATERIAL	WEIGHT \hat{c}	QTY.
APPROV	LIST NO. S10071	GROUP 7			
ED BY T. Okanda	BEFORE	SCALE 1:2			
CHECKED BY M. Kaibara	AFTER				
ED BY	REF.				
DRAWN BY Junya Chijiwa	DAIHATSU DIESEL MFG. CO., LTD.				
DATE OCT. 14, 1997	OSAKA JAPAN				
		TYPE ISA			
		NAME 3 PORT COOLING WATER VALVE-T			
		(Tar epoxy double coating)			
		PARTS NO. S11010711-983Z			
		DRG. NO. 807753			

DRG. NO. 807753 E



t = 3 mm

MATERIAL : SUS304

NO.	ORIFICE TYPE	A	B	C	D	d	h	Purpose
1	ORIFICE 15A-5	40	54	60	80	5	12	for cooling fresh water expansion line
2	ORIFICE 15A-10	40	54	60	80	10	12	for warming line
3	ORIFICE 80A-20	90	125	145	180	20	19	for cooling fresh water outlet
4	ORIFICE 80A-30	90	125	145	180	30	19	for cooling fresh water outlet
5	ORIFICE 80A-40	90	125	145	180	40	19	for auto cooling water valve by-pass

ADD DIMENSION FOR 15A-5, 15A-10, 80A-20, 80A-30

06. APR. 2005 K.S

APPROVED	<i>[Signature]</i>	LIST NO. ADK20-3987-9 (10) #003	MATERIAL APRV	GROUP	SCALE= -:-
CHECKED		BEFORE	MASS.	QTY.	<input checked="" type="checkbox"/> 3 A4
		REF.	TYPE	ALL	
DRAWN	<i>N. Tokunaga</i>	DAIHATSU DIESEL MFG. CO., LTD. OSAKA JAPAN	NAME オリフィス		
DATE	11. DEC. 2004		ORIFICE		
			PARTS NO. Q399333950	A	A
			DWG. NO. Q399333950AA		



1

2

3

HISTORY OF DWG. DATE

SPECIFICATION	
PLUNGER DIA.	φ16
CAPACITY	2500mm ³ /st
TANK CAPACITY	1000 cc
PRESS. GAUGE	1/2X100X50MPa





ATTACHED TO THE HULL

NO.	NAME OF PARTS		PARTS NO.	MATERIAL	MASS. (g)	QTY.
APPROVED BY	<i>A. Takano</i>	LIST NO.	ADK20-1394-6 (10) #020	GROUP		
CHECKED BY	<i>O. Kumabe</i>	BEFORE		SCALE	1/5	TYPE DK-20
DRAWN BY	M. OHMURO	AFTER		REF.	481546D	NAME NOZZLE TEST PUMP ASSY. G
DATE	MAY 29. '98					PARTS NO.
						DWG NO. AQA10003156 A




E
D
C
B
A

1 2 3 4 5 6 7




Detail of T/C cleaning nozzle "A"

Note) keep the needle of T/C cleaning nozzle tightly closed not in use.





Detail of "C"

Note) Keep the valve tightly closed not in use.



Detail of "B" (SHIPYARD SUPPLY)

(when rubber hose is connected.)



※ Gauge board hose connections(3PCS) and detachable rubber hose(2m) are supplied for tool by DAIHATSU. 1 Set / Ship

△	FIRST DRAWING	2006/09/29	K. S
本図はダイハツディーゼル株式会社の所有物です。This drawing is the property of Daihatsu Diesel Mfg.Co.,Ltd. Reproduction,use or disclosure 許可無く複写、転載及び第三者への開示を禁止します。 to third parties without express authority of Daihatsu is strictly forbidden.			

APPROVED	ISE WAKISHI	LIST NO.	MATERIAL	APRV	GROUP	O	SCALE= * : *
CHECKED		BEFORE	Q990307160BB	MASS.	***	A	QTY. ***
		REF.	-	TYPE	ALL		
	TERAUCHI YOICHI	DAIHATSU DIESEL MFG. CO., LTD.		NAME			
	SHIMOKAWA KEISUKE			クミタテス:タービンセンジョウヨウグ:TPS			
DATE	2006/09/29	OSAKA JAPAN		ASSY.:T/C CLEANING FITTING:TPS			
				PARTS NO.	AQA10003161	A	*

E
D
C
B
A

ABS-RULE

*
*
* CALCULATION SHEETS *
*
* OF *
* TORSIONAL VIBRATION *
*
*

SASEBO HEAVY INDUSTRIES CO., LTD.

DAIHATSU DIESEL MFG. CO., LTD.

TECHNICAL DEPARTMENT

MORIYAMA, JAPAN

SHIP NO.	761/762	DRAWN BY	<i>S. Tanaka</i>
TYPE	6DK-20	CHECKED BY	<i>R. Sumino</i>
LIST NO.	QE 5 1 3 2 5 8 8 0 F Z		
DATE	DEC. -14, 2006	APPROVED BY	<i>N. Kinoshita</i>
REVISION			

3
5
3

¥1. SPECIFICATIONS

(1) DIESEL ENGINE

TYPE VERTICAL 4-CYCLE, SINGLE-ACTING,
SOLID AND DIRECT INJECTION WITH
TURBO CHARGER AND INTER COOLER.

NO. OF CYLINDER 6

BORE AND STROKE 200mm X 300mm

RATED SPEED 900 min-1

NORMAL OUTPUT 760kW

OSCILLATING MASS FOR PISTON AND
CONNECTING ROD 41.2 kg

FIRING ORDER 1- 5- 3- 6- 2- 4

MANUFACTURE DAIHATSU DIESEL MFG. CO., LTD.

(2) A. C GENERATOR

TYPE NTAKL

NORMAL OUTPUT 875.0kVA

MANUFACTURE NISHISHIBA ELECTRIC CO., LTD.

(3) MASS NAME OF HOLZER TABLE

MASS NO.	MASS NAME
1.....	FRONT GEAR
2- 7.....	CRANK THROW
8.....	FLYWHEEL
9.....	GEN. FAN
10.....	GEN. ROTOR

TABLE 1 HOLZER TABLE AND STRESS, TORQUE

THE 1 NODE VIBRATION

N= 78.09 Hz

MASS NO.	EQ. MASS kgm2	TORS. STIFF. MNm/rad	SHAFT DIA cm	AMP. radian	TORQUE *1E2 Nm	STRESS N/mm2
1	.741	3.515E+01	17.0	1.000	1.785	.185
2	5.618	2.369E+01	17.0	.995	15.244	1.580
3	5.618	2.369E+01	17.0	.931	27.832	2.885
4	5.618	2.369E+01	17.0	.813	38.832	4.025
5	5.618	2.369E+01	17.0	.649	47.613	4.936
6	5.618	2.369E+01	17.0	.448	53.675	5.564
7	5.618	3.027E+01	17.0	.222	56.672	5.875
8	117.647	2.541E+01	19.0	.034	66.389	4.930
9	12.255	3.302E+01	17.8	-.227	59.690	5.390
10	60.784			-.408	0.000	

ORDER NUMBER	ENGINE min-1	VECTOR SUM
5.5	851.9	.528
6.0	780.9	4.057



TABLE 2 HOLZER TABLE AND STRESS, TORQUE



THE 2 NODE VIBRATION

N=102.59 Hz

MASS NO.	EQ. MASS kgm2	TORS. STIFF. MNm/rad	SHAFT DIA cm	AMP. radian	TORQUE *1E2 Nm	STRESS N/mm2
1	.741	3.515E+01	17.0	1.000	3.080	.319
2	5.618	2.369E+01	17.0	.991	26.222	2.718
3	5.618	2.369E+01	17.0	.881	46.779	4.849
4	5.618	2.369E+01	17.0	.683	62.726	6.502
5	5.618	2.369E+01	17.0	.418	72.490	7.515
6	5.618	2.369E+01	17.0	.112	75.110	7.786
7	5.618	3.027E+01	17.0	-.205	70.327	7.290
8	117.647	2.541E+01	19.0	-.437	-143.441	-10.651
9	12.255	3.302E+01	17.8	.127	-136.953	-12.368
10	60.784			.542	-0.000	

ORDER NUMBER	ENGINE min-1	VECTOR SUM
6.5	947.0	.807
7.5	820.7	2.229





**TEST RECORDS OF THE DIESEL ENGINE
AT SHOP TRIAL**
ディーゼル機関試運転成績書

SHIPYARD : MESSRS. Sasebo Heavy Industries Co., Ltd.
 造船所 : Sasebo Shipyard SNO. 762
 ENGINE TYPE :
 機関型式 : 6DK-20
 ENGINE NO. :
 機関番号 : DK620Z1818 , DK620Z1819 , DK620Z1820
 DATE OF MFG. :
 製造年月 : Sep. - 2008

RECORDS OF SHOP TRIAL

記 事

2 - Sep. - 2008
 2 - Sep. - 2008

R U N N I N G T E S T

立 会 運 転 検 査

O V E R H A U L I N S P E C T I O N

立 会 分 解 検 査

WITNESSED BY: *[Signature]*

WITNESSED BY: *[Signature] SSK*

DAIHATSU DIESEL MFG. CO., LTD.
 MORIYAMA FACTORY, SHIGA
 QUALITY CONTROL DEPT.

APPROVED BY: *[Signature]*

APPROVED BY: *[Signature]*

JUDGMENT	<i>Good</i>
判 定	

CHECKED BY: *[Signature]*

SPECIFICATIONS 主要目

DIESEL ENGINE				ディーゼル機関			
Engine model & type	機関仕様、型式	4-cycle diesel engine 立形単動4サイクルディーゼル機関		:	6DK-20		
Engine No.	機関番号	DK620Z1818 , DK620Z1819 , DK620Z1820					
Rated output & speed	定格出力及び回転速度	760 kW	(1034) PS,	900	min ⁻¹		
No of cylinder, Bore & Stroke	シリンダー数、直径、行程	6	、	200 mm、	300 mm		
A. C. GENERATORS				交流発電機			
				[Supply 御支給品]			
Manufacture	製作所	NISHISHIBA ELECTRIC Co.,Ltd				made	
Output, Cycle	出力、周波数	875 KVA	(700) kW、	60	Hz		
Voltage, Current & P.F.	電圧、電流、力率	450 V、	1123 A、	80 %			
ACCESSORY				付属機器			
	Mfg. 製作所	Type 形式	Spec. 仕様	No.1	No.2	No.3	
Turbo-charger 過給機	ABB	TPS48D01	CV10 CT75 CA17 TV01 TT16 TA75	HT490852	HT490853	HT490854	
Air cooler 空気冷却器	DDK	DH-39-1	—————	39140	39141	39142	
Governor 调速機	BOSCH	RHD6-MC	Design No.	105856-5580			
			Serial No.	88742162	88742163	88742172	
SURVEYOR'S MARK				規 格			
	No.1 Eng.	No.2 Eng.	No.3 Eng.				
Diesel engine ディーゼル機関	 ABPQA	 ABPQA	 ABPQA				
	 NO.DK620Z1818	 NO.DK620Z1819	 NO.DK620Z1820				
	2-9-08	2-9-08	2-9-08				
A.C. Generator 交流発電機	ABS TYPE APPROVAL	ABS TYPE APPROVAL	ABS TYPE APPROVAL				
	KO 1029774	KO 1029774	KO 1029774				
	NO.252171A1A-1	NO.252171A1A-2	NO.252171A1A-3				
	18-JULY-08	18-JULY-08	18-JULY-08				
VALVE ADJUSTMENTS				調整要目表			
Intake valve 吸気弁	Open (before T.D.C) 開 (上死点前)	Degree 度	50	Top clearance ピストン頂隙		10.5	mm
	Close (after B.D.C) 閉 (下死点後)	Degree 度	35	Injection pressure 燃料噴射圧力		29.4	MPa
	Clearance 間隔	mm	0.31			300	kg/cm ²
Exhaust valve 排気弁	Open (before B.D.C) 開 (下死点前)	Degree 度	55	Fuel pump 燃料ポンプ	Type 形式	104257-3032	
	Close (after T.D.C) 閉 (上死点後)	Degree 度	50	Nozzle 噴射弁	Type 形式	DLL140TE3010	
	Clearance 間隔	mm	0.31	Firing order 着火順序	1-5-3-6-2-4		
Beginning of Pumping (before T.D.C) 燃料ポンプ突始め (上死点前)		Degree 度	11.5				
Starting valve 起動弁	Open (before T.D.C) 開 (上死点前)	Degree 度	4	Direction of crank rotation (Viewed from the flywheel) 回転方向 (フライホイール側から見て)			Clock wise 時計方向
	Close (after T.D.C) 閉 (上死点後)	Degree 度	130				

LOAD RUNNING TEST				Date of test :			No.1 ENG.			TYPE : 6DK-20 ENG.NO. : DK620Z1818		
				*1-9-2008 2-9-2008								
Kind of load	%	Standard at 100%	*	*	*		100	100		*		
Time of recording	clock-min	9-00~	25	50	75	9-00~	9-30	10-00	11-00~	11-30		
Running test time	min		20	20	20		30	30		30		
Generator output	kW		175	350	525		700	700		770		
Fuel consumption	** kg/h		48.7	79.5	111.9		144.1	144.1		158.3		
(be based on Gen.output)	** g/kWh		278.0	227.2	213.1		205.8	205.8		205.5		
(be based on Eng.output)	** g/kWh	≤ 197 +5%	255.5	215.8	204.1		197.6	197.6		197.3		
Gen. efficiency at P.F.=1.0			91.9	95.0	95.8		96.0	96.0		96.0		
Fuel pump rack reading			12.0	16.5	20.0		23.5	23.5		25.0		
Cooling water pressure	Jacket	MPa	For reference	0.22	0.22	0.22		0.22	0.22		0.22	
	Cooler	MPa	For reference	0.10	0.10	0.10		0.10	0.10		0.10	
Lub. oil pressure	Bearing	MPa	0.4 ~ 0.55	0.54	0.52	0.51		0.50	0.50		0.50	
	Turbo-charger	MPa	0.2 ~ 0.5	0.49	0.48	0.46		0.46	0.46		0.45	
Boost air pressure	MPa		0.030	0.080	0.140		0.207	0.207		0.230		
Fuel oil pressure	Eng. inlet	MPa	For reference	0.37	0.38	0.34		0.34	0.34		0.34	
Lub. oil temperature	Oil cooler	Outlet	°C	52	54	54		55	55		55	
	Engine	Inlet	°C	66	66	67		67	67		68	
Outlet		°C	69	69	70		70	70		71		
Cooling water temperature	Oil cooler	Inlet	°C	30	31	33		35	36		39	
				Exhaust gas temperature	Cylinderhead outlet	1	°C	290	310	325		340
2	°C	295	315			330		350	355		370	
3	°C	285	310			330		360	365		375	
4	°C	290	315			335		350	355		370	
5	°C	280	310			330		350	355		370	
6	°C	295	315			335		360	365		375	
	Turbo-charger inlet	°C		325	385	420		440	440		465	
Fuel oil temperature	°C	For reference	31	33	34		32	34		36		
Boost air temperature	°C	45 ~ 55	35	39	41		46	47		50		
Maximum combustion pressure	1	MPa	Difference ≤ ±0.3	5.8	8.6	11.4		13.8	13.8		15.1	
				5.9	8.7	11.5		13.8	13.8		15.1	
				5.8	8.6	11.4		13.8	13.8		15.0	
				5.8	8.6	11.4		13.8	13.8		15.0	
				5.9	8.7	11.5		13.8	13.8		15.1	
				5.9	8.7	11.5		14.0	14.0		15.0	
Generator bearing temperature	°C		38	43	46		43	47		49		
Generator Lub. oil pressure	MPa		0.43	0.42	0.41		0.40	0.40		0.40		
Other Data												
Air temp. at Turbo-charger inlet	°C		28	31	32		27	28		33		
Room temperature	°C		29	29	30		28	28		31		
F.O. temp. of F.O.flowmeter inlet	°C		25	25	27		26	26		28		
C.W. temp. of Air cooler inlet	°C		28	28	28		27	27		32		
Humidity	%		72	75	72		78	78		65		
Atmospheric pressure	hPa		998	998	998		993	993		998		

* Inspected by DAIHATSU


**Corrected value with Low heating value 42.7 MJ/kg, Accordance with ISO

Fuel consumption (be based on Eng.output) = Fuel consumption (be based on Gen.output) × Gen. efficiency

TYPE : 6DK-20

No.1 ENG.

ENG.NO. : DK620Z1818


*Crank-shaft Deflection							Date of test ; *27-8-2008	
Cold condition (Standard +3.0 ~ -3.0) (Gen.side ← → Eng.side)							UNIT: 1/100mm	
	1	2	3	4	5	6		
A	0.0	0.0	0.0	0.0	0.0	0.0	View from the fly-wheel 	
B	±0	±0	±0	±0	±0	±0		
C	-1.5	-0.8	0.0	0.0	0.0	0.0		
D	-2.5	-1.5	0.0	0.0	-0.2	-0.2		
E	-1.5	-0.8	-0.2	0.0	-0.2	-0.2		
Hot condition (crank-arm temperature 66 °C)								
	1	2	3	4	5	6		
A	0.0							
B	±0	±0	±0	±0	±0	±0		
C	-4.0							
D	-7.0							
E	-3.0							
*Temperature after continuous operation (°C)							Date of test ; *28-8-2008	
Diesel Engine								
	No.	1	2	3	4	5	6	7
Main bearing		64	67	68	68	67	67	63
Crank pin bearing		64	65	65	65	65	64	-
Lub. oil		64						
*Engine starting test							Date of test ; *29-8-2008	
Air receiver capacity 100 L	Time	Pressure		Time	Pressure		Time	Pressure
	1	2.45		8	1.30		15	
Initial pressure 2.45 MPa	2	2.20		9	1.20		16	
	3	2.00		10	1.10		17	
Room temperature 27 °C	4	1.90		11	1.00		18	
	5	1.70		12	0.93		19	
	6	1.55		13	0.85		Standard [≥6 ≤1.18]	
	7	1.40		14	× 0.70			
Protecting Device test							Date of test ; *28-8/2-9-2008	
Over speed (stop)	(1008~1035) 1025 min ⁻¹	C.W. temp. rise (stop)	(90± ³ / ₂) 90 °C					
L.O. pressure down (stop)	(0.20±0.01) 0.20 MPa	* Level of Leaked oil rise (alarm)	GOOD					
* L.O. pressure down for T/C (alarm)	(0.20±0.01) 0.20 MPa							
*Governor setting Needle : 2 rev. open				Fuel oil ; Exxon mobil oil "A"				
				Density ; *0.8607/0.8628 g/cm ³ at 15°C				
				Low heating value ; *42.61/42.57 MJ/kg				
				Lub. oil ; Exxon mobil motor oil #30				
				Power factor; 100%				
				Drawing ; T.NAKAGAWA				
				Checked ; T.FUJIMOTO				

LOAD RUNNING TEST				Date of test : *1-9-2008 2-9-2008			No.2 ENG.		TYPE : 6DK-20 ENG.NO. : DK620Z1819			
Kind of load	%	Standard at 100%	*	*	*		100	100		*		
Time of recording	clock-min	9-00~	9-20	9-40	10-00	9-00~	9-30	10-00	11-00~	11-30		
Running test time	min		20	20	20		30	30		30		
Generator output	kW		175	350	525		700	700		770		
Fuel consumption	** kg/h		48.5	79.4	111.7		144.8	144.8		158.5		
(be based on Gen.output)	** g/kWh		277.3	226.9	212.8		206.9	206.9		205.8		
(be based on Eng.output)	** g/kWh	≤ 197 +5%	254.8	215.6	203.9		198.6	198.6		197.6		
Gen. efficiency at P.F.=1.0			91.9	95.0	95.8		96.0	96.0		96.0		
Fuel pump rack reading			11.5	16.0	20.0		23.0	23.0		24.5		
Cooling water pressure	Jacket	MPa	For reference	0.20	0.20	0.20		0.20	0.20		0.20	
	Cooler	MPa	For reference	0.10	0.10	0.10		0.11	0.11		0.10	
Lub. oil pressure	Bearing	MPa	0.4 ~ 0.55	0.53	0.52	0.51		0.50	0.50		0.50	
	Turbo-charger	MPa	0.2 ~ 0.5	0.50	0.48	0.47		0.46	0.46		0.46	
Boost air pressure	MPa		0.027	0.080	0.140		0.208	0.208		0.232		
Fuel oil pressure	Eng. inlet	MPa	For reference	0.38	0.40	0.38		0.38	0.38		0.37	
Lub. oil temperature	Oil cooler	Outlet	°C	52	56	56		56	56		56	
Cooling water temperature	Engine	Inlet	°C	69	69	69		68	68		69	
		Outlet	°C	71	72	72		72	72		72	
	Oil cooler	Inlet	°C	29	30	32		34	35		38	
Exhaust gas temperature	Cylinderhead outlet	1	°C	Difference ≤10%	280	305	315		350	350		360
		2	°C		280	315	325		355	355		370
		3	°C		290	320	335		365	370		380
		4	°C		285	315	330		360	360		375
		5	°C		285	320	335		360	365		380
		6	°C		275	310	325		350	355		365
	Turbo-charger inlet	°C	320		390	420		445	445		465	
Fuel oil temperature	°C	For reference	29	30	32		32	33		35		
Boost air temperature	°C	45 ~ 55	32	37	40		46	47		50		
Maximum combustion pressure	1	MPa	Difference ±0.3	5.8	8.6	11.4		13.8	13.8		15.0	
		2		MPa	5.8	8.6	11.4		14.0	14.0		15.0
		3		MPa	5.8	8.6	11.4		14.1	14.1		15.1
		4		MPa	5.9	8.7	11.5		14.1	14.1		15.2
		5		MPa	5.9	8.7	11.5		13.9	13.9		15.0
		6		MPa	5.8	8.6	11.4		13.8	13.8		15.0
Generator bearing temperature	°C		38	45	48		45	48		51		
Generator Lub. oil pressure	MPa		0.44	0.43	0.42		0.42	0.42		0.42		
Other Data												
Air temp. at Turbo-charger inlet	°C		29	30	30		29	30		33		
Room temperature	°C		29	29	30		28	28		31		
F.O. temp. of F.O.flowmeter inlet	°C		25	25	27		26	26		28		
C.W. temp. of Air cooler inlet	°C		28	28	28		27	27		32		
Humidity	%		72	75	72		78	78		65		
Atmospheric pressure	hPa		998	998	998		993	993		998		

* Inspected by DAIHATSU

**Corrected value with Low heating value 42.7 MJ/kg, Accordance with ISO

Fuel consumption (be based on Eng.output) = Fuel consumption (be based on Gen.output) × Gen. efficiency

*Crank-shaft Deflection							Date of test ; *27-8-2008	
Cold condition (Standard +3.0 ~ -3.0) (Gen.side ← → Eng.side)							UNIT: 1/100mm	
	1	2	3	4	5	6		
A	0.0	0.0	0.0	0.0	0.0	0.0	View from the fly-wheel 	
B	±0	±0	±0	±0	±0	±0		
C	-1.5	-0.5	+0.5	+0.5	+0.2	0.0		
D	-2.5	-1.0	0.0	0.0	+0.2	0.0		
E	-1.5	-0.2	0.0	0.0	+0.2	0.0		
Hot condition (crank-arm temperature 68 °C)								
	1	2	3	4	5	6		
A	-0.5							
B	±0	±0	±0	±0	±0	±0		
C	-3.0							
D	-7.0							
E	-3.5							
*Temperature after continuous operation (°C)							Date of test ; *28-8-2008	
Diesel Engine								
	No.	1	2	3	4	5	6	7
Main bearing		64	66	68	68	68	67	64
Crank pin bearing		65	66	67	67	66	66	-
Lub. oil		64						
*Engine starting test							Date of test ; *29-8-2008	
Air receiver capacity 100 L	Time	Pressure		Time	Pressure		Time	Pressure
	1	2.45		8	1.35		15	× 0.70
Initial pressure 2.45 MPa	2	2.20		9	1.25		16	
	3	2.00		10	1.15		17	
Room temperature 27 °C	4	1.80		11	1.05		18	
	5	1.65		12	0.95		19	
	6	1.55		13	0.85		Standard [≥6 ≤1.18]	
	7	1.45		14	0.80			
Protecting Device test							Date of test ; *28-8/2-9-2008	
Over speed (stop)	(1008~1035) 1030 min ⁻¹	C.W. temp. rise (stop)	(90± ³ ₂) 90 °C					
L.O. pressure down (stop)	(0.20±0.01) 0.20 MPa	* Level of Leaked oil rise (alarm)	GOOD					
* L.O. pressure down for T/C (alarm)	(0.20±0.01) 0.20 MPa							
*Governor setting Needle : 2 rev. open				Fuel oil ; Exxon mobil oil "A"				
				Density ; *0.8607/0.8628 g/cm ³ at 15°C				
				Low heating value ; *42.61/42.57 MJ/kg				
				Lub. oil ; Exxon mobil motor oil #30				
				Power factor; 100%				
				Drawing ; E.IWASA				
				Checked ; T.FUJIMOTO				

LOAD RUNNING TEST			Date of test :	*1-9-2008	* * *		* * *		* * *		* * *		
				2-9-2008	No.3 ENG.		TYPE : 6DK-20		ENG.NO. : DK620Z1820				
Kind of load	%	Standard at 100%		*	*	*		100	100		*		
				25	50	75					110		
Time of recording	0'clock-min	9-00~		9-20	9-40	10-00	9-00~	9-30	10-00	11-00~	11-30		
Running test time	min			20	20	20		30	30		30		
Generator output	kW			175	350	525		700	700		770		
Fuel consumption	** kg/h			48.6	79.5	112.0		144.8	144.8		158.7		
(be based on Gen.output)	** g/kWh			277.6	227.2	213.4		206.9	206.9		206.1		
(be based on Eng.output)	** g/kWh	≤ 197 +5%		255.1	215.8	204.4		198.6	198.6		197.9		
Gen. efficiency at P.F.=1.0				91.9	95.0	95.8		96.0	96.0		96.0		
Fuel pump rack reading				11.5	16.0	20.0		23.0	23.0		24.5		
Cooling water pressure	Jacket	MPa	For reference	0.20	0.20	0.20		0.20	0.20		0.20		
	Cooler	MPa	For reference	0.10	0.10	0.10		0.10	0.10		0.10		
Lub. oil pressure	Bearing	MPa	0.4 ~ 0.55	0.54	0.53	0.51		0.50	0.50		0.49		
	Turbo-charger	MPa	0.2 ~ 0.5	0.48	0.46	0.45		0.44	0.44		0.44		
Boost air pressure	MPa			0.030	0.083	0.143		0.205	0.205		0.230		
Fuel oil pressure	Eng. inlet	MPa	For reference	0.36	0.37	0.35		0.33	0.33		0.35		
Lub. oil temperature	Oil cooler	Outlet	°C		52	55	56		57	57		57	
	Cooling water temperature	Engine	Inlet	°C		65	70	70		70	70		70
Outlet			°C		68	72	72		72	72		72	
Exhaust gas temperature	Cylinderhead outlet	1	°C	Difference ≤10%		295	305	320		340	345		355
		2	°C			295	305	320		345	345		355
		3	°C			285	315	335		360	365		375
		4	°C			295	315	335		355	365		375
		5	°C			285	315	335		360	365		375
		6	°C			295	315	335		360	365		375
	Turbo-charger inlet	°C			330	390	420		440	450		460	
Fuel oil temperature	°C	For reference		30	32	32		31	32		34		
Boost air temperature	°C	45 ~ 55		33	38	41		45	46		49		
Maximum combustion pressure	1	MPa	Difference ±0.3		5.9	8.9	11.6		13.8	13.8		15.2	
	2	MPa			5.9	8.7	11.6		14.0	14.0		15.0	
	3	MPa			5.9	8.7	11.6		14.0	14.0		15.0	
	4	MPa			5.9	8.7	11.6		13.9	13.9		15.0	
	5	MPa			5.8	8.6	11.5		14.0	14.0		15.0	
	6	MPa			5.9	8.9	11.6		14.1	14.1		15.0	
Generator bearing temperature	°C			36	45	49		47	49		50		
Generator Lub. oil pressure	MPa			0.42	0.41	0.41		0.40	0.40		0.40		
Other Data													
Air temp. at Turbo-charger inlet	°C			28	28	30		28	31		30		
Room temperature	°C			29	29	30		28	28		31		
F.O. temp. of F.O. flowmeter inlet	°C			25	25	27		26	26		28		
C.W. temp. of Air cooler inlet	°C			28	28	28		27	27		32		
Humidity	%			72	75	72		78	78		65		
Atmospheric pressure	hPa			998	998	998		993	993		998		

* Inspected by DAIHATSU



**Corrected value with Low heating value 42.7 MJ/kg , Accordance with ISO

Fuel consumption (be based on Eng.output) = Fuel consumption (be based on Gen.output) × Gen. efficiency

TYPE : 6DK-20

No.3 ENG.

ENG.NO. : DK620Z1820

*Crank-shaft Deflection							Date of test ; *27-8-2008	
Cold condition (Standard +3.0 ~ -3.0) (Gen.side ← → Eng.side)							UNIT: 1/100mm	
	1	2	3	4	5	6		
A	0.0	0.0	0.0	0.0	0.0	0.0	View from the fly-wheel 	
B	±0	±0	±0	±0	±0	±0		
C	-1.0	-0.5	0.0	-0.2	0.0	0.0		
D	-2.5	-1.0	-0.2	-0.2	0.0	0.0		
E	-1.0	-0.5	+0.2	0.0	0.0	0.0		
Hot condition (crank-arm temperature 66 °C)								
	1	2	3	4	5	6		
A	-0.5							
B	±0							
C	-3.5							
D	-8.0							
E	-4.0							
*Temperature after continuous operation (°C)							Date of test ; *28-8-2008	
Diesel Engine								
	No.	1	2	3	4	5	6	7
Main bearing		65	67	68	68	68	67	64
Crank pin bearing		66	66	66	67	66	66	-
Lub. oil		65						
*Engine starting test							Date of test ; *29-8-2008	
Air receiver capacity	Time	Pressure	Time	Pressure	Time	Pressure		
100 L	1	2.45	8	1.20	15			
Initial pressure	2	2.10	9	1.10	16			
2.45 MPa	3	1.90	10	1.00	17			
Room temperature	4	1.70	11	0.90	18			
27 °C	5	1.60	12	0.80	19			
	6	1.45	13	0.75	Standard [≥6 ≤1.18]			
	7	1.30	14	× 0.60				
Protecting Device test							Date of test ; *28-8/2-9-2008	
Over speed (stop)	(1008~1035) 1025 min ⁻¹	C.W. temp. rise (stop)	(90± ³ / ₂) 90 °C					
L.O. pressure down (stop)	(0.20±0.01) 0.20 MPa	* Level of Leaked oil rise (alarm)	GOOD					
* L.O. pressure down for T/C (alarm)	(0.20±0.01) 0.20 MPa							
*Governor setting Needle : 2 rev. open				Fuel oil ; Exxon mobil oil "A"				
				Density ; *0.8607/0.8628 g/cm ³ at 15°C				
				Low heating value ; *42.61/42.57 MJ/kg				
				Lub. oil ; Exxon mobil motor oil #30				
				Power factor; 100%				
				Drawing ; K.SUGAWARA				
				Checked ; T.FUJIMOTO				

*Load character test 負荷特性試驗													
	Load 負荷	%	100	75	50	25	0	25	50	75	100	110	100
		kW	700	525	350	175	0	175	350	525	700	770	700
No.1 Eng.	Volt. 電圧	V	450	450	450	450	450	450	450	450	450	450	450
	Freq. 周波数	Hz	60.0	60.55	61.1	61.7	62.6	61.7	61.1	60.55	60.0	59.75	60.0
No.2 Eng.	Volt. 電圧	V	450	450	450	450	450	450	450	450	450	450	450
	Freq. 周波数	Hz	60.0	60.55	61.1	61.7	62.6	61.7	61.1	60.55	60.0	59.75	60.0
No.3 Eng.	Volt. 電圧	V	450	450	450	450	450	450	450	450	450	450	450
	Freq. 周波数	Hz	60.0	60.55	61.1	61.7	62.6	61.7	61.1	60.55	60.0	59.75	60.0
*Parallel running test 並列運転試驗 (Standard 規格: Deviation of output 並列偏差 ≤ 15 %)													
	Load 負荷	%	75	100	80	60	40	20	40	60	80	100	75
	Volt. 電圧	V	450	450	450	450	450	450	450	450	450	450	450
	Freq. 周波数	Hz	60.0	59.5	59.9	60.35	60.8	61.3	60.8	60.35	59.9	59.5	60.0
No.1 Eng.	Output 出力	kW	525	700	560	420	280	140	280	420	560	700	525
No.2 Eng.	Output 出力	kW	525	700	560	420	280	145	280	420	560	700	525
No.3 Eng.	Output 出力	kW	525	700	560	420	280	145	285	415	560	700	525
*Governor test 調速機試驗													
		Load 負荷	Description 測定値				Regulation 變動率 (%)		Time 時間				
		%	Rated. 變動前	Inst. 瞬間	Perma. 整定	Inst. 瞬間	Perma. 整定	(sec) (秒)					
No.1 Eng.	Freq. 周波数 (Hz)	100 → 0	60.0	62.8	62.6	4.7	4.3	2.6					
		0 → 50	62.6	59.5	61.1	5.2	2.5	2.9					
		50 → 100	61.1	58.8	60.0	3.8	1.8	3.2					
	Eng. speed 機関速度 (min ⁻¹)	100 → 0	900	945	940	5.0	4.4	-					
		0 → 50	940	905	915	3.9	2.8	-					
		50 → 100	915	890	900	2.8	1.7	-					
No.2 Eng.	Freq. 周波数 (Hz)	100 → 0	60.0	62.8	62.6	4.7	4.3	2.5					
		0 → 50	62.6	59.7	61.1	4.8	2.5	3.1					
		50 → 100	61.1	58.7	60.0	4.0	1.8	3.2					
	Eng. speed 機関速度 (min ⁻¹)	100 → 0	900	945	940	5.0	4.4	-					
		0 → 50	940	905	915	3.9	2.8	-					
		50 → 100	915	890	900	2.8	1.7	-					
No.3 Eng.	Freq. 周波数 (Hz)	100 → 0	60.0	62.85	62.6	4.8	4.3	2.8					
		0 → 50	62.6	59.6	61.1	5.0	2.5	3.2					
		50 → 100	61.1	58.9	60.0	3.7	1.8	3.1					
	Eng. speed 機関速度 (min ⁻¹)	100 → 0	900	945	940	5.0	4.4	-					
		0 → 50	940	905	915	3.9	2.8	-					
		50 → 100	915	885	900	3.3	1.7	-					
Standard 規格	Freq. 周波数	-	-	-	≤ 10	≤ 5							
		*Volt. Changing range 電圧變更範圍	*1Hz changing time 1Hz變更時間		Room temp. *30 °C								
		MAX. 最大	MIN. 最小	UP 上昇	DOWN 下降								
No.1 Eng.		520 V	395 V	8.5 sec	8.5 sec								
No.2 Eng.		520 V	395 V	8.5 sec	8.4 sec								
No.3 Eng.		525 V	395 V	8.5 sec	8.2 sec								
		Date of test ; *28-8-2008											

Speed Switch Unit (-D) MDP-REV-D Instruction Manual

Article

This is prepared for Main Diesel Generator engine from the standard manual Q7LT333430FA.
Output contact of "13" may be used for Low speed detection.

(29 pages including the front page)

DAIHATSU DIESEL MFG. CO., LTD.
TECHNICAL DEPARTMENT
MARINE ENGINE DESIGN

TYPE		Prepared by	K. Tanabe
LIST No.	Q7LT333490FZ		W. Ise
DATE	October 12, 2004	Approved by	W. Ise
REVISION			

	#
--	---

Speed Switch Unit-D Safety Precautions

This manual describes precautions for safety installation and operation of the speed switch unit-D. Operate equipment following these precautions.

Hazards and damage likely to result from incorrect wrong use or, neglecting of the indicated precautions, is explained below in this Manual using the following symbol marks shown below. The symbols:



... **CAUTION** = State likely to cause damage of light or intermediate damage.



1. Caution against electric shock

- (1) Voltage remains in the internal terminal block even after POWER is turned OFF. See page 24(Fig.17).
- (2) When using 100 or 200 VAC for signal output contacts, be aware of possible electrical shock from the terminal block.



2. Caution against current leakage

- (1) To prevent current leakage, be sure to ground equipment properly. See page 24(Fig.17).

-CONTENTS-

1	Overview.....	4
2	Features and functions.....	4
3	Specifications	5
4	Outline.....	6
5	Configuration.....	6
6	Operation and modes.....	7
6.1	Display and operation.....	7
6.2	Actions when the power supply is turned on	8
6.3	Normal state/display (normal mode)	8
6.4	Initial set values.....	9
6.5	Set value display/setting mode and initial set value display/ setting mode.....	10
7	Set value display/setting mode.....	12
7.1	Mode and setting items.....	12
7.2	Start-up interlock contact (#14L).....	13
7.3	Low speed detection contact (#14).....	14
7.4	Low speed detection contact (#13).....	14
7.5	Overspeed detection contact (#12)	14
7.6	Hysterisis (#14, #13, and #12).....	14
8	Initial setting display/setting mode	16
8.1	Mode and setting items.....	16
8.2	Pulse setting/reduction gear ratio set values.....	17
8.3	Full scale set value.....	18
8.4	Contact output mode.....	18
8.5	Analogue output zero/span adjustment.....	19
9	Installation.....	21
10	Wiring	22
10.1	Input/output connector terminal configuration	22
10.2	Wiring installation to I/O connector	23
10.3	External wiring	24
10.4	Connection with the pulse sensor	25
10.5	Connection and branching of analogue output	26
10.6	Precautions in wiring handling.....	27
11	Troubleshooting.....	29
11.1	Troubleshooting table.....	29




Fig. 1 Speed switch unit–D panel display

1 Overview

This product is a revolution detector available with a digital display function. It is a new type of speed switch unit, compact in size and highly functional, that indicates measurements digitally by a micro computer, ensuring high precision, flexible setting that meet a wide range of applications.

2 Features and functions

- High measurement precision by digital measurement (0.05% (at F.S.) \pm 1 digit)
- Revolution speed displayed digitally to a maximum of 4 digits.
- Three-point revolution detection and one-point contact for start-up interlock.
- High resist pressure semiconductor contact output (resist pressure 1500V, AC 100V, 0.1A)
- 4 ~ 20mA analogue output
- Revolution speed frequency output (1 Hz per revolution)
- Input specification and revolution range can be set at any value.
- Detachable terminal block is used.

3 Specifications

Item		
Speed detection	Number of detection points	3 speeds (#12, #13, #14) (#14L: contact for start-up interlock)
	Detection speed range	100 ~ 9990min ⁻¹ (#14L: 1 ~ 999min ⁻¹)
	Measurement precision	0.5min ⁻¹ when it is 1000min ⁻¹ (0.05% (at FS.) ± 1 digit)
	Setting method	Detection point is set by key operation
	Response time	Contact output response 0.3 seconds
	Hysteresis	Standard 3.0% (0.0 ~ 1.0% at F.S. setting changeable)
Display	Display range	0 ~ 9999
	Display	4-digit red digital display (brightness adjustable)
	Display update	Approx. 0.5 sec.
Pulse input	Puls input range	2 ~ 20kHz
	Setting method	Set number of pulses and reduction gear ratio per revolution
	Input pulse	Dedicated pulse sensor (AC 2Vpp ~ 288Vpp (AC 0.7 ~ 100Vrms))
Frequency output (pulse output)	Output signal	1Hz, 0/15V (5k Ω) per revolution Allowable load resistance 5 K Ω or more, non-insulated with the power supply
	Output potential range	1 ~ 9999 Hz (1 ~ 9999min ⁻¹)
	Output error	0.1% (2000Hz or higher)
Analogue	Output signal	Current signal 1 output 4-20mA load resistance 500
	Output precision	± 0.5%(FS)
	Full scale	100 ~ 9990min ⁻¹
Contact output	Output contact	3 contact points (#12: Overspeed, #13 low speed, #14, low speed) 1 contact points (#14L: for start-up interlock)
	Contact feature	set up with Contact output mode (Reference for P18)
	Contact capacity	No-voltage semi-conductor contact point, AC/DC 100V 0.1A, pressure resistance 1500V
Power supply	Voltage	DC24V -25 ~ +30% (18.0V ~ 31.2V)
	Power consumption	2.5W
Environmental conditions	Working temperature	5 ~ 55 ° C (Max. 95% RH, with no dew condensation)
	Storage temperature	-20 ~ 65 (MAX 95%RH, with no dew condensation)
	Ambience	No corrosive gas
	Vibration/impact	5 ~ 13.2Hz: ± 1mm, 13.2 ~ 100Hz:0.7G Impact: max. 10G
Case	Dimension	72 × 36 × 133
	Weight	0.2Kg
	Color	Black

4 Outline




Fig. 2 Outline drawing

5 Configuration




Fig. 3 Internal block diagram

6 Operation and modes

6.1 Display and operation




Fig. 4 Panel display

<Display function>

Digital display: Engine revolution speed is indicated digitally on the 4-digit digital LED display.
Set values, etc. are displayed, during various setting operations.

<LED indicator>

- # 1 2 : Means over-speed detection and indicates that the engine is rotating faster than the rated speed.
- # 1 3 : Means Low-speed detection and indicates that the engine speed has passed over the low-speed set value.
- # 1 4 : Means Low-speed detection and indicates that the engine speed has passed over the low-speed set value.
- # 1 4 L : Indicates that the conditions for start-up interlock have been met. It is applicable in start-up interlock circuits as it can detect complete stop of the engine.

<Input>

[F] Function selection key:

Switch for changing the mode and items. Pressing this key during normal mode changes the mode to setting display/setting mode.

Pressing and holding this key for more than 3 seconds changes the mode to initial setting display/setting mode.

[] [] Data input key:

Allows you to increase and decrease the set value.

[S] Set key:

Starts the setting of items and also enters and saves the set value.

6.2 Actions when the power supply is turned on

When the power supply is turned on, all LEDs turn on for about 1 second and normal mode starts. During the above action, revolution detection, output and error detection functions are suspended whether or not input signal exists.

Note) Before using the speed switch unit for the first time, various settings must be made to enable normal function, as initially set values are only temporary values set for shipment.

Please set each parameter correctly reading this instruction manual to enable correct use of the unit.

The units delivered, as the accessories of diesel engine will be suitably set up.

6.3 Normal state/display (normal mode)

During normal mode, the revolution speed presently detected is displayed. When the revolution speed exceeds the detection set values, the relevant contact output operates and at the same time the relevant LED indicator lights. This mode is displayed except when the setting change mode is selected.

During normal mode, the display brightness setting can be changed by the [▲][▼] data entering keys. (The initial setting value is set at the maximum brightness of 31, and normally it is not particularly necessary to change it.)

The next time the power supply is turned, the brightness is displayed at the value preciously saved.

	Increase the brightness.
	Decrease the brightness
S	Pressing this button for more than 3 seconds saves the present brightness.

6.4 Initial set values

Note) To use this product, it is necessary to pre-set various set values correctly.
Using this unit without setting these values may cause critical problem in engine operation and control.

For the initial set values the following values are entered before shipment.

To encourage setting by the users, the values set in the initial setting are normally impractical values.

Refer to the table below and set items that have no mark attached.


The units delivered, as the accessories of diesel engine will be suitably set up.

marked items can be used without changing the initial set value.

Section	Set Items	Settable range	Initial Set Value	Set Value
8 . 2	Number of gear teeth	1 ~ 300	1	
8 . 2	Reduction gear ratio	1 ~ 20	2	
8 . 3	Analogue value full scale	10 ~ 999	10	
8 . 4	Output mode	0 ~ 15	0	
7 . 2	#14L	ON revolution speed	1 ~ 999	1
7 . 2		OFF revolution speed	1 ~ 999	1
7 . 2		Off delay timer	0 ~ 300	0
7 . 3	#14 ON (OFF) revolution speed	100 ~ 9999	100	300
7 . 4	#13 OFF (ON) revolution speed	100 ~ 9999	100	300
7 . 5	#12 ON (OFF) revolution speed	100 ~ 9999	100	
7 . 6	#14, 13, 12 contact hysteresis	0 ~ 10.0	3	
8 . 5	Analogue output zero setting	-9.9 ~ 0 ~ 9.9	0	
8 . 5	Analogue output span setting	-9.9 ~ 0 ~ 9.9	0	
6 . 3	Display LED, brightness adjustment	1 ~ 31	31	

marked items basically require no change

6.5 Set value display/setting mode and initial set value display/ setting mode



[F] : Press the “[F]Function selection key” once.

[S] : Press the “[S]set key” once.

[F]3sec : Press and hold (3seconds) the “[F]Function selection key” .

[S]3sec : Press and hold (3seconds) the “[S]set key”.

Fig. 5 Setting procedure list

To change the set values, it is necessary to perform setting change work using the “Set value display/setting mode” and “Initial setting value display/setting mode”.

“Set value display/setting mode”:

A mode for setting mainly items concerning speed detection.

“Initial setting value display/setting mode”:

A mode for setting constants that should be pre-set such as number of gear teeth and full scale value, etc.

To change from the “Normal mode” to “Set value display/setting mode” or “Initial setting value display/setting mode”, press the “[F] function selection key” at normal mode.

To change to each mode, press the “[F] function selection key” as follows. Please refer to Fig. 5 Setting procedure list.

To change to the “Set value display/setting mode”, press the “[F] function selection key” once.

To change to the “Initial setting value display/setting mode” press and hold (3 seconds) the “[F] function selection key”.

To increase or decrease the set values by pressing the [▲][▼] keys, pressing the key once increases/decreases the value by ± 1 step, but pressing and holding the same key changes the mode to repeat mode and the values can be entered continuously. Keep pressing even further, changes the mode to fast forward and values can be changed in 10-fold, 50-fold steps.

7 Set value display/setting mode

7.1 Mode and setting items

Pressing the “[F] function selection key” from “Normal mode”, changes the mode to “Set value display/setting mode”.

In this mode, each time the “[F] function selection key” is pressed, the table below is displayed sequentially and pressing the “[F] function selection key” once again at the last item, returns the mode to “Normal mode”. (Refer to Fig. 5)

The set value display/setting mode consists of the following setting items.

Setting #14L ON:

Revolution detection for start-up interlock, ON point revolution speed

Setting #14L OFF:

Revolution detection for start-up interlock, OFF point revolution speed

Setting #14L OFF Delay:

Contact start-up interlock, OFF DELAY TIMER (second)

Setting #14 ON:

Low speed detection ON point revolution speed

Setting #13 OFF:

Low speed detection OFF point revolution speed

Setting #12 ON:

Overspeed detection ON point revolution speed

Hysteresis (#14, #13, #12):

ON-OFF width of #14, #13, #12 (% at FS)

Pressing and holding the “[S] set key” during the item display changes the mode to the set value change mode of the applicable item.

When it enters into the set value setting mode, measurement is suspended and external output and external contact point are frozen temporarily.

(When it returns to the normal mode again, it restarts but with a delay of about 1 to 2 seconds)

To add, when no operation is made for 3 minutes when any set value is being displayed or set, it will automatically return to normal mode.

When the brightness degree had been decreased in normal mode, the maximum brightness will be displayed temporarily in set value display mode but will display the original brightness again when returned to normal mode.

7.2 Start-up interlock contact point (#14L)




Fig. 6 14L OFF DELAY TIMER contact point operation outline

Internal combustion engine employs fly wheel (inertial mass) at the output axis to reduce output fluctuation. Therefore, when the engine is stopped, revolution remains longer than expected due to inertia of fly wheel, and even when the users stop the machine, the output axis may not be stopped completely. When start-up command is given to the engine under such situation, it may trigger unexpected accidents.

Contact for start-up interlock outputs a condition that can block restarting of engine when the output axis is rotating, with the following 3 conditions combined, so as to enable secure detection of engine stop (refer to Fig. 6 “Engine Activation Disabled” part).

- (1) “#14L ON detected revolution speed” as engine operating condition,
- (2) “#14L OFF detected revolution speed” as engine condition immediately before stopping,
- (3) Time counter timer from (2) to complete stop “#14L DELAY TIMER”

For using the start-up interlock contact (#14L), the following 3 values must be set.

#14L ON setting

H = 1 ~ 999

#14L OFF setting

L = 1 ~ “#14 ON set value”

#14L OFF Delay setting

d = 0 ~ 300 sec.

Description:

is an operation point setting for start-up interlock contact and when the engine revolution speed exceeds this set value, #14L contact output operates.

#14L starts the OFF DELAY timer when the engine revolution speed becomes below this set value.

is a set value of #14L OFF DELAY timer and sets the delay time in seconds. #14L contact point output turns off when the time set by this timer is up.

7.3 Low speed detection contact (#14)

To use the low speed detection contact (#14), the following value must be set.

When the engine revolution speed increases above this set value, #14 contact output operates.

#14 ON setting

#14 = 100 ~ 9999

7.4 Low speed detection contact (#13)

To use the low speed detection contact (#13), the following value must be set.

When the engine revolution speed increases above this set value, #13 contact output operates.

#13 OFF setting

#13 = 100 ~ 9999

7.5 Overspeed detection contact point (#12)

To use the overspeed detection contact (#12), the following value must be set.

When the engine revolution speed increases above this set value, #12 contact output operates.

#12 ON setting

#12 = 100 ~ 9999

7.6 Hysterisis (#14, #13, and #12)

Hysterisis is provided to secure stability in detection operation even when the revolution speed sways. At the point of time the revolution speed exceeds the set value (detected revolution speed), the contact turns on and at the point of time the revolution speed become less than set value (return revolution speed) for the amount of hysterisis, the contact turns off.




Fig. 7 Hysteresis

Chattering may generally cause relay contact depositing by contacts repeating ON/OFF in a short time.

Detection revolution speeds for #14, #13 and #12 are set individually, but for return revolution speed, this hysteresis value will be applied to all.

Hysteresis (#14, #13, and #12)

0.0 ~ 10.0% (at FS)

3.0% is registered as initial set value.

It is not particularly necessary to change.

Hysteresis means the range between (detection revolution speed) – (return revolution speed), and this value is set by the percentage value of the full scale set value in § 8.3.

[Ex. 4] When it is $F = 150$, $\#12 = 1020$, $H = 3.0$,

(F: analogue full scale set value, #12: overspeed detection set value, H: hysteresis set value)

$$\text{Hysteresis} = 1500 \times 3.0/100 = 45\text{min}^{-1}$$

#12 ON point (detection speed) ----- 1020min^{-1}

#12 OFF point (return speed) ----- 975min^{-1}

8 Initial setting display/setting mode

8.1 Mode and setting items

Pressing and holding (keep pressing for 3 seconds) the “[F] function selection key” from “Normal mode” or “Set value display/setting mode” changes the mode to “Initial setting display/setting mode”.

In this mode, each time the “[F] function selection key” is pressed, the following display will be displayed sequentially and pressing the “[F] function selection key” at the last item returns the mode to normal mode. (Refer to Fig. 5)

Initial set value display/setting mode consists of the following setting items.

Pulse setting:

Pulse number per revolution (number of teeth)

Reduction gear ratio setting:

Reduction gear ratio from the crank shaft

Full scale setting:

Scale range of analogue output

Output mode setting:

N/C, N/O modes of output contacts

Analogue output zero/span adjustment:

For analogue output range adjustment

Pressing and holding the “[S] set key” during display of each item changes the mode to set value changing mode of the relevant item.

When it changes to the initial setting mode, measurement is suspended and external output and external contact points are frozen temporarily.

(When it returns to the normal mode again, it restarts but with a delay of 1 to 2 seconds).

To add, when either of the set value displayed or set is left for 3 minutes without any operation, automatically returns to normal mode.

When the brightness degree had been decreased in normal mode, the maximum brightness will be displayed temporarily in set value display mode but will display the original brightness again when returned to normal mode.

8.2 Pulse setting/reduction gear ratio set values

Engine revolution speed (or revolution speed of rotor) is calculated from the frequency of pulse signal impressed on the sensor input terminal based on the pulse specification set and is displayed.

For the calculation of revolution speed, it is necessary to set the following pulse specifications.

Number of pulses per revolution (number of gear teeth)

$$P = 1 \sim 300$$

Reduction gear ratio

$$r = 1 \sim 20$$

is the number of pulses generated per revolution of the rotation axis (gear) installed with a pulse sensor.

is the reduction gear ratio to set when the engine revolution speed and the rotation axis installed with a pulse sensor are not the same.

For instance, when the revolution of the engine output axis is detected by pulse sensor in the original condition, the reduction gear ratio of becomes $r = 1$.

[Ex. 1] Engine output axis direct measurement: when the number of gear teeth is 142.

$$P = 142, r = 1$$

When the pulse sensor is attached to the gear that interlocks with the cam shaft of 4 cycle engine, r becomes 2. (Cam shaft only rotates 1/2 revolutions per engine revolution, so the reduction gear ratio becomes 2).

[Ex. 2] Cam shaft measurement: number of gear teeth 75

$$P = 75, r = 2$$

Also when the number of pulses per revolution is not an integral number, set a value 10-times and at the same time set a value 10 times large also for .

[Ex. 3] Cam shaft measurement: tacho generator 7.5 pulse

$$P = 75, r = 20$$

(Reference)

The pulse frequency to be impressed is expressed by the following formula.

$$\text{Frequency} = \text{Revolution speed} \times \text{number of pulses} \\ \div \text{reduction gear ratio} \div 60$$

On the contrary, when calculating the revolution speed from the frequency, it is expressed by the following formula.

$$\text{Revolution speed} = \text{Frequency} \times \text{reduction gear ratio} \times 60 \\ \div \text{number of pulses}$$

8.3 Full scale set value

The revolution speed can be output by the analogue signal of DC 4 ~ 20mA.

It is necessary to set the full scale value so it meets the specification of the equipment to which this output is connected.

To add, hysteresis (on-off difference) at the time of speed detection is calculated based on this full scale value.

$$\text{Analogue full scale setting range} \\ F = 1\ 0\ 0 \sim 9\ 9\ 9\ 0\ \text{min}^{-1}$$

The set value is determined by defining the revolution speed necessary at the time of 20mA output to meet the specification of the equipment to be connect to and the value dividing the revolution speed by 10 shall be the set value. 4mA is equivalent to 0 revolution speed.

$$[\text{Ex. 4}] \text{ Full scale} = 2\ 5\ 0\ 0\ \text{min}^{-1} \\ F = 2\ 5\ 0$$

8.4 Contact output mode

Contacts that operate when the contact output and the conditions of (start-up interlock contact (#14), low-speed detection contact (#14), low-speed detection contact (#13) and over-speed detection contact (#12)) are met can be specified whether it should be ON during operation or OFF by the following setting.

$$\text{Output mode setting range} \\ o = 0 \sim 1\ 5$$

Note) As a standard setting, it is set at [0] (all contacts are A contact operation) at the time of shipment from the plant.

This value is expressed by the mode numbers from 0 to 15 and is applied to each contact, #14L, #14, #13 and #12, as follows:

No.	#14L	#14	#13	#12
0	A	A	A	A
1	A	A	A	B
2	A	A	B	A
3	A	A	B	B
4	A	B	A	A
5	A	B	A	B
6	A	B	B	A
7	A	B	B	B
8	B	A	A	A
9	B	A	A	B
10	B	A	B	A
11	B	A	B	B
12	B	B	A	A
13	B	B	A	B
14	B	B	B	A
15	B	B	B	B

A : N/O (On when over the value) mode
B : N/C (Off when over the value) mode

8.5 Analogue output zero/span adjustment

When there is a slight deflection in the analogue output range (4 ~ 20mA), this range can be corrected by the adjustment of zero output (4mA) and full output (20mA).

Note 1)

The speed switch unit has been adjusted at the time of shipment to ensure that correct analogue output can be made.

Normally, it is not necessary to change this setting.

Note 2)

Do not attempt to adjust the deflection in the revolution speed caused by the error in the equipment (for instance tachometer) connected to the analogue output by this function of speed switch unit.

Analogue zero output/full output adjustment setting range
- 9 . 9 ~ 0 . 0 ~ + 9 . 9 % (no correction when it is 0.0%)

When you enter into this mode, “A” is displayed on the leftmost side of the numerical value display and the present output on the right side.(Continuous lighting)

Under this condition the following keys are accepted.

- | |
|----------|
| F |
|----------|

 changes to normal mode
- | |
|----------|
| S |
|----------|

 Pressing and holding this for 3 seconds changes to “Analogue output adjustment”.

[Analogue zero output adjustment]

When you enter into this mode, “b” is displayed on the leftmost side of the numerical value display in continuous display and the present zero correction value on the right side by flashing. The analogue output will be fixed at “4.00mA”.

The correction value is the % value added to the standard state.

Here, with the following keys, fine adjustment of output value (4mA) will be made.

F	Cancels the setting and changes to “full output adjustment”.
	Raises the correction value (output rises at the same time)
	Lowers the correction value (output declines at the same time)
S	Pressing and holding for 3 seconds sets and saves the present indicated value.

To add, the setting range will be $\pm 9.9\%$ and no correction value when it is 0.0%.

[Analogue full output adjustment]

When you enter into this mode, “c” is displayed on the leftmost side of the numerical value display in continuous display and the present zero correction value on the right side by flashing. The analogue output will be fixed at “20.00mA”.

The correction value is the % value added to the standard state.

Here, with the following keys, fine adjustment of output value (20.00mA) will be made.

F	Cancels the setting and changes to “full output adjustment”.
	Raises the correction value (output rises at the same time)
	Lowers the correction value (output declines at the same time)
S	Pressing and holding for 3 seconds sets and saves the present indicated value.

To add, the setting range will be $\pm 9.9\%$ and no correction value when it is 0.0%.

9 Installation




Fig. 8 Speed switch unit-D side face




Fig. 9 Fixture (accessory)




Fig. 10 Panel cut dimension

Cut the panel of the place to install into in the panel cut size (Fig. 10).

Insert speed switch unit-D from the front side of the panel cut hole. (Fig. 11)

After inserting, hook the attached fixture to the fixture installing hook and screw in metal fitting screw with a slotted screwdriver to securely fasten to the panel side. (Fig. 12)




Fig. 11 Installation (insertion)




Fig. 12 Installation (fixing)

When there is vibration on the installation panel face, you can use “bracket: panel installation (NN00262007A)” (option) which can be installed more securely.

When converting the conventional speed switch unit and speed switch unit 2 to speed switch unit-D during maintenance, etc., you can use the speed switch unit-D available with a compatible case attached with a bracket that fit each unit,

10 Wiring

10.1 Input/output connector terminal configuration

Speed switch unit–D has double decked input/output connector on the backside of the main body. The terminal configuration is described on the nameplate seal on the upper side of the main body in the same way as below.

Please refer to the drawing for correct wiring.

The connector configuration and terminals are as described below.




Fig. 13 Terminal configuration

Upper deck terminal			
	FG	Frame ground for the speed switch. Make sure to connect to the ground to prevent noise and the risk of electric	
24Vdc	P	Connect the power supply. Connect + 24V to [P] and 0V to [N]. Power supply specification, power voltage: DC 24V, allowable voltage range: - 20 ~ + 30%, power consumption: 2.5W	
	N		
SENSOR	+	Connect the sensor output. [+] and [-] are DC 24v power supplies. [S] is for the pulse sensor output which is input in pulse.	
	S		
	-		
FREQUENCY OUTPUT	F+	Outputs the pulse of detected revolution speed. (1Hz per rotation) 0/15V, allowable load resistance is 5K or more and non-insulated from the power supply.	
	F-		
ANALOG OUTPUT	M+	Outputs current at 4 20mA by scaling determined by the full scale setting. Load resistance 500 or below.	
	M-		
Lower deck connector			
OUTPUT CONTACT	OVER	12a	Turns on (off) the contact point when it reaches the pre-set speed limit. No-voltage semiconductor contact point, contact point rating: AC/DC 100V 0.1A, resist pressure: 1500V
		12c	
	LOW	13a	Turns off (on) the contact point when it reaches the pre-set low speed. No-voltage semiconductor contact point, contact point rating: AC/DC 100V 0.1A, resist pressure: 1500V
		13c	
	LOW	14a	Turns on (off) the contact point when it reaches the pre-set low speed. No-voltage semiconductor contact point, contact point rating: AC/DC 100V 0.1A, resist pressure: 1500V
		14c	
	LOWLOW	14a	Contact attached with a start-up interlock off-delay timer when the engine stops. No-voltage semiconductor contact point, contact point rating: AC/DC 100V 0.1A, resist pressure: 1500V
		14c	

10.2 Wiring installation to I/O connector



Fig. 14 Connector

Peeling allowance 9mm



Fig. 15 Peeling allowance of wiring

1) Electric wires to connect to the connector must satisfy the following specification.

Recommended: Single wire: ϕ 1.0mm (AWG 18)

Twisted wire: 0.75mm^2 (AWG 20)

Strand diameter: Min. ϕ 0.18mm

Usable electric wire range

Single wire: ϕ 0.4 ~ 1.0mm (AWGF 26 ~ 18)

Twisted wire: $0.3 \sim 0.75\text{mm}^2$ (AWG 22 ~ 20)

Strand diameter: Min. ϕ 0.18mm

2) Secure 9mm for peeling allowance of wiring. Twist it lightly so it will not spread out. Solderless terminal is not necessary.

Electric wire insertion hole

Electric wire insertion/release
operating unit




Fig. 16 Connector ele

3) Insert and release wiring to the connector by pressing the wire insertion/release operation unit located at the side of the wiring insertion hole, with a slotted driver or the like. Insert it fully and release the driver from the electric wire insertion/release operation unit. Wiring is grasped inside the connector and fixed securely.

4) Connector can be inserted, only one line to one pin. Should it become necessary to insert multiple wirings into one pin, a separate terminal block will be necessary to bundle the wiring into one before connecting to the wiring.

5) Connector itself can be removed easily by pulling it out. If it is difficult to install wiring, remove the connector to make installation easier. Also at the time of speed switch unit-D replacement, wirings can be removed in a lump at the connector, and there is no need to remove wirings one by one.

6) After completing installation, be sure to check that the wiring is correct and that no short circuiting has occurred due to spreading of wiring. Also pull the wirings to see that they do not come off.

10.3 External wiring

External wiring example of speed switch unit-D is given below.

1) Standard connection

A combination of one unit of pulse sensor and one unit of speed switch. There are one analogue output system, three contact output systems, frequency (pulse) output and start-up interlock contact output. The contact signal is connected to the engine control panel for control.




Fig. 17 Standard connection with one unit of pulse sensor and one unit of speed switch

2) Driving two units of speed switch

One unit of pulse sensor can drive up to two units of speed switches. By parallel driving, the number of outputs can be expanded to 2-fold. (2 systems of analogue output, 6 systems of contact output). To connect from the first speed switch to the other, do so via separate relay terminal block.




Fig. 18 Parallel driving connection by one unit of pulse sensor and two units of speed switches.

10.4 Connection with the pulse sensor

1) When connecting the pulse sensor NN00006014A (new type) (DC series engine since 2005)




Fig. 19 Pulse sensor NN00006014A

Fig. 20 Pulse sensor speed switch connection diagram

When connecting this pulse sensor to the speed switch unit -D, refer to the connection diagram in Figure 20.

This pulse sensor is provided with a wire breaking detection function for coil and the red LED at the upper part of pulse sensor turns on when the coil wire breaks, to display the state of wire breakage and at the same time to output it outside. When using the coil breakage detection, prepare a separate relay as in the drawing above and connect it.

For the relay to be used in wire breaking detection, select the one with a coil rated current 30mA or below during operation.(Omron: MY 4-D equivalent)

This pulse sensor is compatible with the (2) pulse sensor (conventional type) in terms of the dimension at the installation section and electrically, it is possible to use it as an alternative model.

2) When connecting pulse sensor 50A, 100, 200 (L51131) (conventional type) (Except for the above)




Fig. 21 Pulse sensor (L51131)




Fig. 22 Pulse sensor (conventional)
- speed switch connection diagram

When connecting this pulse sensor to the speed switch unit-D, refer to the connection diagram in Figure 22.

This pulse sensor has no display/output function for coil breaking detection.

10.5 Connection and branching of analogue output




Fig. 23 Analogue output connection (one system)

The speed switch unit -D has one output of analogue output signal (4-20mA signal) that outputs the rotational speed. For the connection diagram, refer to Figure 23. The allowable load resistance of connecting instrument is 500Ω maximum.




Fig. 24 Analogue output connection (two systems) part 1




Fig. 25 Analogue output connection (two systems) part 2

When outputs of two systems are necessary for sending signals to the meter and data logger, connect the instrument in serial referring to Figure 24 and 25.

However, in the following cases, use an isolator and divide the analogue signal into two.

When load resistance is set to over 500 Ω in total.

When floating of the input signal is not carried out in either instrument.

Note)

When connecting to an instrument with a load resistance exceeding 500 Ω , nonconformity may occur such as discrepancy between the actual revolution speed and the revolution speed indicated on the instrument.

When negative terminal sides of two units of connecting instruments are grounded, current wraparound occurs through grounding and as a result, the input of equipment on the downstream side bypasses, causing disability in signal input to this instrument.

These incidents can be avoided by inserting an isolator and insulating the signal by direct current. For the isolator, select the insulator type with two-outputs (M system: W2YV-AAA-R2 equivalent).




Fig. 26 Analogue output connection
(isolator used for dividing into 2)

10.6 Precautions in wiring handling

1) Wiring and shield handling

Wiring to the speed switch unit must be installed taking note of the following points.

For power supply wirings, pair negative and positive wirings and twist them together.

For the pulse sensor wiring, use three-wire shield wire.

For analogue output, use two-wire shield wire.

For frequency output, use two-wire shield wire.

Use the shield wire on the basis of single-point grounding. Make sure to connect grounding.

Keep wirings connected to the speed switch unit away from the power line and large size relays.

2) Twisted pair wiring

Twisted pair wiring means twisting 2 wirings. This is generally done on electric wires to improve the resistance to noise easily and reduce the effect of electromagnetic induction to the outside.



Fig. 27 Twisted pair wiring



Fig. 28 Normal parallel wiring

3) Grounding of shield wire (single-point grounding)

Grounding of three-core shield wire between pulse sensor speed switch units.




Fig. 29 Shield wire grounding (single-point grounding)

Single-point grounding is an effective connecting method for strengthening the noise resistance of wiring, using the weak signal and pulse, by grounding the shield wire at only single point as shown in the above diagram.




If the sensor side is also connected to the ground, two sides, the sensor side and speed switch side would be grounded. This would cause potential difference between the two points that would provide a good condition for the noise to adhere, it is normally not done.

But if neither grounding is available, there would be no place for noise ingredient to escape to when external noise ingredient adheres to the shield wire, making it possible for the noise to adhere to the signal line, which otherwise should be protected, impeding the effective use of shield wire.

The shield wire must be connected based on single-point grounding.

11 Troubleshooting

11.1 Troubleshooting table

	Phenomenon	Cause	Countermeasure
1	Display/LED does not light	The power is not supplied	Turn on the power supply
		Power supply mis-wired.	Redo wiring work.
		Mis-wired to pulse sensor	Redo wiring work.
2	Contact signal does not output	Wrong set value	Redo the setting work.
	The meter does not work	Wrong wiring	Redo wiring work.
		Pulse sensor attaching gap inappropriate	Fix within the range of 1 to 2 turn return from the rotor. It can be checked if it is detected during operation of pulse sensor by the green LED. 
		This unit or pulse sensor failure	Check if either the unit or sensor is defective and replace with a new one if any defect is found.
3	Meter indication swings during constant rotation. Contact output turns off sometimes.	Pulse sensor attaching gap inappropriate	Fix within the range of 1 to 2 turn return from the rotor. It can be checked if it is detected during operation of pulse sensor by the green LED. 
		Looseness in pulse sensor lock nut	Retighten
		Pulse sensor failure	Replace the pulse sensor with a new one.
		Noise influence	Contact the person in charge of engineering
		Looseness, omission of wiring	Redo wiring work.
4	Meter reading differs from the actual measurement	Incorrect speed switch set value	Redo the setting work
	Contact output differs from the revolution speed detected by the contact output.	Analogue adjustment defect (Only for the phenomenon of meter reading being different from the actual measurement)	Make adjustment by analogue setting (Correctable up to $\pm 9.9\%$)
		Pulse sensor attaching gap inappropriate	Fix within the range of 1 to 2 turn return from the rotor. It can be checked if it is detected during operation of pulse sensor by 
		Analogue output load resistance exceeds 500	Lower the load resistance

Operation Manual

TPS 48D01

ABB		ABB Turbo Systems Ltd CH 5401 Baden		
Type	TPS 48D01	HT486842		
n_{Mmax}	1022	t_{Mmax}	650	°C
	1/s	t_{Bmax}	620	
n_{Bmax}	971			
	175 kg	8	50	50
Year	2007	Application according to the Operation Manual		CE
made in Switzerland				

HZTL2410 Japanese

Operating condition and replacement intervals

The operational limits for the turbocharger n_{Bmax} , t_{Bmax} , n_{Mmax} , t_{Mmax} , inspection- and replacement intervals for the components concerned on the rating plate are valid for the operational mode and compressor inlet condition, which has been agreed upon between the engine builder and ABB.



Note: Replacement intervals of components depends on the load profile, turbine inlet temperature, suction air temperature and turbocharger speed. In case the operation conditions differs significantly from what is considered to be normal for the current application, it is recommended to contact ABB for a re-calculation of replacement intervals. Frequent load alterations, high temperatures and high speed lower the life of components.
Unless otherwise agreed, the application limits n_{Mmax} , t_{Mmax} are valid for the test operation for a limited time.

We herewith confirm that this Operation Manual has been drawn up orientated towards the Product Liability Law 1/1/90 as well as to the „European Machinery Directives“.

We reserve all rights in this document and in the information contained herein.
Reproduction, use or disclosure to third parties without express authority by ABB Turbo Systems Ltd is strictly forbidden.

© Copyright by ABB TURBO SYSTEMS Ltd 2004

Design and specifications are subject to change without notice.

Printed on naturally white paper, bleached free from chlorine and environmentally acceptable.

The CD is made of polycarbonate and contains in addition aluminium, lacquer, dye stuffs and materials of the adhesive label. The CD-cover is made of recycled cardboard.

These materials may be disposed with the domestic wastes or at a specialised collecting centre.



Table of Contents

1	Preliminary remarks
1.1	Foreword
1.2	Layout and function
1.3	Correct application
1.4	Essential information
1.5	Abbreviations and symbols
1.6	Turbocharger rating plate
2	Safety
2.1	Basic safety instructions
2.2	General safety instructions
2.3	Special safety instructions
2.4	Safety instructions and hazard protection
3	Commissioning
3.1	Oil supply
3.2	Inspection work
3.3	Putting into operation after out of service period
4	Operation
4.1	Servicing work
4.2	Monitoring
4.3	Surging of turbocharger
4.4	Contact with rotating parts
4.5	Shutting the engine down
5	Maintenance
5.1	Outline of cleaning work
5.2	Cleaning the filter silencer
5.3	Cleaning the compressor during operation
5.4	Cleaning turbine blades and nozzle ring in operation
5.5	Maintenance work

6	Troubleshooting
6.1	Possible remedies for failures
7	Removal and installation
7.1	Turbocharger weights
7.2	Remove the turbocharger
7.3	Installing the turbocharger
8	Disassembly and assembly
8.1	Module weights
8.2	Disassembling and assembling turbocharger (with V-band connection)
8.3	Disassembling and assembling turbocharger (with strap connection)
8.4	Axial and radial clearances
8.5	Table of tightening torques
9	Taking out of operation
9.1	Turbocharger shut down (with V-band connection)
9.2	Turbocharger shut down (with strap connection)
10	Mothballing the turbocharger
10.1	Taking out of operation for up to 12 months
10.2	Taking out of operation for more than 12 months
11	Reserve and spare parts
11.1	Ordering spare parts
11.2	Directory of part numbers
11.3	General view of turbocharger
11.4	General view of cartridge group

1 Preliminary remarks

1.1 Foreword

This operation manual will help you to become familiar with your ABB Turbo Systems Ltd turbocharger and to use it to full effect in its intended application. You will find important instructions as to the safe, correct, and economical operation of the turbocharger.

This operation manual includes helpful information on the following topics:

- Information on the operation of a turbocharger and ways to prolong the turbocharger's service life.
- Early awareness and avoidance of hazards.
- Minimising repair costs and failure times.

This operation manual is a complement to, and an extension of, existing national regulations on accident protection and prevention.



NOTE

At least one operation manual must be available at all times at the site where the turbocharger is used. It is essential that this operation manual is read before beginning work by all persons working with or on the turbocharger. Personnel only working occasionally on the turbocharger (e.g. during installation and maintenance) must also have read and fully understood the operating manual before working on the turbocharger.

The instructions included in this operation manual must be followed under all circumstances.




NOTE

This applies especially to the general and special safety instructions preceding and in the respective chapters. Ignoring hazards and the safety instructions can lead to serious personal injury and damage to equipment.

In the event of doubt, consult the officer for safety and accident protection responsible for your area.

1.2 Layout and function



S_00095

1	Suction branch / Filter silencer	8	Gas outlet flange
2	Compressor casing	9	Nozzle ring
3	Diffuser	10	Turbine casing
4	Bearing casing	11	Turbine-end bearing flange
5	Axial thrust bearing	12	Compressor-end bearing flange
6	Radial plain bearing (only visible turbine-end)	13	Compressor wheel
7	Turbine		

Preliminary remarks

1

Layout and function

1.2

Page 3

Mode of operation

The turbocharger is a turbo-machine and consists of the following main components:

- Turbine
- Compressor

These are both connected with a common shaft.

The exhaust gases from the diesel or gas engine flow through the turbine casing (10) and nozzle ring (9) to the turbine (7).

The turbine (7) uses the energy contained in the exhaust gas to drive the compressor wheel (13), whereby the compressor draws in fresh air, and the compressed air is forced into the cylinders.

The exhaust gases escape through the exhaust pipe which is connected to the gas outlet flange (8).

The air which is necessary for the operation of the diesel or petrol engine and which is compressed in the turbocharger, is drawn through the suction branch or the filter silencer (1) into the compressor wheel (13). It then passes through the diffuser (3) and leaves the turbocharger through the outlet on the compressor casing (2).

The rotor runs in two radial plain bearings (6), which are located in the bearing flanges (11/12) between the compressor and the turbine. The axial thrust bearing (5) is located between the two radial plain bearings.

The bearings are connected to a central lubricating oil feed which is supplied by the oil lubrication circuit of the engine. The oil outlet is always at the lowest point of the bearing casing (4).

1.3 Correct application



NOTE

This turbocharger supplied by ABB Turbo Systems has been developed exclusively for use on diesel and gas engines to generate the volume of air and the charging pressure necessary for the operation of such engines. Any other usage shall be regarded as a special application which must be discussed with ABB Turbo Systems. The manufacturer accepts no liability for other applications.

The turbocharger has been designed for the diesel or petrol engine described, including speed and output. If it is used otherwise ABB Turbo Systems reserves the right to reject all claims under the warranty.

This turbocharger was built in accordance with state of the art technology and is operationally safe according to prevailing safety regulations.



NOTE

The turbocharger may be hazardous to life and limb of the user or third parties. In addition, improper use may cause damage to the machine.

The machine may only be operated by trained personnel.

Correct use of the turbocharger also includes observation of the assembly, disassembly, operating, maintenance and repair conditions specified by the manufacturer. Regulations set out by local authorities must be observed when disposing of the turbine.

The turbocharger should only be operated and used in a technically perfect condition, for its intended purpose and in compliance with the operation manual.

► Defects which could affect safety must be eliminated immediately.

The manufacturer shall not accept liability for damages resulting from unauthorised alterations to the turbocharger.

1.4 Essential information

Organizational measures

In addition to this manual, the general, statutory regulations applicable in the respective country for the prevention of accidents and the protection of the environment must be observed.

This also applies to the provision and wearing of personnel protection equipment.



NOTE

The safety and risk consciousness of the personnel working on and with the turbocharger must be checked regularly with reference to this manual.

- ▶ The turbocharger must be shut down immediately in the event of alterations affecting safety or of corresponding operating behaviour. The fault should be reported to the person or department responsible.



NOTE

Additions to, and alterations and conversions of the turbocharger that could compromise safety require the prior approval of ABB Turbo Systems.

Original parts and safety

Original parts and accessories are especially designed for the turbocharger supplied by ABB Turbo Systems Ltd .



NOTE

We herewith expressly state that parts and accessories not supplied by us have also not been tested and approved by us.



WARNING

If components and assemblies not manufactured and tested by ABB Turbo Systems are used, this may have a negative effect on the technical design specifications of the turbocharger.

Moreover, the active and/or passive safety of the turbocharger may be compromised by the use of non-original parts. Note that such improper use may endanger personnel and the machine.

ABB Turbo Systems shall not be liable for any damage caused by using non-original parts and accessories.

Qualification of personnel

The turbocharger must only be operated and maintained by trained and authorised personnel.



CAUTION

Work on mechanical components, such as bearings or rotors, must only be performed by qualified fitters from an official service station of ABB Turbo Systems Ltd !

It must be ensured that only authorised personnel work on the turbocharger.

After-sales service

The Contact Information brochure contains an overview of official ABB Turbo Systems Ltd service stations worldwide.

Design variants

This instruction manual is valid for various turbocharger design variants.

This means that some sections and component descriptions in this operating manual do not apply to your turbocharger.

Our service stations and agencies will gladly answer your questions relating specifically to your model.

Storage of new turbochargers

New turbochargers supplied by ABB Turbo Systems Ltd can be stored without additional safeguarding measures for a period of 6 months after the delivery date.

Ensure that the area where the turbocharger is to be stored is dry with humidity of 40-70% and free of condensation.

- ▶ After 6 months, rust-proofing oil should be sprayed on exposed surfaces and all accessible areas of the turbocharger.
- ▶ To do this, the insulating materials must be removed.



NOTE

Repeat the steps described for rust-proofing your turbocharger every 6 months.

1.5 Abbreviations and symbols

The following abbreviations are used in this document:

▷ Prerequisite


▶ Work step

⇒ Result

✓ Positive checkpoint (activity which must be performed without fail)

✗ Negative Checkpoint (activity which may not be performed under any circumstances)

1.6 Turbocharger rating plate



L_00012

Operational limits

- 1 Turbocharger operational limits at engine overload (110%). In test rig operation only, unless otherwise agreed with the engine manufacturer.
- 2 Turbocharger operational limits in service.

Inspection and exchange intervals for turbocharger components

- 3 Inspection interval for plain bearings in 1000 h
- 4 Exchange interval for the compressor in 1000 h (no values 100,000 h)
- 5 Exchange interval for the turbine in 1000 h (no values 100,000 h)

Preliminary remarks	1
---------------------	---

Turbocharger rating plate	1.6	Page 10
---------------------------	-----	---------

Additional specifications:

- 6 Customer part number
- 7 Field for special design designation
- 8 Weight of the turbocharger in kg
- 9 CE = Conformité Européenne
- 10 Turbocharger type
- 11 Series number
- 12 Year of construction of the turbucharger

Explanations of the rating plate

The conditions agreed with the engine manufacturer apply to the values indicated on the rating plate with regard to operational limits, inspection intervals and replacement intervals.



Continuous running above the indicated values n_{Bmax} , t_{Bmax} can considerably reduce the recommended exchange intervals. In such cases, you should contact the nearest official service station of ABB Turbo Systems Ltd.

n_{Mmax} , t_{Mmax} normally apply only when running at overload (110%) during trials on the engine test bed. These limits may also be permitted in service for special applications. The operation over n_{Mmax} , t_{Mmax} is not permitted.

Non-compliance with the recommended exchange intervals may increase the risk of unpredictable component failure.

The inspection intervals and replacement intervals for the turbocharger components specified must be observed without fail!

Turbocharger components whose permissible operating times have expired may not be used again under any circumstances!

2 Safety

2.1 Basic safety instructions

The following symbols and terms are used for the safety instructions in this operation manual:



WARNING

Serious injury or fatal accident may result if the working and operation instructions marked with this symbol are not, or only partly observed.

Warning signs must be strictly observed at all times.



CAUTION

Serious damage to the machine or to other property may result if the working and operation instructions marked with this symbol are not, or only partly, observed.

Caution signs must be strictly observed at all times.

2.2 General safety instructions

The instructions listed here are designed to ensure your safety and to promote safe handling of the turbocharger and its associated operating materials.



WARNING

The following safety instructions must be followed when operating and when working on the turbocharger.

- Do not work on the turbocharger if you are under physical or mental stress.
- Wear protective clothing at all times.
 - Helmet
 - Ear protection
 - Protective glasses
 - Protective suit
 - Oil and petrol resistant gloves
 - Protective shoes
- Attach individual parts and larger component modules carefully to suitable hoists/lifting devices which are in technically perfect condition and which have adequate load-bearing capacity.
- Do not stand under suspended loads.
- If welding work is to be carried out above the turbocharger, the air filter must be covered to prevent damage to the filter mat.
- When working on the turbocharger, be aware of the risk of it falling.
- For overhead assembly work, use the steps and platforms provided for this purpose.

2.3 Special safety instructions

Safety when connecting

- Work only on those connections for which you are qualified.

Safety when commissioning and during operation

- Before starting work, make a visual inspection of the working area.
- Remove obstacles and any objects lying around from the work area.
- Before commissioning check the turbocharger for damage and leaks.
- Refrain from any activity which could compromise safety while working with the turbocharger.
- Inspect the turbocharger after about 12 hours of operation or at least once a day for visible damage and defects.
- Report any damage or changes in operational performance to the person/department responsible immediately.
- In the event of damage, shut down the turbocharger immediately and secure it against inadvertent or unauthorized use.

Safety when cleaning

When handling detergents, solvents, acids and alkalis be sure to observe the respective safety directions on the manufacturers' labels.

Follow directions regarding the environmentally compatible collection, storage and disposal of these liquids.



Explosion hazard

Cleaning work should be carried out outdoors due to explosion hazard. If this is not possible, ensure that there is adequate ventilation and air circulation. Before beginning cleaning work in confined spaces, extinguish naked flames (including cigarettes!) due to the risk of explosion.

- Before cleaning, protect the floor against unintended leaks of oil and operation materials.
- You must wear protective clothing (see section **General safety instructions**).
- Handle operation materials and detergents with utmost caution.
- When handling solvents, wear protective clothing **and** observe the following rules:
 - Avoid skin contact with solvents.
 - Avoid inhaling vapours under all circumstances.
 - Do not allow solvents to soak protective clothing.
- After cleaning, check electric cables for signs of wear or damage.

Safety during disassembly, assembly, maintenance and troubleshooting

- Perform the prescribed adjustment, maintenance and inspection work at the specified intervals.
- Inform operating personnel about special work and repairs before starting.
- Ensure that absorbent materials are available to clean up any operation materials that escape accidentally.
- Ensure safe and environmentally-friendly drainage, collection and disposal of operating and auxiliary materials.
- Before opening a cover or removing a protective component on the turbocharger, the engine must have been switched off and must not be started up again until all parts have been properly re-assembled.



CAUTION

Assembly and disassembly work must only be performed by trained personnel. Work on mechanical components, such as bearings or rotors, must only be performed by qualified fitters from an official service station of ABB Turbo Systems.

Safety when taking out of operation or putting into storage

- Secure the rotor against turning.
- Clean the turbocharger before mothballing.
- Wear protective clothing when mothballing the turbocharger.
- Keep the work area clean and free of oil and operating materials.
- Remove any obstacles lying around on the floor.

2.4 Safety instructions and hazard protection

Associated hazards may arise during operation of and work on the turbo-charger:

- from the turbocharger and its accessories.
- from the operating materials used.
- due to failure to comply with the safety instructions.
- from inadequate performance of maintenance and inspection work.

Mechanical influences

Mechanical influences can cause serious or even fatal injury:

Personal injury

Unconsciousness and injury due to:

- crushing
- shearing
- cutting
- winding
- smashing
- drawing in
- knocking
- stabbing
- rubbing
- escape of liquids under high pressure **and** at high temperature
- slipping
- tripping
- falling

Causes

- sharp edges, pointed parts
- crush, shear and winding areas
- fragmentation / ejection of parts
- fracture or rupture of parts due to overload
- Elastic elements (springs), liquids **and** gases under pressure/in a vacuum
- slippery, oily work area, obstacles on the floor

September 2005

HZTL2410_EN (TPS48-61)

Protective measures

- ✓ Wear leather protective gloves
- ✓ Wear close-fitting protective clothing
- ✓ Tie up long hair and beards (wear hair protection)
- ✓ Wear face and eye protection
- ✓ Wear protective shoes
- ✓ Keep floor, equipment and the turbocharger clean
- ✓ Ensure the availability of oil absorbing materials and have oil collector basins ready or in position
- ✓ Eliminate leaks

Operation and process materials

Operation and process materials refer to **chemical and hazardous substances**:

- Oil
- Grease
- Coolants
- Detergents and solvents
- Acids



CAUTION

Note that operation and process materials are harmful to the environment if they penetrate soil or water.

Personal injury

The following injuries can be caused by operation and process materials:

- Allergies
- Skin disease
- Loss of consciousness
- Poisoning or nausea after inhalation

Causes

- Inhalation of toxic gases, smoke and vapours
- Skin contact with aggressive fluids
- Clothing wet or soaked with hazardous substances
- Spilling and tipping over of vessels containing substances used during operation
- Escape due to leakage
- Tanks and collectors which are not gas-tight and which do not comply with the regulations on hazardous substances
- Burning cigarettes or open flame in the proximity of operation materials

Version 2

Protective measures

- ✓ Utmost caution when handling process and operation materials
- ✓ Protective clothing must be worn
- ✓ Avoid skin contact and inhalation under all circumstances
- ✓ Ensure that the workroom is properly ventilated
- ✓ Observe the hazard indications on the containers for operation and process materials
- ✓ Immediately after use, seal the hazardous substance container tight
- ✓ Used operation materials must be collected safely in accordance with the legal provisions, stored separately in suitable containers as prescribed, and disposed of as special waste in a technically and environmentally compatible manner
- ✓ Ensure that containers for new / used operation materials are sealed tight
- ✓ In the event of leaks or spills immediately apply a suitable absorbent material and dispose of this in a technically and environmentally compatible manner as special waste

Handling insulating materials

- ✓ Ensure that the work area is well ventilated
- ✓ Keep the work area clean
- ✓ Avoid disturbing dust
- ✓ Dust-suppressing tools and processing steps
- ✓ Remove from packaging only in the work area
- ✓ Exercise particular care when removing old insulating materials
- ✓ Dispose of insulating materials in a technically and environmentally compatible manner
- ✓ If large quantities of dust are created, wear protective glasses
- ✓ Use half or quarter masks
- ✓ Wear suitable work clothing and gloves
- ✓ For sensitive skin, apply moisturising, protective barrier cream

Safety	2
--------	---

Safety instructions and hazard protection	2.4	Page 9
---	-----	--------

Noise

The effects of noise above a legally permitted level can cause personal injury.

- Personal injury**
 - Loss of hearing
 - Deafness
 - Impaired hearing
 - Health disorders such as loss of balance or of consciousness
 - Cardiac and circulatory disturbances
- Causes**
 - Machine noise level above 85 dB (A)
- Protective measures**
 - ✓ Wear ear protection

Heat hazard

When the turbocharger is operated, surfaces become very hot.

- Personal injury**
 - Burns
- Causes**
 - Missing or incorrectly fitted insulation.
- Protective measures**
 - ✓ Wear leather protective gloves.

September 2005

HZTL2410_EN (TPS48-61)

Version 2

3 Commissioning

3.1 Oil supply

A carefully designed oil supply, which functions under all operating conditions, is an important precondition for trouble-free operation of the turbocharger.

Lubrication of the turbocharger is normally carried out with oil from the engine oil circuit.

If a separate lubrication system is used, then standby lubrication is also to be provided.



NOTE

The engine manufacturer's recommendations regarding oil selection and oil change intervals are to be observed.

Oil filtration



CAUTION

To prevent dangerous wear to the bearing parts, depending on the turbine specification and bearing used, different-sized impurities must be filtered out of the lubrication oil.

As standard, for the turbocharger an oil filtration of **34 µm** is prescribed. That means, impurities which are larger than **0.034 mm**, must be filtered out of the oil with a filtration efficiency of **> 99%**.

- ▶ If the oil is not sufficiently filtered through the engine filter, an additional filter is to be installed.
- ▶ During a cold start and, if due to deposits of dirt in the additional filter, the flow resistance rises above **0.5 bar**, a bypass must respond, which guarantees the oil supply of the turbocharger by bypassing the filter.
- ▶ Before putting into operation for the first time, check that the oil filters are clean.



NOTE

Also observe the specifications of the engine manufacturer concerning filter fineness and filtration efficiency.

Lubricants




NOTE

All lubricating oils used for engines are permissible.

Oil inlet viscosity and temperature

The oil inlet temperature must not exceed 105°C. The permissible oil inlet viscosities and temperatures are shown in the following diagram.



S_00132

1)	Kinetic viscosity (mm ² /s = cSt)
2)	Oil inlet temperature (°C)
A	Permissible range



NOTE

During engine start, the lower temperature limit may be temporarily undershot.
The oil inlet temperature however should thereby not fall below 10 °C.

Oil pressure

The oil pressure before the bearings must be exactly maintained to ensure fault-free operation.

The oil pressure (overpressure) before the turbocharger with the engine under load should be **2.0 ... 4.5 bar** and at idling speed at least **0.2 bar** .

With cold oil, during the starting phase, temporarily a higher oil pressure of up to **8 bar** is permissible. During pre- and post-lubrication, the oil pressure must not exceed **1.0 bar** .

Pre-lubrication



CAUTION

Before every engine start, actuate pre-lubrication device. The turbocharger must be supplied with oil from the very first moment the engine is started.

3.2 Inspection work

This inspection work includes preventive visual controls, as well as monitoring and measurement to ensure the correct functioning of the turbo-charger. These serve as an aid to detecting anomalies before and during commissioning, thus preventing possible damage to the machine.

- The safety instructions must be followed before and during all inspection work.

3.2.1 Inspection before commissioning

- | | |
|--------------------------------|---|
| Monitoring equipment | ▶ To be checked for correct functioning. |
| Oil filters | ▶ Check cleanliness before commissioning. |
| Manometers on oil lines | ▶ Check oil pressure in oil supply lines. |
| Air filter mat | ▶ Inspect for damage. |



CAUTION

It is urgently recommended that the entire lubrication system is bridged using a bypass pipe, in order to be flushed thoroughly with warm, clean oil before commissioning and after every servicing operation on the lubrication system.

We strongly recommend the use of a starting filter when running the engine in and after every servicing operation on the lubrication system.

Pre-lubrication



CAUTION

Before every engine start, actuate pre-lubrication device. The turbo-charger must be supplied with oil from the very first moment the engine is started.

3.2.2 Inspection after commissioning

- Charger speed** ▶ Measuring (optional, charger speed counter not included as standard with all turbocharger types)
- Charger pressure** ▶ Measuring
- Temperatures** ▶ Measure upstream/downstream from turbine, compressor and oil feed for various engine speeds
- Gas, air, and oil lines** ▶ After the engine has been started up, check all gas, air and oil lines for leaks.



NOTE

Lubricants and pastes used during assembly of the turbocharger are liquefied or vaporised and may escape as an oily liquid or smoke in the first few hours after commissioning. If oily liquid continues to escape after this period, the cause must be treated as an oil leak and located. The first step in this process is to check the oil supply to the turbocharger for leaks. If this is not in order, contact an official ABB Turbo Systems service station.

- ▶ Measure the speed, oil pressure, charging pressure and temperatures before and after the turbine and the compressor at various engine speeds.
- ▶ Compare the measured values with those of the inspection report, taking into account the different operating conditions.

3.2.3 Inspection after 100 service hours

Clean or replace lubricating oil filters after the first 100 service hours.

3.3 Putting into operation after out of service period

- ▶ Inspect the exhaust pipe before and after the turbine for possible combustion residues, foreign bodies or residual water and clean if necessary.
- ▶ Start up the engine end oil circulation system.
- ▶ Inspect air supply lines or filter segments for possible foreign bodies and clean if necessary.

4 Operation

4.1 Servicing work

Servicing work during operation includes visual checks, monitoring and measuring as well as inspection and function checks in order to ensure correct functioning of the turbocharger. It serves as an aid to detecting anomalies during operation, thus preventing damage to the machine. The inspection, measurement and servicing operations listed must be carried out at the intervals indicated.



WARNING

The pertinent safety instructions must be observed during all servicing work.



CAUTION

Servicing work must be carried out at the prescribed intervals in order to avoid damage to and malfunctioning of the turbocharger.

4.1.1 Servicing work every 25 to 50 hours

Operation data

- ▶ must be recorded
- ▶ Enter in the machine logbook
- ▶ In the event of significant anomalies, establish the cause



CAUTION

If you are unable to establish the cause of the anomalies, contact an official ABB Turbo Systems service station.

- ▶ Visual check for air, exhaust gas, water and oil leaks.

4.1.2 Servicing work according to the engine manufacturer's instructions

Oil filters

- ▶ With the engine at standstill clean or replace oil filters

4.1.3 Servicing work every 8,000 -12,000 hours

- ▶ Dismantle the turbocharger
- ▶ Clearance measurement
- ▶ Clean turbine- and compressor casings and check for any cracks and erosion / corrosion.
- ▶ Clean bearing casing, blow through oil ports
- ▶ Clean nozzle ring and check for cracks and erosion
- ▶ Inspection and assessment of the rotor and bearing parts



NOTE

Inspection and assessment of the rotor

The first inspection and assessment of the bearing parts has to be carried out in acc. with the rating plate or between 8,000 and 12,000 service hours.

The inspection and assessment of the rotor and the bearing parts must be carried out by an official service station of ABB Turbo Systems.

4.1.4 Entries in the machine logbook

Monitoring of the machine plant provides information about the performance of the turbocharger.

The following operation data and measurement values must be entered regularly in the engine manufacturer's machine log book:


- Output and speed of the engine
- Air intake temperature
- Exhaust gas temperature before and after the turbine
- Pressure of the charge-air
- Pressure drop in the charge-air cooler
- Lube oil pressure, lube oil temperature

If provided

- Air temperature after compressor and after the charge-air cooler
- Speed of the turbocharger
- Pressure loss in the air filter

4.2 Monitoring

4.2.1 Speed measurement



S_00096

1	Line amplifier	7	Cable plug
2	Installation variants (right or left)	8	Gasket
3	Bearing casing	9	Screw plug
4	Sealing disc with cam or groove	10	Voltage limiting module
5	Speed transmitter	11	Connecting cable
6	Flange plug		

TPS turbochargers can be optionally fitted with a speed transmitter system for measuring the turbocharger speed. This speed transmitter, in connection with the corresponding measuring units or monitoring systems (not part of the delivery), permits continuous remote monitoring of the turbocharger speed. With continuous monitoring of the engine installation, the turbocharger speed can be used as a suitable control parameter.

If required, the line amplifier can be purchased as an optional addition to the described speed measuring system.

A reduction in speed of a charger can signify:

- Damaged rotor components or bearing.
- Defects in the connected pulse charging cylinders.
- Defects or leaks on the exhaust gas pipes or on the charge-air lines.



NOTE

With 4-stroke applications, heavy fouling of the turbine can also be a cause of an increase in the turbocharger speed.

Possible reasons for failure of the speed indicator:

- Defects on the speed transmitting system, on the connecting cable, on the measuring unit or in the power supply. (if applicable on the line amplifier or the line amplifier power supply).
- Turbocharger damage.



CAUTION

If the speed indication fails, it is recommended that the engine output be reduced to idling speed and the engine stopped. The cause of the failure should then be determined.

Installation:

If the speed transmitter system is not assembled on the turbocharger at the time of delivery, it will be in a separate package together with its cable.

To assemble, the transmitter system must be screwed into the left or right threaded hole on the bearing casing, depending on the desired position. The screw plug which is in this threaded hole and its seal must first be removed. It should be noted that the sensor is screwed in completely and to the correct tightening torque without a gasket (see chapter Tightening torques table).

Exchange or subsequent assembly of the speed sensor:**NOTE**

We recommend that subsequent assembly or replacement of the speed transmitter system should be carried out only by an official ABB Turbo Systems service station.

4.3 Surging of turbocharger

Surging of the turbocharger can occur with certain engine operating states, such as rapid load removal or while manoeuvring. The direction of flow in the compressor is then briefly reversed. However, sporadic surging of this kind does not generally affect the safe operation of the turbocharger.



CAUTION

Prolonged or periodic surging

If surging is prolonged or occurs periodically, the following components may be damaged:

- Compressor wheel (vibration fractures, ...)
- Turbine blades (cracks)
- Bearing (overheating)
- Filter silencer

Action to be taken:

The operating safety of the turbocharger is no longer ensured with continuous or periodically recurring surging. The operator must take immediate steps to correct the surging together with the closest official ABB Turbo Systems service station.

The above mentioned components are to be examined for damage by an official service station of ABB Turbo Systems and replaced in cases of doubt.

4.4 Contact with rotating parts

Mild, uniform wear around the circumference of rotor components, caused by slight local grazing against adjacent components, is non-hazardous and permissible. This slightly reduces the length of the blades in the compressor and/or the turbine. Certain tolerances must be observed to avoid significant loss of efficiency.

- ▶ A check on dimensions must be carried out by an official ABB Turbo Systems service station.

4.5 Shutting the engine down



CAUTION

Before shutting the engine down, it must be allowed to idle for a further **5 to 10 Minutes**, so that the circulating oil can dissipate the heat in the turbocharger bearings.

5 Maintenance

5.1 Outline of cleaning work

Cleaning work includes regular visual checks and washing to ensure the correct functioning of the turbocharger and its auxiliary appliances.

- The external condition and the degree of contamination of the cleaning points listed below must be established by visual checks at the intervals indicated.
- The safety instructions must be observed during all cleaning work.

Filter silencer

- ▷ Filter ring must be cleaned wet
- ▶ Dismantle the filter silencer
- ▶ Felt segments in the cover panels are to be cleaned dry


Compressor

- ▷ Wet clean with fresh water in accordance with the engine manufacturer's instructions
- ▶ Engine warm from running
- ▶ High compressor speed

Turbine

- ▷ Wet clean with fresh water in accordance with the engine manufacturer's instructions
- ▶ High engine load
- ▶ Gas inlet temperature before turbine may not exceed 450°C

5.2 Cleaning the filter silencer



S_00116

If provided

The filter ring (81265) can be replaced or cleaned by washing.



NOTE

To ensure perfect operation during washing it is advisable to replace the filter ring with another (filter rings available in packs of two).



CAUTION

Wash or replace the filter ring every 500 service hours. The filter ring is not to be washed more than five times.

September 2005

Washing the filter ring

- ▶ Rinse filter ring with water (up to 40°C) using fine washing powder or, if very dirty, soak it and squeeze out carefully. Rinse in cold water. Avoid high mechanical stress (wringing, strong water jet).

Cleaning the silencer

- ▶ Allow the filter ring to dry completely before assembly.
- ▶ Loosen the tension bands (81270) and withdraw cover grid (81266).
- ▶ Withdraw the cover panels (81137), bend them upwards and remove the felt segments (81136).



CAUTION

During cleaning take care that the felt segments do not get wet!

- ▶ Remove dirt with a cloth, a soft brush or compressed air.
- ▶ Have heavily soiled felt segments replaced by an ABB Turbo Systems service station.



CAUTION

Damaged tension bands must be replaced with new ones.

HZTL2410_EN (TPS48-61)

Version 2

5.3 Cleaning the compressor during operation

The dirt in the compressor stage (compressor wheel and diffuser) depends on the cleanness of the air drawn in and the operating point.

A deposit of dirt in the flow ducts will be formed if the following substances are present in the intake air:

- Oil or saline mist
- Solid combustion residues
- Dust of various kinds

Soiling of the compressor stage has a negative effect on compressor efficiency and charging pressure, particularly for smaller turbochargers.

This results in higher exhaust temperatures and increased fuel consumption by the engine. Contamination of the compressor also increases the rotor unbalance.

Periodic cleaning of the compressor in operation prevents or retards an increase in soiling, but in no way replaces the regular servicing work, during which the turbocharger is completely dismantled.



NOTE

If the coating of dirt is very thick and hard, the compressor can only be cleaned manually when dismantled. This cleaning should be carried out by an official ABB Turbo Systems service station.

Principle of wet cleaning

Water is injected before the compressor wheel via an injection pipe fitted in the filter silencer or the suction branch in order to clean the compressor stage in operation.

The water does not act as a solvent in the process, but the deposit is removed by the mechanical impact of the drops. The process is ideal, provided the soiling is not too advanced.

5.3.1 Wet cleaning of the compressor



NOTE

These guidelines for wet cleaning the compressor apply exclusively for cleaning with water and are subject to the approval of the **engine manufacturer**.



CAUTION

Due to the danger of corrosion, only **fresh water** may be used, and on no account salt water. The water should also not contain any cooling additives or solvents, which could form deposits in the flow ducts.

The injection pipe must on no account be connected directly via a cock to a water pipe or a dosing vessel larger than the one supplied. This prevents uncontrolled volumes of water entering the turbocharger and engine, which can lead to serious damage.

Cleaning interval

The interval between periodic cleanings depends in large measure on the operating conditions. In general, cleaning should be carried out every **24 to 72 operating hours**.

Engine load during wet cleaning

Cleaning of the compressor stage must be performed with the engine warm from running and **as fully loaded** as possible (i.e. at high turbocharger speed).

The success of the cleaning can be seen from the charging or scavenging pressure or also from the exhaust gas temperatures. If cleaning is unsuccessful, it can be repeated up to 2 times.

An unsuccessful cleaning should be repeated after a stabilisation period of 10 minutes at the earliest.



NOTE

If cleaning is still unsuccessful after three attempts, and if the engine operating values are unsatisfactory, we recommend that the turbocharger be checked and cleaned by an official ABB Turbo Systems service station.

After cleaning the compressor stage, the engine must be run under load for at least another **5 minutes**.

Cleaning more than one turbocharger compressor


If several turbochargers are installed on one engine, we recommend cleaning the turbocharger compressors one after the other.

5.3.2 Wet cleaning with external pressurised water container



NOTE

The supply of water from the externally mounted dosing vessel is not suitable for applications where underpressure is not present before the compressor wheel (e.g.: Blower connected upstream of the compressor or high-pressure compressor stage in the case of two-stage charging).



S_00097

X	Screw plugs	D	Compressed air
Y	Valve lever	W	Water
Z	Container		

September 2005

HZTL2410_EN (TPS48-61)

Version 2

Cleaning parameters for each turbocharger compressor

Turbocharger type	Turbocharger speed	Contents of the dosing vessel [dm ³]	Water injection time t ₁ [s]
TPS 48	roughly n _{Bmax}	0.4	10
TPS 52			
TPS 57			
TPS 61			

Operating the pressure water vessel

- ▶ Remove the screw plug (X).
- ▶ Fill the vessel with pure water.
- ▶ Screw the screw plug back in place.
- ▶ Actuate valve lever(Y) against the spring and hold it for **10 to 15 seconds** until all the water has been injected.

September 2005

HZTL2410_EN (TPS48-61)

Version 2

5.4 Cleaning turbine blades and nozzle ring in operation

Combustion of heavy fuel oil in diesel engines causes soiling of the turbine blades and nozzle rings of the turbochargers. Heavy fuel oil of particularly poor quality in combination with a high exhaust gas temperature, as occurs with a 4-stroke engine, can lead to particularly hard deposits, above all on the nozzle ring.

Poor turbine efficiency, increased exhaust gas temperatures, higher charging and ignition pressures and a lower engine output are the result.

Experience in operation shows, that with periodical cleaning during operation, the interval between overhauls can be extended. The wet cleaning of the turbine blades and the nozzle ring described in the following can be applied with 4-stroke applications with heavy fuel oil and gas engines with heavy deposits (e.g. waste dump gas).

For the other applications, in general no turbine cleaning is necessary.



NOTE

Regular cleaning of the turbine during operation prevents or retards a severe increase in soiling.

This cleaning does not replace the normal maintenance work, during which the turbocharger is to be completely dismantled.



NOTE

Very heavily soiled turbochargers are not to be cleaned with this method. In this case, the rotor must be cleaned by an official ABB Turbo Systems service station.

Wet cleaning

Wet cleaning is used for TPS turbochargers.

To clean the turbine components during operation, the thermal shock principle is applied in combination with a subsequent flushing phase. During the cleaning process, the layer of dirt on the material surface of the turbine components loosens.



CAUTION

Only clean fresh water without cleaning agents or solvents may be used for the wet cleaning.



NOTE

The instructions of the engine manufacturer for wet cleaning are to be observed.

To achieve the required thermal shock effect for wet cleaning, the temperature before the turbine T_{T1} must lie between 400°C (673 K) and 450°C (723 K).



CAUTION

For reasons of material strength, during the cleaning process the temperature before the turbine T_{T1} must not exceed 450°C (723 K).

If the exhaust gas temperature can be reduced for wet cleaning, we recommend this should be done as far as possible, to reduce stress on the material, but the exhaust gas temperature must not be reduced below 400°C (673 K).

The prescribed water injection pressure and the duration of water injection must be observed without fail.

Smaller volumes of water can lead to an inadequate cleaning effect. Larger volumes of water lead to impermissible thermal stresses.

Clean fresh water free from cleaning agents and solvents must be used.

Cleaning more than one turbocharger turbine

If on a single engine, more than one turbocharger is mounted feeding into the same air receiver, the turbochargers are to be cleaned one after the other.

The cleaning of all turbochargers at the same time causes a greater drop in performance.

To avoid corrosion on the inner surfaces of the casing, the engine must be run for a further 10 minutes after the wet cleaning operation is completed.

Cleaning interval

The frequency of the cleaning depends on the extent of soiling. As a guidance value, the turbine components are to be cleaned approx. every 200 service hours.

If required, this cleaning interval can be shortened after consultation with ABB Turbo Systems.

Requirement for water supply

During the injection, the absolute static water pressure p_{WT} before the water connection on the turbine casing must be at least 1.5 bar above the absolute turbine inlet pressure ($p_{WT} - p_{Ti} \geq 1.5 \text{ bar}$).

If necessary, the engine load must be lowered during cleaning.

- p_{WT} = absolute static pressure before water connection on turbine casing
- p_{Ti} = absolute static pressure before the turbine



CAUTION

The water supply line to the turbine casing must on no account be connected to a water pipe directly via a cock.

Wet cleaning procedure

Check that the temperature before the turbine T_{Ti} is between 400°C (673 K) and 450°C (723 K). If necessary the engine output is to be adapted.

The engine output must also be lowered if $p_{WT} - p_{Ti} \geq 1.5$ bar.

**NOTE**

If $T_{Ti} = 400^\circ\text{C}$ can not be achieved ($T_{Ti} < 400^\circ\text{C}$), then the temperature should be set as high as possible.

- ▷ Check that the water supply is ensured.
- ▶ Open shut-off valve
- ▶ Inject water with pressure p_{WT} for 15 to 30 seconds
(As standard 15 seconds are recommended. Extend the injection period if cleaning effect with 15 seconds is unsatisfactory and if engine operation permits this.)
- ▶ Reheating phase of the turbocharger components over a time t_h according to the following table „Cleaning parameters“.
- ▶ Repeat the last 2 previous points until water has been injected three times.
- ▶ This completes the turbine cleaning process. The shut-off valve must be closed.

**NOTE**

If an engine is charged by more than one turbocharger, to save time the turbines should be cleaned sequentially. That means, that during the reheating phase of one turbocharger, the water injection can take place at the next one.

Cleaning parameters

Type	Temperature before turbine [°C]	Water Absolute pressure ¹⁾ [bar]	Injection period per injection [s]
TPS 48	400 ... 450	3,5 ... 6,0	15 ... 30
TPS 52	400 ... 450	3,5 ... 6,0	15 ... 30
TPS 57	400 ... 450	3,5 ... 6,0	15 ... 30
TPS 61	400 ... 450	3,5 ... 6,0	15 ... 30

Type	Water volume per injection ²⁾ [l]	Pause between the injections [min]	Number of water injections
TPS 48	1,5 ... 3,5	3	3
TPS 52	2,0 ... 5,0	3	3
TPS 57	3,5 ... 8,0	3	3
TPS 61	5,0 ... 12,0	5	3

- 1) Before the water connection on the turbine casing during cleaning
- 2) Water volume depending on pressure before turbine, water injection pressure and injection period



CAUTION

The specified water volume is per turbocharger.

5.5 Maintenance work

Maintenance work includes inspection and function checks of wearing parts with or without changing process materials, parts or modules. It must be carried out in accordance with the intervals as set out in the Outline of Maintenance work.



CAUTION

Failure to conduct scheduled maintenance work

Failure to carry out the maintenance work at the prescribed intervals can lead to damage and malfunction of the turbocharger. The safety instructions in the respective chapters must be observed for all maintenance work. Keep lubrication and auxiliary materials ready

Overview of maintenance work

- ▶ Completely replace bearings in accordance with the instructions on the rating plate and/or as indicated by the service station or in case of damage.
- ▶ Replace compressor wheel in accordance with the instructions on the rating plate and/or as indicated by the service station or in case of damage.
- ▶ Replace turbine in accordance with the instructions on the rating plate and/or as indicated by the service station or in case of damage.



NOTE

These operations must be carried out by an authorised ABB Turbo Systems service station.

6 Troubleshooting

6.1 Possible remedies for failures

6.1.1 Exhaust temperature too high

Engine output and speed unchanged

- | | |
|--------------------------|---|
| Engine | <ul style="list-style-type: none"> ▷ Malfunction in the injection system ▶ Repair, or contact the manufacturer. |
| Turbocharger | <ul style="list-style-type: none"> ▷ Air starvation, e.g. air filter clogged with dirt ▶ Clean ▷ Compressor / turbine soiled ▶ Clean ▷ Exhaust counterpressure too high ▶ Clean or repair boiler or exhaust silencer ▷ Turbine damaged or worn ▶ Contact an official ABB Turbo Systems service station. |
| Charge-air cooler | <ul style="list-style-type: none"> ▷ Cooler soiled ▶ Clean ▷ Insufficient coolant water quantity ▶ Replenish ▷ Coolant water inlet temperature too hot ▶ Clean/inspect cooling system ▷ Ventilation inadequate ▶ Improve ventilation |

6.1.2 Charge-air pressure too low

Engine output and speed unchanged

Intake condition normal

Engine

- ▷ Air receiver leaking
 - ▶ Repair
- ▷ Gas line between engine and turbine leaking
 - ▶ Repair
- ▷ Injection misadjusted
 - ▶ Correct adjustment
- ▷ Valve control misadjusted
 - ▶ Correct adjustment

Turbocharger

- ▷ Manometer display faulty
 - ▶ Replace manometer
- ▷ Leak in line to the manometer
 - ▶ Repair leak
- ▷ Air filter dirty, causing excessive loss of pressure
 - ▶ Clean
- ▷ Compressor / turbine soiled
 - ▶ Clean
- ▷ Compressor / turbine damaged
 - ▶ Contact an official ABB Turbo Systems service station.
- ▷ Excessive exhaust counterpressure
 - ▶ Clean boiler or exhaust silencer

6.1.3 Charge-air pressure too high

Engine output and speed unchanged

Intake condition normal

Engine

- ▷ Malfunction in the injection system
 - ▶ Correct adjustment
- ▷ Engine output higher than expected
 - ▶ Check engine output
- ▷ Injection misadjusted
 - ▶ Correct adjustment

Turbocharger

- ▷ Manometer display faulty
 - ▶ Replace manometer

6.1.4 Vibrations

Turbocharger

- ▷ Rotor imbalance due to heavy fouling of compressor/turbine
- ▷ Turbine or compressor damaged
- ▷ Bearing defective
 - ▶ Contact an official ABB Turbo Systems service station.

6.1.5 Noises during run-out

Turbocharger

- ▷ Turbocharger dirty
 - ▶ Clean
- ▷ Bearing damaged
- ▷ Rotor grazing
- ▷ Foreign bodies in the turbocharger
 - ▶ Contact an official ABB Turbo Systems service station.

6.1.6 Run-out time too short

Turbocharger

- ▷ Turbocharger dirty
 - ▶ Clean
- ▷ Bearing damaged
- ▷ Rotor grazing
- ▷ Foreign bodies in the turbocharger
 - ▶ Contact an official ABB Turbo Systems service station.

6.1.7 Sluggish start-up

Turbocharger

- ▷ Turbocharger dirty
 - ▶ Clean
- ▷ Bearing damaged
- ▷ Rotor grazing
- ▷ Foreign bodies in the turbocharger
 - ▶ Contact an official ABB Turbo Systems service station.

6.1.8 Lubricating oil pressure too low

Engine

- ▷ Oil filter heavily soiled
 - ▶ Clean
- ▷ Oil pump in the lubricating system defective
 - ▶ Inspect
- ▷ Manometer provides false reading
 - ▶ Replace manometer

Turbocharger

- ▷ Axial clearance of the rotor too big
 - ▶ Contact an official ABB Turbo Systems service station.

6.1.9 Constant surging of the turbocharger

Engine

- ▷ Exhaust pressure to the turbine elevated because boiler or exhaust silencer is dirty
- ▷ Trap dirty
- ▶ Clean

Turbocharger

- ▷ Charge-air cooler or silencer dirty
- ▷ Heavy deposits of contamination in the turbine
- ▶ Clean



NOTE

If it is not possible to determine the reason for the surging, contact an official ABB Turbo Systems service station.

7 Removal and installation

7.1 Turbocharger weights




WARNING

Attach individual parts and larger component modules carefully to suitable hoists/lifting devices which are in technically perfect condition and which have adequate load-bearing capacity.

Turbocharger parts that are not suspended in accordance with the regulations during disassembly and assembly may fall and can cause serious or even fatal injury.

- ▶ Select a suitable rope taking into account the weight of the turbocharger parts.
- ▶ Do not stand under suspended loads.



L_00082



NOTE

To ensure the safety of loads on the crane hook, the ropes must be crossed for suspending. See also the illustration above.

Turbocharger complete without silencer / air suction branch and without gas outlet manifold

Weight [kg]

TPS 48	TPS 52	TPS 57	TPS 61
110	160	260	450

Turbocharger complete without gas outlet manifold and with silencer

Weight [kg]

TPS 48	TPS 52	TPS 57	TPS 61
129	187	300	512

Turbocharger complete without gas outlet manifold and with air suction branch (radial)

Weight [kg]


TPS 48	TPS 52	TPS 57	TPS 61
116	168	271	471

7.2 Remove the turbocharger

- ▶ Disconnect all gas and air lines in accordance with the engine manufacturer's instructions.

If provided


Remove insulation as follows:



S_00098

- ▶ Remove screws and plate (A) of the bearing casing insulation.
- ▶ Remove remaining screws of the bearing casing insulation (B).
- ▶ Withdraw bearing casing insulation upwards. For more simple removal, the bearing casing insulation can be compressed.
- ▶ Unplug cable on the speed measurement (C).
- ▶ Check the lifting equipment.


Turbocharger without gas outlet manifold



S_00099

- ▶ Secure lifting equipment to bearing casing.


Turbocharger with gas outlet manifold without insulation:



S_00100

- ▶ Sling lifting equipment around the gas outlet manifold and secure to the bearing casing.

Turbocharger with gas outlet manifold and with insulation:



S_00101

- ▶ Secure lifting equipment with a ring bolt and nut to the flange of the gas outlet manifold and to the bearing casing.



During removal, a turbocharger that is not lifted in compliance with regulations may fall, and can cause serious or even fatal injury.

- ▶ Select a suitable rope taking into account the weight of the turbocharger.

- ▶ Loosen securing screws (**D**) on the bearing casing.
- ▶ Lift the turbocharger from the engine and place it aside.
- ▶ Cover oil connections.

September 2005

HZTL2410_EN (TPS48-61)

Version 2

7.3 Installing the turbocharger




WARNING

During installation, a turbocharger that is not lifted in compliance with regulations may fall, and can cause serious or even fatal injury.

- ▶ Select a suitable rope taking into account the weight of the turbocharger.

- ▶ Remove covers from the oil connections.
- ▶ Visual inspection of the O-ring gaskets of oil supply- and drain pipe (the engine-end O-ring gaskets are not part of the scope of delivery of ABB Turbo Systems).
- ▶ Check the lifting equipment.

Turbocharger without gas outlet manifold



S_00099


- ▶ Secure lifting equipment to bearing casing

September 2005

HZTL2410_EN (TPS48-61)

Version 2


Turbocharger with gas outlet manifold without insulation:



S_00100

- ▶ Sling lifting equipment around the gas outlet manifold and secure to the bearing casing.

Turbocharger with gas outlet manifold and with insulation:




S_00101

- ▶ Secure lifting equipment with a ring bolt and nut to the flange of the gas outlet manifold and to the bearing casing.
- ▶ Mate turbocharger with the engine.
- ▶ Tighten securing screws (D) on the bearing casing.
- ▶ Plug in cable for the speed measurement (C).

If provided:

Secure insulation as follows:

- ▶ Mate bearing casing insulation.



S_00098

- ▶ Tighten screws of the bearing casing insulation (B).
- ▶ Mate screws and plate (A) of the bearing casing insulation.

- ▶ Secure all gas and air lines in accordance with the engine manufacturer's instructions.

8 Disassembly and assembly

8.1 Module weights




WARNING

Attach individual parts and larger component modules carefully to suitable hoists/lifting devices which are in technically perfect condition and which have adequate load-bearing capacity.

Turbocharger parts that are not suspended in accordance with the regulations during disassembly and assembly may fall and can cause serious or even fatal injury.

- ▶ Select a suitable rope taking into account the weight of the turbocharger parts.
- ▶ Do not stand under suspended loads.




L_00082



NOTE

To ensure the safety of loads on the crane hook, the ropes must be crossed for suspending. See also the illustration above.

Modules



S_00102

A	Strap connection	B	V-band connection
---	------------------	---	-------------------

September 2005

HZTL2410_EN (TPS48-61)

Version 2

Weights [kg]

	Description	TPS 48	TPS 52	TPS 57	TPS 61	
1	Silencer	19	27	40	62	
2	Air suction branch, radial	6	8	11	21	
3	Air suction branch, axial	4	4	6	9	
4	Compressor casing	24	35	51	89	
5	Wall insert	7	10	13	30	
6	Diffuser	2	3	6	10	
7	Cartridge group	32	48	83	136	
8	Nozzle ring	1	2	3	6	
9	Rupture ring	2	3	5	12	
10	Turbine casing with external rupture protection	1 inlet	32	47	77	130
		2 inlets	35	50	86	145
		3 inlets	-	53	96	162
		4 inlets	-	-	93	162
11	Gas outlet flange	4	8	16	30	
12	Gas outlet manifold	18	25	40	56	

September 2005

HZTL2410_EN (TPS48-61)

Version 2

8.2 Disassembling and assembling turbocharger (with V-band connection)



NOTE

Not all tools are identified with a part number. The identification of the tools is ensured with the tools list (included in the toolbox).



WARNING

During removal and assembly, turbocharger components that have not been suspended in compliance with regulations may fall, and can cause serious or even fatal injury.


- ▶ Select a suitable rope taking into account the weight of the turbocharger parts.
- ▶ Do not stand under suspended loads.

Removing compressor casing

- ▶ Disconnect all air ducts in accordance with the engine manufacturer's instructions.

If provided:


- ▶ Remove screws of the compressor casing insulation and dismantle insulation.
- ▶ Loosen V-band (72020) and remove filter silencer or air suction branch.



S_00103

1	Filter silencer	2	Air suction branch
----------	-----------------	----------	--------------------

- ▶ Slightly loosen V-band (72030) and turn compressor casing (72000), until the ring bolt (90230) on the lifting equipment can be secured.
- ▶ Completely loosen V-band (72030) and travel compressor casing (72000) away horizontally with wall insert (77000).
- ▶ Knock wall insert (77000) out of the compressor casing with nylon hammer and remove O-ring gasket (77005).




S_00104



NOTE

If the compressor casing can not be easily released, it can be pushed off against the turbine casing with the press-off tool (90042). For this, the two cover plates (A+B) of the turbine casing insulation must be removed.

If provided



S_00105

**CAUTION****Axial force**

A high axial force can be generated with the press-off tool and with improper handling (pressing off too strongly at one side) the rotor can be damaged.

- ▶ Therefore always engage at both sides alternately and do not press off too much at each side.

Installing compressor casing

- ▶ Install the compressor casing following these instructions in the reverse order.



NOTE

Always replace O-ring gaskets (see section **Spare parts**)

- ▶ Clean V-bands (72020/72030) thoroughly before assembly.
- ▶ Grease V-band thread and inside of the profile with Antiscuff (or similar high-temperature lubricating paste).
- ▶ Check lifting equipment and secure to bearing casing (42001).



CAUTION

Work that exceeds the scope of the description in this chapter must only be performed by a trained fitter from an official ABB Turbo Systems service station.

September 2005


HZTL2410_EN (TPS48-61)

Version 2

Removing cartridge group


If provided

- ▶ Disconnect all lines according to engine manufacturer's specifications, remove insulation, dismantle turbocharger and remove compressor casing as well as filter silencer (see also previous chapter).



S_00105

- ▶ Remove screws on both plates (A+B) of the turbine casing insulation and dismantle the plates.



S_00106

If provided

- ▶ Disconnect plug to speed measuring transmitter (86505).

- ▶ Treat screw thread of the V-band (52410) with rust dissolver and allow to act.
- ▶ Loosen V-band (52410) with hexagon insert (90400) and remove.
- ▶ Loosen fastening screws (C) of the bearing casing (42001) and remove.
- ▶ Carefully withdraw cartridge group and remove gasket (42013).
- ▷ Bearing casing is not easy to remove.
- ▶ Press off bearing casing with press-off tool (90042) against the turbine casing (see following diagram).




CAUTION

Axial force

A high axial force can be generated with the press-off tool and with improper handling (pressing off too strongly at one side) the rotor can be damaged.

- ▶ Therefore always engage at both sides alternately and do not press off too much at each side.

90042




S_00128

- ▶ Cover oil connections.



NOTE

The V-band (52410) is always to be replaced by a new one. (see section **Spare parts**)




S_00107

- ▶ Press off nozzle ring (56001) with the two withdrawal devices (90070) and the service support bracket (90012) and remove.

If provided:

- ▶ Remove lamellar sealing ring (56005).
- ▶ Place cartridge group on the service support (90012) and screw tight.

Diffusor disassembly
TPS...D/E/F33



S_00110

- ▶ Loosen screws (42008), remove diffuser (79000) and O-ring gasket (42012).
- ▶ Measure axial and radial clearances (see section **Axial and Radial Clearances**).

September 2005

HZTL2410_EN (TPS48-61)


Version 2

Installing the cartridge group



NOTE

Always replace O-ring gaskets (see section **Spare parts**)



S_00109

If provided:

- ▶ Fit lamellar sealing ring (56005).



NOTE

Ensure the correct coiling of the lamellar sealing ring (56005).


- ▶ Push in nozzle ring (56001) up to the stop in the turbine casing (51000).
- ▶ Pay attention to the position of the cam.



NOTE

So that the nozzle ring is fixed during operation, it must be clamped between the partition wall and the turbine casing.

- ▶ The pressing (PD) must be calculated.




$PD=A-B$

S_00129




NOTE

If the calculated value is less than 0.1 mm, an official service station of ABB Turbo Systems must be contacted.

*S_00110*

- ▶ Measuring axial and radial clearances (see section Axial and Radial Clearances).
- ▶ Secure diffuser (79000) and O-ring gasket (42012) with screws (42008).
- ▶ Check lifting equipment and secure to bearing casing (42001).
- ▶ Unscrew cartridge group and lift from the service support (90012).



S_00111

- ▶ Grease centering seats, inside of the V-band profile and screw threads with Antiscuff (or similar high-temperature lubricating paste).
- ▶ Remove provisional covers at the oil connections.
- ▶ Assemble cartridge group and gasket (42013) as far as possible by hand.




CAUTION

During assembly of the cartridge group, do not damage or move gasket rings (A) in the securing support. The gasket rings (A) are engine side and are not included in the scope of supply of ABB Turbo Systems.

September 2005

HZTL2410_EN (TPS48-61)

Version 2



S_00112



NOTE

If two turbochargers, each with a left and right oil inlet, are mounted on one engine, as a precaution against mistaken, incorrect assembly, a pin can be fitted in the bracket as assembly security device. This pin (B) fits in the respective groove on the foot of the bearing casing.

- ▶ Fit V-band (52410) and tighten using hexagon insert (90400) to the specified torque. (use torque spanner!).
- ▶ Loosen V-band and remove.
- ▶ Measure the distance between the V-band flanges at several points with a feeler gauge. This distance must not be greater than the calculated value (PD).



CAUTION

Correct positioning of the turbine casing

Operation of the TPS turbocharger with axially incorrect positioned turbine casing leads to damage to the nozzle ring and turbine casing.


- ▶ If the calculated value is not achieved, repeat tightening procedure with V-band (do not tighten V-band with more than the specified torque) or separate casing with press-off tool and start from the beginning.
- ▶ Fit V-band and tighten with the specified torque.



NOTE

An optimal seating of the V-band is achieved through gentle taps on the cover band with a nylon hammer.

- ▶ Retighten V-band with torque spanner (see chapter Tightening torques table).




S_00113

- ▶ Assemble bearing casing (42001) with fixing screws (C).
- ▶ Tighten fixing screws with the torques specified in the following table.

TPS	Fixing screws C [mm]	Tightening torques [Nm]
48	M16	230
52	M20	455
57	M20	455
61	M24	780

► Fit speed sensor (86505).

If provided:



S_00105

► Fit insulation plates (A+B).



CAUTION

Work that exceeds the scope of the description in this chapter must only be performed by a trained fitter from an official ABB Turbo Systems service station.

8.3 Disassembling and assembling turbocharger (with strap connection)



NOTE

Not all tools are identified with a part number. The identification of the tools is ensured with the tools list (included in the toolbox).



WARNING

Attach individual parts and larger component modules carefully to suitable hoists/lifting devices which are in technically perfect condition and which have adequate load-bearing capacity. Turbocharger parts that are not suspended in accordance with the regulations during disassembly and assembly may fall and can cause serious or even fatal injury.

- ▶ Select a suitable rope taking into account the weight of the turbocharger parts.
- ▶ Do not stand under suspended loads.

Removing compressor casing

- ▶ Disconnect all air ducts in accordance with the engine manufacturer's instructions.


If provided

- ▶ Remove screws of the compressor casing insulation and dismantle insulation.
- ▶ Loosen V-band (72020) and remove silencer or air suction branch.

September 2005

HZTL2410_EN (TPS48-61)


Version 2



S_00103


1	Silencer	2	Air suction branch
---	----------	---	--------------------

- ▶ Slightly loosen screws (72011) and turn compressor casing (72000), until the ring bolt (90230) on the lifting equipment can be secured.



S_00114

If provided



S_00105



NOTE

If the compressor casing can not be easily released, it can be pushed off against the turbine casing with the press-off tool (90042). For this, the two cover plates (A+B) of the turbine casing insulation must be removed.

September 2005




Axial force

A high axial force can be generated with the press-off tool and with improper handling (pressing off too strongly at one side) the rotor can be damaged.

- ▶ Therefore always engage at both sides alternately and do not press off too much at each side.

- ▶ Loosen screws (72011) and remove with securing straps (72012).
- ▶ Carefully travel compressor casing (72000) away horizontally with wall insert (77000).

**Diffusor disassembly
TPS..-F31/F32**



S_00115

- ▶ Release screws (72040) and remove from compressor casing (72000) with fixing washers (72041) and diffuser (79000).
- ▶ Knock wall insert (77000) out of the compressor casing with nylon hammer and remove O-ring gasket (77005).

TPS 61

To lift the wall insert (77000) use the ring bolts (90255).

HZTL2410_EN (TPS48-61)

Version 2

Installing compressor casing

Diffusor assembly TPS.. – F31/F32

- ▶ Install wall insert (77000) and O-ring gasket (77005) analogously in the reverse order.
- ▶ Install diffuser analogously in the reverse order.
- ▶ Fit the compressor casing analogously in the reverse order.



NOTE

Always replace O-ring gaskets. (see section **Spare parts**)

- ▶ Thoroughly clean securing straps (72012) and V-band (72020) before assembly. Grease V-band thread and inside of the profile with Antiscuff (or similar high-temperature lubricating paste).



CAUTION


Work that exceeds the scope of the description in this chapter must only be performed by a trained fitter from an official ABB Turbo Systems service station.

Removing cartridge group

- ▶ Check lifting equipment and secure to bearing casing (42001).


If provided

- ▶ Disconnect all lines according to engine manufacturer's specifications, remove insulation, dismantle turbocharger and remove compressor casing as well as filter silencer (see also previous chapter).



S_00105

- ▶ Remove screws on both plates (A+B) of the turbine casing insulation and remove the plates.



S_00117

If provided

- ▶ Disconnect plug to speed measuring transmitter (86505)
- ▶ Treat screw thread of the studs (51006) with creep oil and allow to react.
- ▶ Release nuts (51007) and remove Verbus washers (51003) with securing straps (51002).
- ▶ Loosen fastening screws (C) of the bearing casing (42001) and remove.
- ▶ Remove cartridge group.
- ▷ Bearing casing is not easy to remove.


- ▶ Press off bearing casing with press-off tool (90042) against the turbine casing (see following diagram)



Axial force


A high axial force can be generated with the press-off tool and with improper handling (pressing off too strongly at one side) the rotor can be damaged.

- ▶ Therefore always engage at both sides alternately and do not press off too much at each side.



S_00128

- ▶ Cover oil connections.




S_00107

- ▶ Withdraw nozzle ring (56001) with the two withdrawal devices (90070) and the service support bracket (90012).

If provided

- ▶ Remove lamellar sealing ring (56005).

Diffusor disassembly
TPS.. D/E/F33



S_00110


- ▶ Place cartridge group on the service support (90012) and screw tight.
- ▶ Loosen screw (42008) and remove diffuser (79000) and O-ring gasket (42012).
- ▶ Measure axial and radial clearances (see section **Axial and Radial Clearances**).

Installing the cartridge group



NOTE

Always replace O-ring gaskets (see section **Spare parts**)



S_00109

If provided

- ▶ Fit lamellar sealing ring (56005).



NOTE

Ensure the correct coiling of the lamellar sealing ring (56005).


- ▶ Push in nozzle ring (56001) up to the stop in the turbine casing (51000).
- ▶ Pay attention to the position of the cam.



NOTE

So that the nozzle ring is fixed during operation, it must be clamped between the partition wall and the turbine casing.

- ▶ The pressing (PD) must be calculated.



S_00133




NOTE

If the calculated value (PD) is less than 0.1 mm, an official service station of ABB Turbo Systems must be contacted.

- ▶ Measure axial and radial clearances (see section **Axial and Radial Clearances**).

Diffusor assembly
TPS...D/E/F33



S_00110


- ▶ Secure diffuser (79000) and O-ring gasket (42012) with screw (42008).



NOTE


See section Removing Rotor.

- ▶ Check lifting equipment and secure to bearing casing (42001).
- ▶ Unscrew cartridge group and lift from the service support (90012).
- ▶ Grease centering seats and screw threads with Antiscuff (or similar high-temperature lubricating paste).
- ▶ Remove provisional covers at the oil connections.



S_00134

- ▶ Fit cartridge group as far as possible by hand



S_00118




CAUTION

During assembly of the cartridge group, do not damage or move gasket rings (A) in the securing support. The gasket rings (A) are engine side and are not included in the scope of supply of ABB Turbo Systems.



NOTE

If two turbochargers, each with a left and right oil inlet, are mounted on one engine, as a precaution against mistaken, incorrect assembly, a pin can be fitted in the bracket as assembly security device. This pin (B) fits in the respective groove on the foot of the bearing casing.




S_00113

- ▶ Secure cartridge group with the securing straps (51002), the Verbus washers (51003) and nuts (51007) (see also chapter Tightening torques table).
- ▶ Secure bearing casing (42001) with fixing screws (C).
- ▶ Tighten fixing screws (C) with the tightening torques according to the following table.

TPS	Fixing screws C [mm]	Tightening torques [Nm]
48	M16	230
52	M20	455
57	M20	455
61	M24	780

If provided



S_00105



- ▶ Plug in connector for speed measuring transmitter (86505) and fit the insulation plates (A/B).



CAUTION

Work that exceeds the scope of the description in this chapter must only be performed by a trained fitter from an official ABB Turbo Systems service station.

8.4 Axial and radial clearances



S_00119

- ▶ After removal and before the installation of the cartridge group, the axial clearance A and the radial clearance B are to be measured and noted.



NOTE

To correctly measure the axial clearance A, raise the turbine slightly.

Axial and radial clearance [mm]


	TPS 48	TPS 52	TPS 57	TPS 61
A at least	0.08	0.10	0.12	0.15
A maximum	0.16	0.18	0.21	0.25
B at least	0.50	0.61	0.72	0.81
B maximum	0.99	1.15	1.31	1.55



CAUTION


If the clearances are outside the tolerance, an official ABB Turbo Systems service station must be contacted.

8.5 Table of tightening torques



S_00120

If provided



S_00121

September 2005

HZTL2410_EN (TPS48-61)

Version 2

The tightening torques listed must be observed for the screwed connections listed in the following table.

Tightening torques [Nm]

Part no.	TPS 48	TPS 52	TPS 57	TPS 61
32113	10	10	20	40
32114	10	10	20	40
42002	20	40	65	65
42008	10	10	20	40
51007	25	45	75	75
52410	60 ¹⁾	60 ¹⁾	60 ¹⁾	-
52432	20	40	65	65
72011	35	70	105	105
72020	60	60	60	60
72030	60 ¹⁾	60 ¹⁾	-	-
86505	15	15	15	15

¹⁾ V-band connection only

9 Taking out of operation

9.1 Turbocharger shut down (with V-band connection)

If with a damaged turbocharger, the Diesel engine can only be shut down temporarily for an emergency repair, then the following procedure should be adopted:


- ▶ Fit cover plate.



CAUTION

The instructions of the engine manufacturer for operation of the engine with locked / isolated turbocharger must be followed precisely in all cases!

Fitting the cover plate




S_00122

- ▶ Dismantle turbocharger. (See section **Disassembling and assembling turbocharger with V-band connection**)



NOTE

Do not disassemble nozzle ring.



S_00123

- ▶ Block the opening in the turbine casing with the cover plate (A).
- ▶ Secure cover plate to turbine casing (51000) with V-band (52410) and screw tight on support.



NOTE



Clean V-band (52410) thoroughly with a steel brush before assembly. Grease thread and inside of the profile with Antiscuff (or similar high-temperature lubricating paste).

Cover plate drawing



NOTE

The cover plate (material: general structural steel, in accordance with DIN EN 10025-2) must be produced in-house according to the drawing.



S_00124

Cover plate with V-band connection

TPS	B1 [mm]	B2 [mm]	B3 [mm]	B4 [mm]
48	65.7 ± 0.4	60	19.1 ± 0.1	130
52	79.6 ± 0.4	78	20.1 ± 0.1	155

Taking out of operation	9
-------------------------	---

Turbocharger shut down (with V-band connection)	9.1	Page 4
---	-----	--------

TPS	B5 [mm]	ØD1 [mm]	ØD2 [mm]	ØD3 [mm]	R1 [mm]
48	150	258 ± 0.2	222.7 ± 0.2	17	115
52	180	307 ± 0.2	265.7 ± 0.2	21	135

September 2005

HZTL2410_EN (TPS48-61)

Version 2

9.2 Turbocharger shut down (with strap connection)

If with a damaged turbocharger, the Diesel engine can only be shut down temporarily for an emergency repair, then the following procedure should be adopted:


- ▶ Fit cover plate.



CAUTION

The instructions of the engine manufacturer for operation of the engine with locked / isolated turbocharger must be followed precisely in all cases!

Fitting the cover plate




S_00125

- ▶ Turbocharger disassembly (see section **Disassembling and assembling turbocharger with strap connection**).



NOTE

Do not disassemble nozzle ring.



S_00126

- ▶ Block the opening in the turbine casing with the cover plate (A).
- ▶ Secure cover plate to the turbine casing (51000) with securing straps (51002), Verbus washers (51003) and nuts (51007) and screw tight on support.



NOTE


Clean securing straps (51002) thoroughly before assembly. Grease thread of studs (51006) with Antiscuff (or similar high-temperature lubricating paste).

Cover plate drawing



NOTE

The cover plate (material: general structural steel, in accordance with DIN EN 10025-2) must be produced in-house according to the drawing.



S_00127

Cover plate with strap connection

TPS	B1 [mm]	B2 [mm]	B3 [mm]	B4 [mm]	B5 [mm]
48	65.7 ± 0.5	60	130	11.7 ± 0.2	1.5
52	79.6 ± 0.5	78	155	14.2 ± 0.2	1.5
57	98.2 ± 0.5	100	190	17.2 ± 0.2	2
61	116.8 ± 0.5	120	226	20.5 ± 0.2	2.4

Taking out of operation	9
-------------------------	---

Turbocharger shut down (with strap connection)	9.2	Page 8
--	-----	--------

TPS	B6 [mm]	ØD1 [mm]	ØD2 [mm]	R1 [mm]	M
48	150	222.7 ± 0.2	17	maximum 150	M8
52	180	265.7 ± 0.2	21	maximum 125	M8
57	220	325.7 ± 0.2	21	maximum 153	M10
61	260	387.7 ± 0.2	25	maximum 182	M10

September 2005

HZTL2410_EN (TPS48-61)

Version 2

10 Mothballing the turbocharger

10.1 Taking out of operation for up to 12 months

If a turbocharger has to be laid up for up to 12 months, the decision whether the turbocharger needs special protection or not depends mainly on the condition of the lubricating oil before laying up.

If the Total Acid Number (TAN) is lower than 2 mg KOH/g no special measures need to be taken. However, if the neutralisation factor is higher the turbocharger must be dismantled after laying up, cleaned and protective oil must be applied to the naked parts.

If the turbocharger is left mounted on the engine, and the engine oil is replaced by a protective oil which is circulated with a pre-lubrication pump prior to laying up, no measures need to be taken in respect of the turbocharger. The remains of the old engine oil will be washed away and the sensitive bearing parts will be largely protected against corrosion.

If the rotor turns due to a draught from the flue, fit a blind flange between the compressor casing and the charge-air duct.

10.2 Taking out of operation for more than 12 months

If the turbocharger has to be removed from the engine and stored for a prolonged period of time, disassembly and mothballing of the turbocharger must be done by an official ABB Turbo Systems service station.

Ensure that the area where the turbocharger is to be stored is dry with humidity of 40-70% and free of condensation.



NOTE

Check mothballed turbochargers yearly for corrosion.
In the event of rust, clean and renew the corrosion protection.

11 Reserve and spare parts

11.1 Ordering spare parts

When making inquiries or ordering spare parts, the following data should be specified:

- Turbocharger type
- HT number
- Description and part number

Our service stations and agents accept orders for spare parts.

- ▶ If special variants/cases are not addressed in these general instructions, contact an official ABB Turbo Systems Ltd. service station or an ABB agent.

Spare-parts set



NOTE

Spare-parts set (97070) is required for the work described in this manual. The parts included in the spare-parts set are only available as part of the complete set.

Spare parts set (97070)

Quantity	Description	Part number
1	Socket head screw	42008
2	O-ring gasket	42012/ 81010/ 82010
1	O-ring gasket	77005
1 ¹⁾	Gasket	42013
1	Gasket	52406
1 ¹⁾	V-Band	52410

¹⁾ Only TPS with bearing casings with V-band connection

Reserve and spare parts	11
-------------------------	----

Ordering spare parts	11.1	Page 2
----------------------	------	--------



CAUTION

All spare parts that have been ordered with the turbocharger should be kept complete and serviceable.

- ▶ Rusty parts should be carefully cleaned and greased.

- ▶ Dispose of parts that have been exchanged and are no longer usable in a technically and environmentally compatible manner.

11.2 Directory of part numbers

The following part numbers and descriptions must be used in ALL correspondence or orders:

Turbocharger

Part no.	Description
51000	Turbine casing
51002	Securing straps
51100	Gas outlet manifold
52400	Gas outlet flange
56001	Nozzle ring
57200	Rupture protection
57210	Rupture ring
72000	Compressor casing
72011	Socket head screw
72012	Securing straps
72020	V-Band
77000	Wall insert
79000	Diffuser
81000	Filter silencer
82000	Air suction branch, axial

Cartridge group


Part no.	Description
21000	Shaft
21002	Piston ring
25000	Compressor wheel
32101	Plain bearing bush
32103	Seeger circlip
32105	Thrust ring
32106	Thrust bearing
32108	Piston ring
32109	Sealing disc
32110	Compressor-end bearing flange
32111	Auxiliary bearing
32112	Turbine-end bearing flange
32113	Socket head screw
32114	Socket head screw
32221	Bearing cap
32222	O-ring gasket
42001	Bearing casing
42002	Socket head screw
42008	Socket head screws
43001	Interior wall

September 2005

HZTL2410_EN (TPS48-61)

Version 2

11.3 General view of turbocharger




September 2005

HZTL2410_EN (TPS48-61)

Version 2

S_00130

11.4 General view of cartridge group



September 2005

HZTL2410_EN (TPS48-61)


Version 2

S_00131






ABB Turbo Systems AG
Bruggerstrasse 71a
CH-5400 Baden
Switzerland

Service Manual - Operation & Maintenance
 Excellence inside. ZEXEL.



RHD MODEL GOVERNOR
 (RHD6 & RHD10)



WARNINGS

The following definitions and warning signs are used in this service manual. These are extremely important to safe operation. Important points are described to prevent bodily injury and property damage. They must be fully understood before beginning governor maintenance.



Improper maintenance can result in injury and property damage.

MEANINGS OF MARKS

The following marks are used in this service manual to facilitate correct governor maintenance.

Advice Procedures that must be performed to enable the best possible governor maintenance.

Note Information assisting in the best possible governor maintenance.

FOREWORD

The RHD hydraulic governor is a high performance variable speed governor for use with main and auxiliary marine engines, engines for electric generators and general power engines.

This service manual describes the construction and operation, repair and maintenance, and adjustment of the RHD6 and RHD10 hydraulic governors.

The contents of the manual, including illustrations, drawings and specifications were the latest available at the time of printing.

The right is reserved to make changes in specifications and procedures at any time without notice.

Bosch Corporation
Automotive Aftermarket Division

CONTENTS

	Page		Page
1 FEATURES	1	7 DISASSEMBLY	23
2 SPECIFICATIONS	2	SPECIAL TOOLS	23
3 CONSTRUCTION	6	EXPLODED VIEW.....	24
4 OPERATION	8	PART LIST.....	25
ENGINE STARTING.....	8	PREPARATION	26
NORMAL OPERATION	9	DISASSEMBLY	26
LOAD DECREASE.....	10	8 INSPECTION	31
LOAD INCREASE	11	9 REASSEMBLY	37
ENGINE STOPPING	12	10 ADJUSTMENT	43
AUXILIARY STARTING BOOSTER.....	13	SPECIAL TOOLS	43
SPEED DROOP MECHANISM.....	14	PREPARATION	43
COMPENSATOR MECHANISM.....	15	OPERATION TEST	46
5 ADDITIONAL DEVICES	16	ADDITIONAL DEVICES.....	50
GOVERNOR MOTOR	16	11 TROUBLESHOOTING	55
PNEUMATIC CONTROLLER.....	18	12 PART NUMBER EXPLANATION	56
HYDRAULIC CONTROLLER	19		
6 HANDLING	20		
GOVERNOR INSTALLATION.....	20		
HYDRAULIC FLUID	20		
AIR BLEEDING &			
COMPENSATION ADJUSTMENT	21		
LINKAGE CONNECTIONS	22		
DAILY INSPECTION.....	22		
IN-SERVICE INSPECTION.....	22		

1. The RHD governor has a large controlling force, despite its compact size.
2. As the hydraulic fluid is contained in the governor, piping and sub-tank installation are unnecessary when installing the governor on the engine.
3. As the power piston utilizes a differential system, the operating force is uniform. Moreover, it is not necessary to install a return spring in the fuel control linkage. When play in the linkage system is excessive, however, it is necessary to install a spring at the end of the system to absorb this play.
4. The governor is able to rotate in either direction, and therefore it can be used without modification on engines which rotate in the reverse direction.
5. Because the normal operating speed is low, governor endurance is high, and gearing is simple when installing the governor on low and intermediate speed engines.
6. The governor has a speed droop mechanism and a compensator mechanism, enabling it to be easily and freely adjusted.
The adjustment range is very wide, enabling governor use on a wide range of engines. The governor can also be used as an isochronous governor with 0% speed droop.
7. The governor body's high tensile aluminum alloy casting makes it extremely lightweight.
8. The governor can be equipped with a governor motor, a pneumatic controller and a hydraulic controller.
9. RHD6 and RHD10 governors are interchangeable. For example, if a higher pressure injection system is required or if the governor's control force is insufficient to cope with the demand for increased engine output, decreased fuel consumption or the use of lower quality fuel oil, then the RHD10 can replace the RHD6.
10. The governor is equipped with a standardized piping connection to enable the installation of an auxiliary starting booster.
11. Of the RHD10 governor's main components, 80% are identical to those of the RHD6. Almost 100% of the remote control device's components are identical to those of the RHD6.

2 SPECIFICATIONS

	RHD6	RHD10
Control force	5.9 J {0.6 kgf·m}	9.8 J {1.0 kgf·m}
Output shaft torque	9.8 N·m {1.0 kgf·m}	15 N·m {1.5 kgf·m}
Output shaft operation angle	35°	40°
Power piston diameter	Small: φ17.7; Large: φ25	Small: φ18.6; Large: φ27
Controlled speed range	Standard rating: 600 ~ 2,000 r/min (Normal: 1,700 ~ 2,000 r/min) High speed rating: 800 ~ 2,400 r/min (Normal: 1,900 ~ 2,400 r/min)	
Maximum allowable speed	2,500 r/min	
Compensator	Needle valve type	
Speed droop adjustment range	0 ~ approx 10% (rated)	
Direction of rotation	Clockwise & counterclockwise	
Hydraulic fluid	SAE20W~40 (Mobiloil)	
Dry weight (lever type)	5.5 kg	5.7 kg
Governor drive power	Max approx 0.2 kW {0.3ps}	
Applicable engines	Low speed: up to approx 1,500 kW {2,000 ps} Intermediate speed: up to approx 1,850 kW {2,500 ps} High speed: up to approx 2,200 kW {3,000 ps}	Low speed: up to approx 2,200 kW {3,000 ps} - High speed: up to approx 2,950 kW {4,000 ps}
Applicable injection pumps	PE (all types) PF1Z x 18 cyl PF1C, -1CD x 16 (18) cyl PF1W x 12 (16) cyl PF1GD x 8 cyl PF1DD x 6 cyl	PE (all types) PF1CX x 18 cyl PF1WX x 16 cyl PF1GX x 12 cyl PF1DX x 8 cyl PF1EX x 6 cyl

The main difference between the RHD6 and the RHD10 is the power piston. The parts adjacent to the power piston also differ.

Note:

1. The method of connecting fuel linkages and the amount of corresponding resistance differ depending on the size of the applicable engine and the size and number of the injection pumps.

Consequently, engines with little friction loss can be used in high output engine

applications and, conversely, engines with large friction loss can only be used in applications equal to or less than those specified above.


2. Simply because the governor has surplus control force does not necessarily mean that stable operation can be ensured.

In order to ensure stable operation and to prevent the speed from exceeding the necessary speed, the inertia of the engine and the drive system should be as large as possible.

2 SPECIFICATIONS

The figure below shows the RHD6 hydraulic governor (lever type). The RHD10 has a special plug (piping connection) for auxiliary starting booster installation located below the center of the name plate.


Lever type



P-RHDR-001


2 SPECIFICATIONS

RHD6 and RHD10-MC, -MCL type governor motors




	Voltage	Cycle	Speed	Current consumption	Output
Motor	AC100V	50/60 Hz	1,200/1,450 r/min	20 W	4 W
	AC220V	50/60 Hz	1,200/1,450 r/min	20 W	4 W
	DC24V	-	2,200 r/min	20 W	3 W
	DC100V	-	2,200 r/min	20 W	3 W
Gear head (speed reduction ratio)	1/18, 1/30, 1/50, 1/75, 1/100, 1/150, 1/300, 1/375, 1/450, 1/600, 1/900, 1/1500				
Speed setting time	<p>The speed setting time can be determined freely by choosing from any of the above gear heads.</p> <p>The standard specified time, however, is approximately that shown below.</p> <p>Main engines: 20 ~ 25 sec dead slow to rated speed</p> <p>Engines for generators: 7 ~ 9 sec/1 Hz</p>				
Limit switch adjustment range (RHD6, 10 -MCL)	<p>Standard specification</p> <p>Lower limit: 600 r/min</p> <p>Upper limit: 2,000 r/min</p> <p>Prior to shipment, the lower limit is set at 600 r/min, and the upper at 1,600 r/min.</p> <p>High speed specification</p> <p>Lower limit: 800 r/min</p> <p>Upper limit: 2,400 r/min</p> <p>Prior to shipment, the lower limit is set at 800 r/min, and the upper at 2,000 r/min.</p>				

MCL type with governor motor




P-RHDR-003

Pneumatic controller dimensions



P-RHDR-004

3 CONSTRUCTION



The above figure shows a cutaway view of the RHD6 hydraulic governor.


The governor is installed directly on the engine.

Engine crankshaft speed is increased using a suitable gear ratio, and is then transmitted to the governor gear shaft. This rotation is transmitted to the hydraulic governor's gear pump, which pressurizes the hydraulic fluid.

The gear pump pumps hydraulic fluid from the governor's hydraulic fluid tank in through the low pressure side of the regulating valve, and delivers the high pressure hydraulic fluid to the pilot valve. The regulating valve also regulates the pressure of the fluid pressurized by the

gear pump (RHD6: 1.18 MPa {12 kgf/cm²}, RHD10: 1.47 MPa {15 kgf/cm²}) and returns excess fluid to the gear pump's intake side.

The gear pump has four check valves so that governor performance does not vary, even when the governor rotates in the reverse direction. The gear pump's driven gear and the sleeve are unified. One end of the sleeve is connected to the governor flyweight. The pilot valve inside the sleeve is moved up and down in response to the flyweight's centrifugal force to control the flow of hydraulic fluid to the power piston, reacting promptly to variations in engine load to rotate the terminal shaft.




The flyweight's centrifugal force is transmitted to the pilot valve by the thrust needle roller bearing. The speeder spring's force is always acting against the flyweight's centrifugal force. The set force of the speeder spring can be changed by moving the control lever. The flyweight assembly is an oil damper type assembly. When sleeve rotation is transmitted to the flyweight, the oil acts to absorb unnecessary high frequency rotation fluctuations and enable stable output. The power piston, which controls the fuel injection quantity to the engine, is a simple

mechanism which enables high stabilized output. The power piston is operated by the hydraulic fluid to move in both the fuel increase and fuel decrease directions. The power piston rotates the terminal shaft via the guide lever and the terminal arm to directly control fuel injection quantity. In addition to having a larger diameter power piston, the RHD10 is equipped with a piping connection to enable the connection of an auxiliary starting booster to the top of the power piston.

4 OPERATION

ENGINE STARTING



When the engine is stopped, the flyweight is pushed down and closed by the force of the speeder spring. Consequently, the pilot valve is in its lowermost position.


When the control lever is then moved in the fuel increase direction, the engine is rotated by compressed air, etc, the gear pump is operated through the gear shaft and the hydraulic fluid is pressurized.

Because the flyweight is pushed down by the speeder spring and the pilot valve does not move, the pressurized hydraulic fluid passage

and the passage to the power piston are open, and the hydraulic fluid pressurized by the gear pump is delivered through the pilot valve to the top and bottom of the power piston.

Because the ratio of the areas of the power piston subject to hydraulic pressure is 1:2, the power piston is immediately moved up (in the fuel increase direction) to move the output shaft side lever in the fuel increase direction through the system of links and facilitate engine starting.

NORMAL OPERATION



P-RHDR-008


When the control lever is moved in the speed increase direction, the speeder spring is compressed by the speed control shaft. When the speeder spring force exceeds the flyweight's centrifugal force, the pilot valve is moved down. Because of this, the high pressure hydraulic fluid passage and the top and bottom power piston passages open, and the high pressure hydraulic fluid pressure moves the power piston in the fuel increase direction to increase engine speed. As the engine speed increases, the flyweight's centrifugal force increases and the pilot valve is pulled up.

At the position where the speeder spring force and the flyweight's centrifugal force balance, the high pressure hydraulic fluid passage and the bottom power piston passage are closed by the pilot valve land. Because of this, the power piston maintains this position and a constant stable speed is maintained.

At this time, excess hydraulic fluid overflows through the regulating valve and is returned to the gear pump's intake side to maintain a stable hydraulic fluid pressure to the pilot valve.

4 OPERATION

LOAD DECREASE




When engine load decreases, and governor rotation has increased, the flyweight's centrifugal force increases and moves the pilot valve up. This opens the center pilot port so that the hydraulic fluid in the bottom of the power piston returns to the governor's hydraulic fluid tank. Consequently, the power piston is moved down (in the fuel decrease direction) by the high pressure hydraulic fluid in the top of the cylinder and the speed is decreased to the previous balanced condition. When the power piston moves down, it compresses the speeder spring through the speed droop mechanism's floating lever, the pilot valve moves down, and the land moves to a position where it closes the pilot port. When the power piston moves down, its downward movement is also transmitted to the compensating pushrod and piston through the compensating spring in the power piston.

Because of this, the negative pressure generated in the compensator chamber relieves the upward movement of the pilot valve, momentarily applying a force in the downward direction.

The compensating effect ends when hydraulic fluid from the governor chamber flows in through the needle valve for a fixed period to restore the negative pressure in the compensator chamber to atmospheric pressure.

Consequently, when the pilot port is closed by the speed droop mechanism and the compensator mechanism, the power piston and the terminal shaft stop at a new position where the fuel necessary to operate the engine at normal no-load speed is supplied when the engine load is cut.

LOAD INCREASE



When the engine load increases, engine speed decreases and the governor's operation is exactly opposite to that at load decrease.

Thus, the pilot valve moves down, high pressure hydraulic fluid flows into the chamber below the power piston, and the power piston moves upward in the fuel increase direction to increase the engine speed and return it to the previous balanced condition.

When the power piston moves up, the speeder spring is moved upward by the speed droop mechanism through the floating lever. Consequently, the pilot valve also moves upward until the pilot valve land closes the pilot port.

As the power piston moves up, the compensating piston is drawn up by the lower compensating spring, and the compensator chamber pressure becomes positive.


Because of this, the speed at which the pilot valve moves down is relieved as this pressure is applied in an upward direction.

The compensating effect ends when the hydraulic fluid flows from the governor chamber in through the needle valve for a fixed period to restore the pressure in the compensator chamber to atmospheric pressure.


In this way, the pilot valve returns to its regular position and the engine is maintained at the new power piston position.

4 OPERATION

ENGINE STOPPING



Because the governor's power piston is moved in the fuel decrease direction by the high pressure hydraulic fluid above the power piston, when the control lever is moved to the stop side the pilot valve is moved up by the speeder spring.




The high pressure hydraulic fluid in the bottom of the power piston is then returned to the governor's hydraulic fluid tank, the power piston moves down (in the fuel decrease direction) and the engine can be forcibly stopped.

The engine can also be stopped by remote control by a governor motor or pneumatic controller. These remote control devices are also installed with a synchronizer to enable manual engine stopping.

When the engine is not stopped on the governor side as described above, but is instead stopped by a handle which mechanically sets the control rack to the non-injection position, it is necessary to install a spring in the link system to prevent excessive force being applied to the governor. As this governor does not have a load limit device, it is also necessary to install a spring as above when it is necessary to mechanically limit the load.

AUXILIARY STARTING BOOSTER



An auxiliary starting booster can be connected to the RHD10 governor when necessary. The following explains engine operation at starting when a booster has been connected to the governor.

When compressed air is supplied to the booster piston to facilitate starting, the piston compresses the spring and the hydraulic fluid in the chamber opposite the compressed air is guided through the discharge side check valve to the chamber above the power piston.

As the governor at this time is in the engine starting status, as explained previously, the hydraulic fluid also flows through the pilot valve to the chamber below the power piston.

As the governor is simultaneously being turned, high pressure hydraulic fluid from the gear pump is also acting on the top and bottom chambers of the power piston.


Consequently, hydraulic fluid pressurized by the booster moves the power piston in the fuel increase direction faster than normal, and it arrives at the fuel position necessary for starting faster than normal.

The booster is an effective means of assisting starting for engines such as those for emergency power generators, where mis-starting must be avoided, and high output engines where the governor's surplus output is small.

Boosters are manufactured especially for the RHD6 and RHD10 governors.

4 OPERATION

SPEED DROOP MECHANISM



With the speed droop mechanism, speed droop can be varied freely from 0% ~ 10% by adjusting the speed droop adjuster.

When the speed control shaft position is fixed using the control lever, and the engine speed is maintained at a speed suitable for a fixed load, should the load decrease, the power piston is moved in the fuel decrease direction (ie, down) to prevent an excessive speed increase.

With this power piston movement, the speed droop adjuster attached to the terminal arm turns and pivots the floating lever in a clockwise direction around the wire A to compress the speeder spring and apply a new set load.

Because the speeder spring's set load is increased, the pilot valve is again moved down to a position where it closes the pilot port, the flyweight's centrifugal force and the speeder spring are balanced at an engine speed a little higher than the initial balanced condition, and this engine speed is maintained.

Conversely, when the load increases, power piston movement in the fuel increase direction extends the speeder spring so that the engine speed is maintained at a speed a little lower than that when the engine speed was originally balanced.


Consequently, by adjusting the speed droop adjuster scale, the link lever ratio is changed and, as the speeder spring's set force can be changed, speed droop can be set freely.

- Speed droop (stabilizing droop)
When load is cut at full-load maximum speed (N), the speed will increase and then stabilize at no-load maximum speed (N_2).

Speed droop is the no-load maximum speed (N_2) expressed as a percentage of the full-load maximum speed (N).

- Momentary droop
When the load is cut at full-load maximum speed (N), the maximum speed (N_1) attained while the speed is stabilizing expressed as a percentage of the full-load maximum speed (N) is referred to as the momentary droop.

COMPENSATOR MECHANISM



The compensator mechanism is used to prevent hunting, which generally more easily occurs when speed droop is decreased.

The compensator mechanism's upper compensating spring and lower compensating spring are both assembled with a set load.

When engine speed increases and the power piston has moved in the fuel decrease direction (ie, down), the power piston and pushrod and the compensating piston first move down together. Because of this, the pressure in the compensating chamber becomes negative. When this negative pressure falls below a certain value, as it overcomes the upper spring's set load and compresses the spring, the amount of compensating spring movement becomes relatively less than the amount of power piston movement (the rate that negative pressure is generated becomes less than power piston movement). As the compensating chamber is connected to the lower pilot valve chamber, the lower pilot valve chamber pressure also becomes negative, and the pilot valve works to move down against the flyweight's centrifugal force and close the previously open pilot port. Because of this, power piston movement in response to engine fluctuations can be slowed to a certain extent and hunting prevented.

In other words, providing the compensating spring with a set load and varying the rate at which negative pressure is generated by power piston movement can improve stability by preventing hunting, and improve response (ie, the speed at which the power piston moves in the fuel increase direction) by minimizing momentary droop.

Conversely, when engine speed decreases, the power piston moves up. As the lower compensating spring has a set force, however, the compensating piston also initially moves up, and the compensating chamber pressure becomes positive. When this positive pressure exceeds a certain level, the spring is compressed and the rate at which the positive pressure is generated is slowed. When the compensating chamber pressure becomes positive, the lower pilot valve chamber pressure also becomes positive, and the pilot valve is pushed up to close the pilot port.

Because of this, excessive power piston movement and therefore hunting can be prevented.

Closing the needle valve increases the pressure generated in the compensating chamber, and thus increases the compensator effect, so that response can be further slowed.


5 ADDITIONAL DEVICES

The governor can be equipped with a governor motor and a pneumatic controller. These facilitate remote engine control from a central control room.

Their construction and operation are explained below.

GOVERNOR MOTOR

RHD6 and RHD10 - MC type governor motor



The governor motor operates when the engine speed set switch in the control room is turned ON.


When the motor operates, the speed setting screw is rotated by the friction coupling and gear.

As the speed setting screw is screwed into the guide screw, this rotation results in vertical movement.

Because the speed setting screw acts on the speed adjusting mechanism within the governor, speed setting screw movement changes the set load of the speeder spring to vary engine speed.

The speed can also be changed manually in the same way by turning the synchronizer knob.

**RHD6 and RHD10 - MCL type governor motor
(with limit switches)**



This governor motor enables electrical control of the set governor speed's upper and lower limits through limit switches.

Three types are available for use with ships' main engines, pumps, and generators. The control ranges and speed setting times differ depending on the type used.

The motor is decelerated by the gear head which, through the friction coupling, turns the speed setting screw to slide the speed adjuster in an axial direction. A pin protruding from the speed adjuster turns the speed adjusting lever fixed to the speed control shaft to vary the set speed.


The upper part of the speed adjuster also serves as a cam to operate the limit switches and move them within the range determined by the slot to enable adjustment of the upper and lower set speeds.

When setting the speed manually, the motor side synchronizer can be used to freely vary the speed from the minimum to the maximum irrespective of limit switch control.

Also, when an attempt is made to simultaneously change the set speed by remote control, the friction coupling ensures that the speed is first changed on the engine side to prevent any adverse effect on the motor.

5 ADDITIONAL DEVICES

PNEUMATIC CONTROLLER




The pneumatic controller is used to control engine speed.

When air at a specified pressure is supplied to the pneumatic controller, the air pressure acts on the diaphragm and plate, compressing the spring and pushing the pushrod down.

The pushrod acts on the speed adjusting link mechanism in the governor to change the set load of the speeder spring.

The engine speed can also be freely changed manually in the same way by turning the knob on the top of the controller.

HYDRAULIC CONTROLLER




P-RHDR-019

The hydraulic controller is used to control engine speed, but utilizes hydraulic pressure instead of air pressure, and a piston instead of a diaphragm.

The hydraulic controller's piston displacement is 12 cm³.

GOVERNOR INSTALLATION



1. Install the governor vertically to the governor drive case. Use the accompanying gasket at the installation surface.
2. Ensure the governor gear shaft is not subjected to a direct radial load, and that eccentricity and acceleration-gear play are as small as possible.
Gear shaft spline coupling dimensions are shown at left. These are the same for RHD6 and RHD10 governors.


⚠ CAUTION

When handling the governor, ensure the end of the governor's gear shaft is not subject to force or impact.

Note:
Although the spline is a standard JIS square-shaped spline (6 x 13 x 16), the dimensions shown at left are recommended to avoid even minute eccentricity when installing the coupling. The spline couplings shown at left are standard Bosch Corporation spline couplings.


HYDRAULIC FLUID

Hydraulic fluid type	Fluid charge	Inspection	Replacement
The type of hydraulic fluid used varies depending on the governor oil temperature during normal operation. Less than 50°C: SAE20 50°C ~ 70°C: SAE30 Over 70°C: SAE40	Approx 1,300 cm ³ . With the governor horizontal, fill the governor with fluid until the level is slightly above the middle of the governor case window. If the fluid charge is insufficient, bubbles will form, performance will decrease, and fluid deterioration will be accelerated.	Check the hydraulic fluid daily. If the charge is less than that specified, check for leaks. If repair is not possible, contact an authorized Bosch Corporation service station.	The fluid must initially be replaced after 1,000 hours or 3 months. Thereafter, the fluid must then be replaced every 3,000 hours or 6 months.




AIR BLEEDING AND COMPENSATION ADJUSTMENT

1. Set the speed droop at the smallest value possible using the speed droop adjuster (0 ~ 2 on the adjuster scale) and fully open the compensating needle valve (3 turns from the fully closed position).
2. Operate the engine at low speed and cause the engine to 'hunt' or 'surge' for approximately 30 seconds to bleed the air.



3. Stop the engine, set the speed droop to the setting estimated for the particular application (determined from the performance diagram) and then restart the engine.







4. Close the needle valve until 'hunting' stops.

Advice

The above completes air bleeding and compensation adjustment. If, however, the speed droop adjustment setting is changed during engine adjustment, readjust the needle valve to as open a position as possible at which stabilized engine operation is obtained.

6 HANDLING



LINKAGE CONNECTIONS

1. Use a split tightening type lever. After determining the correct position, secure it using a knock pin, etc.
2. The linkage must be as simple and direct as possible. Minimize resistance and the actual mass of the linkage.

3. The figures at left show the recommended relationships for connections between the terminal shaft angle and the injection pump for a static governor.

Advice

As play in the link system adversely affects performance, ensure play is as small as possible.

DAILY INSPECTION

1. Check the fluid level daily before beginning operation.
If the level is below the middle of the gauge, add fluid to the governor.
2. Check that the governor mounting bolts are not loose and that there are no faults in the linkage connections from the governor terminal shaft to the injection pumps' control rack.


IN-SERVICE INSPECTION

1. Check the governor temperature. The temperature should generally increase to approx 60°C after 30 ~ 40 min of high speed engine operation. If the ambient temperature is high, the temperature may increase to 80°C after continued high speed operation (over 1,800 r/min).
Temperatures over 100°C are abnormal.
2. Check for abnormal noises.
3. Wipe any fluid from the outside of the governor and check that no fluid leaks during operation.

SPECIAL TOOLS


The following special tools (in addition to general tools) are required for disassembly and reassembly of the RHD hydraulic governor.

Key no.	Part name	Zexel part no.	Bosch part no.	Qty	Application
1	Case	376100-2000	9 421 622 974	1	For tools
2	Spanner	376100-2100	9 421 622 811	1	For removing/installing regulating valve (SW22mm, 24mm)
3	Screwdriver	376100-2200	9 421 622 812	1	For removing/installing cover bolts
4	Screwdriver	376100-2300	9 421 622 813	1	For speed droop adjuster adjustment
5	Pliers	376100-2400	9 421 622 814	1	For removing split pins
6	Spanner	376100-2500	9 421 622 815	1	For removing/installing plug (SW17mm)
7	Allan wrench	376100-2600	9 421 622 816	1	SW3mm
8	Allan wrench	376100-2700	9 421 622 817	1	SW5mm
9	Extractor	376100-2800	9 421 622 818	1	For removing pin



7 DISASSEMBLY

EXPLODED VIEW



P-RHDR-028

PART LIST**RHD-LC type hydraulic governor**

Key no.	Part name	Key no.	Part name	Key no.	Part name
1	Base	36	Bolt	89	Roll pin
2	Needle roller bearing	50	Flyweight	95	Floating lever
3	Oil seal	51	Washer	96	Wire
7	Gear shaft	52	Thrust needle roller bearing	104	Gasket
10	O-ring	53	Pilot valve assembly	105	Cover
11	Housing	60	Guide lever	106	Bolt
13	Sleeve	61	Pin	108	Maximum speed setting screw
18	Compensator assembly	62	Split pin	109	Nut
18/1	Power piston	70	Terminal arm assembly	110	Minimum speed setting screw
18/3	Upper compensating spring	70/1	Terminal arm	111	Nut
18/4	Pushrod	70/2	Terminal shaft	112	Gasket
18/5	Washer	70/3	Taper pin	113	Air breather
18/6	Lower compensating spring	70/4	Set screw	118	Needle valve
18/7	Snapping	70/5	Speed droop adjuster	119	O-ring
18/8	Compensator bushing	70/6	Washer	123	Gasket
18/9	O-ring	70/7	Lock washer	124	Screw plug
18/10	Compensating piston	70/8	Screw	130	Gasket
18/11	Roll pin	85	Speed control shaft	131	Regulating valve
35	Gasket washer	86	Collar	135	Indication plate
		88	Fork	136	Nail
				137	Indication plate
				140	Pointer




Pneumatic controller

Key no.	Part name	Key no.	Part name	Key no.	Part name
105	Pneumatic controller	105/12	Piston	105/25	Bolt
105/1	Cover	105/13	Diaphragm	105/26	Eye
105/2	Cylinder	105/14	Plate	105/27	Gasket
105/3	Screw	105/15	Nut	105/28	Eye bolt
105/4	Spring washer	105/16	Cover	105/30	Nut
105/5	Spring seat	105/17	Screw	105/31	Bolt (set screw)
105/6	Nut	105/18	O-ring	105/35	Gasket
105/7	Washer	105/19	Wing nut	105/36	Bolt
105/8	Spring	105/21	Knob	(158)	Pin
105/9	Spring	105/22	Set screw		
105/10	Washer	105/23	Screw		
105/11	Pushrod	105/24	Spring washer		

7 DISASSEMBLY

PREPARATION

Keep the work bench clean and tidy. Before starting disassembly, record performance data and the positions of adjustable parts for later reference. This data will facilitate the detection and diagnosis of any governor malfunctions and defects.



During disassembly, put the disassembled parts neatly and sequentially on the work bench, labelling them if necessary to facilitate later reassembly.

Clean the outside of the governor before disassembly.

DISASSEMBLY

1. Remove the four bolts using a screwdriver and then remove the cover together with the gasket.
2. Turn the governor upside down and drain the fluid.


3. Remove the two wires connecting the fork to the floating lever and then remove the floating lever.

4. Remove the pilot valve assembly.


Advice

Put the pilot valve in clean light oil.


7 DISASSEMBLY




5. Remove the two split pins and then remove the two pins connecting the terminal arm and the guide lever to the power piston.



6. Remove the bolts using an allen wrench (SW 5 mm).




7. Tap the base lightly with a plastic hammer to separate it from the housing.




8. Remove the sleeve from the housing and the gear shaft from the base.

Advice
Put the sleeve in clean light oil.

7 DISASSEMBLY




9. Push the power piston down from the top of the governor and then remove the compensator bushing and the compensator assembly.




10. Remove the roll pin securing the fork to the speed control shaft, and then remove the speed control shaft, the collars and the fork.

Note:

PC, MC, and MCL type governors are equipped with a cancel spring on the speed control shaft. Remove the cancel spring when removing the speed control shaft.





11. Remove the flyweight assembly together with the thrust needle roller bearing and the washer from the housing.



12. Turn one terminal shaft one half turn and remove the terminal shafts' taper pins. Remove the set screws using an allen wrench (SW 3 mm), then remove the terminal shafts and arm.

Advice

1. Do not remove the terminal arm assembly unless it is not operating smoothly or it is necessary to replace parts.
2. When replacing the terminal shafts and arm, they must be replaced as an assembly.




13. Remove the needle valve and regulating valve (hexagon head, SW 24 mm) and any other external parts.

The above completes disassembly of main RHD governor components.


Disassemble other components when necessary.

The pneumatic controller is the most commonly equipped additional device. Disassembly is described below.




PNEUMATIC CONTROLLER DISASSEMBLY

1. Loosen the wing nut. Then, loosen the knob until it can be easily turned.




2. Remove the four bolts using a screwdriver and then remove the cover.

7 DISASSEMBLY



3. Remove the diaphragm together with the pushrod, and then remove the two springs.



4. Loosen the nut and then remove the spring seat.

The above completes disassembly of main pneumatic controller parts.
Disassemble other parts when necessary.

Record the details of all inspections and repairs.

With parts such as those listed below, first check their external appearance to determine whether further disassembly is necessary.

- Terminal arm assembly
- Pilot valve assembly
- Housing assembly
- Flyweight assembly
- Governor motor assembly

Wash all parts thoroughly in clean light oil, and check for wear, damage and scratches. Replace any parts that cannot be reused with new parts.

REPLACEMENT STANDARDS


Parts with key numbers marked ○ :

Replace at disassembly or every 2 years

Parts with key numbers marked □ :


Replace every 4 years or 20,000 hours

In principle, assemblies must be replaced when any of their component parts have been used for 8 years or 40,000 hours.



If parts other than the above are worn or damaged, replace them with new ones.

8 INSPECTION





Base assembly and housing

Replace the base if the power piston, gear shaft or sleeve contact surfaces are worn or damaged.


Replace the housing if the power piston, gear shaft or sleeve contact surfaces, or the housing holes, are worn or damaged.

Replace the housing if the pressfitted terminal arm bushings are worn or loose.



Gear shaft and sleeve

Replace the gear shaft if the outside, spline, oil seal contact surface or gear is worn or damaged. Replace the sleeve if the gear, pilot ports or lands are worn or damaged.




Compensator assembly

Assemble the compensator assembly's power piston, pushrod and compensator bushing in the housing and check that they move smoothly up and down under their own weight when the housing is moved.

Repair or replace them if they do not move smoothly.

Note:

If the power piston does not move smoothly, hunting or excessive speed droop will prevent engine adjustment.




Flyweight assembly

Foreign matter in the flyweight will prevent smooth flyweight movement.


Check that the flyweight moves smoothly.

Wash the flyweight thoroughly.



Power piston, guide lever and terminal arm

- Replace the guide lever if the pin holes are worn.
Replace the pins if they are worn.
Replace the power piston if the inside is worn.
- Replace the speed control shaft if it is bent or the shaft journals are worn.



Regulating valve


Check that the piston moves smoothly.

Repair or replace the piston if it is worn or does not move smoothly.

Other parts

- Check all other parts for cracks, damage, damaged threads and rust.
Repair or replace them if necessary.
- Replace all O-rings and gaskets.
- Replace springs that are damaged, bent or rusted.

8 INSPECTION



GOVERNOR MOTOR BRUSH INSPECTION (MC, MCL TYPES)

Advice

Inspection applies only to direct current (DC) type motors. The following is not necessary for alternating current (AC) motors.

Brush inspection intervals



Brush inspection intervals are shown below.

Part name	Inspection interval	Remarks
Brush	Monthly	When overall length is 4 mm or less

Note:


Overall length of new brushes: 10 mm

Brush inspection




Brush removal

1. Remove the screw and then remove the cover.




2. Loosen and then remove the cap.



3. Remove the brush from the motor.

Advice


Do not stretch the brush spring during removal.



4. Measure the overall length of the brush.

Advice

- When overall brush length still exceeds the wear limit of 4 mm, reverse the removal procedure to reinstall the brush. (Inspection is complete.)
- When overall brush length is 4 mm or less, continue with the following steps. (Replace both brushes at the same time.)




Motor removal

1. Loosen the screw and then remove the knob.


Note:

Screw: SW3

8 INSPECTION




2. Remove the screws and then remove the motor horizontally.



Advice

The motor is connected to a harness. Do not pull the harness excessively.



Brush replacement

1. Remove the knob-side brush using the same procedure as above.
2. Replace both brushes with new ones and then reinstall the motor and knob by reversing the removal procedure.

Advice


- When reinstalling the motor, install the motor so that the side with the nameplate is facing up.
- Tighten diagonally opposed motor fixing screws (4) gradually and evenly.

Tightening torque: 2 ~ 2.2 N·m

{0.2 ~ 0.22 kgf·m}

Brush part numbers


Part name	Zexel part no. (Bosch part no.)	Remarks
Brush	158901-4500 (9 421 622 899)	For DC24V
	158901-4600 (9 421 622 900)	For DC100V




Governor reassembly is described below.

PNEUMATIC CONTROLLER
(if installed)


1. Screw the locknut onto the spring seat, then screw the spring seat into the cylinder.



2. Install the diaphragm and pushrod together with the two springs.




3. Install the cover and secure it using the four bolts.




4. Install the knob and wing nut.

9 REASSEMBLY



GOVERNOR ASSEMBLY


1. Install the regulating valve.
Tightening torque: 25 ~ 29 N·m
{2.5 ~ 3.0 kgf·m}




2. Install the terminal shafts and arm. Align each terminal shaft's and terminal arm's taper hole.
Coat the taper pins with an adhesive and install the taper pins.

CAUTION

When installing the two taper pins in the terminal shafts, support the terminal arm and terminal shafts to avoid damaging the bushings pressfitted to the housing.




3. Coat the set screws with an adhesive and install the two set screws.
Tightening torque: 3.9 ~ 4.9 N·m
{0.4 ~ 0.5 kgf·m}




4. Caulk the two taper pins after final tightening.

9 REASSEMBLY




5. Install the flyweight assembly, thrust needle roller bearing and washer in the housing.




6. Install the speed control shaft, collars and fork, and then install the roll pin.

Advice

PC, MC, and MCL governors are equipped with a cancel spring. Install the cancel spring when installing the speed control shaft.




7. Install the power piston, the compensator assembly and the compensator bushing.




8. Install the gear shaft in the base, and the sleeve in the housing.

9 REASSEMBLY



Advice

When pressfitting the gear shaft bearing into the base, pressfit the bearing to align with the base face, as shown. If the bearing is pressfitted too deep, the bearing will block the high pressure fluid passageway.




9. Install the base to the housing using the bolts and gasket washers.

Tightening torque: 10 ~ 15 N·m


{1.0 ~ 1.5 kgf·m}

CAUTION


While securing the base to the housing, check that the gear shaft turns smoothly. If the gear shaft does not turn smoothly, the oil delivery gear may be damaged.




10. Attach the guide lever to the terminal arm and the power piston using the two pins and two split pins. Then, bend the split pins over.



11. Install the pilot valve assembly.




12. Install the floating lever and secure it to the fork and pilot valve using the two wires.



Advice

Bend the ends of the wires to prevent them from loosening.



13. After assembling the governor's inner components, thoroughly wash the inside and then install the cover using the bolts.

Air tightness test


- 1 Before filling the governor with hydraulic fluid, remove the air breather and install the connector, gaskets and eye bolt. Then, supply compressed air at 49 kPa {0.5 kgf/cm²} to the governor through the connector, and immerse the governor in light oil.
- 2 Operate the speed control shaft and check that no air leaks from the governor. If air leaks, repair the governor.

Advice

If the governor is equipped with an overflow valve, seal it using a blind plug. If the governor is equipped with booster connections, remove them and seal the openings with blind plugs.

Remove the blind plugs and reinstall all components after adjustment.



9 REASSEMBLY




14. Remove the connector, gaskets and eye bolt.
Reinstall the air breather, then remove the cover.

In addition to general tools, the following special tools are necessary for governor adjustment.

SPECIAL TOOLS

Key no.	Part name	Part no.	Shape	Remarks
1	Driving stand	307610-0050		For driving RHD governor
2	Adjusting device	307610-1010		For measuring lever angle




PREPARATION


1. Attach the driving stand to the pump tester and install the governor on the driving stand.

Fill the governor with the specified amount of hydraulic fluid (approx 1,300 cm³; the fluid should be a little over the middle of the gauge).

10 ADJUSTMENT



2. Move the terminal arm by hand until it becomes difficult to move to bleed the air from the governor.



3. Turn the flywheel by hand and check that the gear shaft can be turned easily, and that the flyweight turns together.


Note:

If the gear shaft does not turn easily, it will heat up during operation and adversely affect endurance.


⚠ CAUTION

Remove the lever after operating the flywheel.


Operating the test bench without removing the lever can cause serious injury and damage the test bench.



4. Set the speed control shaft in the speed increase position, rotate the gear shaft and check that the terminal shaft moves in the fuel increase direction.



5. Attach the adjusting device to the driving stand and then attach the adjusting device lever to the terminal shaft.




- Set the speed control shaft in the speed decrease position, rotate the gear shaft and check that the terminal shaft moves in the fuel decrease direction.

Note:

If the cover is installed, the terminal shaft may not return in the fuel decrease direction, depending on the set position of the speed control shaft.

- Install the governor cover.




Warming-up operation

Run the governor at 1,000 r/min for 20 mins and check that no fluid leaks.

Air bleeding


Fully open the needle valve (approx 3 turns from the fully closed position) and run the governor at 1,000 r/min. Operate the speed control shaft so that the power piston moves through its full stroke.

Do this at least 10 times to bleed all air from the governor's hydraulic system.







Terminal shaft pointer adjustment

- Run the governor at approx 1,000 r/min and move the speed control shaft to the stop position.
- In the above condition, align the terminal shaft side pointer with the indication plate's (fuel side) 0 position and fix it using the screw.



- This position is the terminal shaft angle's 0 position. Align the adjusting device's 0 position with this position.

10 ADJUSTMENT



4. Run the governor at approx 600 r/min (with the needle valve fully open, ie, returned 3 turns from the fully closed position) and turn the speed control shaft. Check that the terminal shaft moves easily from $0^\circ \sim 35^\circ$ (RHD10: $0^\circ \sim 40^\circ$) when the power piston moves through its full stroke. At this time, check that the terminal shaft operating torque is 9.8 N·m {1 kgf·m} for the RHD6 or 14.7 N·m {1.5 kgf·m} for the RHD10 using a spring balance attached to the adjusting device.

OPERATION TEST

The operation test is the same for LC, PC, MC, and MCL type governors.

Perform the operation test with the needle valve fully open.


Speed control shaft pointer angle adjustment

1. Remove the governor cover and set the droop adjuster pointer at the specified value.
2. Run the governor at 2,000-10 r/min and secure the speed control shaft at the position (A) where the terminal shaft angle is 30° (ie, 6 on the scale). Then, align the speed control shaft pointer at 8 (on scales graduated from 0 ~ 8) and tighten the screw.


Note:

- 1 On PC, MC and MCL governors, the terminal shaft is fixed (at A) by a knob.
- 2 On RHD10 governors, when the terminal shaft angle is 32° (ie, 8 on the scale), align the speed control shaft pointer at 10 using the screw.

For RHD6



Speed droop adjuster



Speed droop adjustment

1. Temporarily fix the droop adjuster pointer at the specified position.
2. Operate the governor at N_1 r/min and then fix the speed control shaft when the terminal shaft angle is 30° for the RHD6 or 32° for the RHD10.

3. Gradually increase governor speed and further adjust the speed droop adjuster so that governor speed is N_2 r/min when the terminal shaft angle is returned to 10° for the RHD6 or 8° for the RHD10.

Note:

When the speed droop adjuster pointer is moved toward 0, speed droop decreases.

When the speed droop adjuster is moved toward 10, speed droop increases.

Advice

Confirm that N_2 is within the allowable speed when the speed droop adjuster is exactly as specified.

Note:

If the lever attached to the terminal shaft deviates more than $\pm 1^\circ$ during high speed operation (ie, at approx 1,800 r/min), check as follows.





Regular deviation: Check compensator related parts (housing, base, assembly, regulating valve). Replace them if necessary.

Irregular deviation: Check the flyweight assembly. Replace it if necessary.

Perform the following adjustments with the governor adjusted as described above.

10 ADJUSTMENT

For RHD6



Maximum speed setting screw adjustment (not necessary on MCL type governors)

1. Install the governor cover.

Operate the governor at N_1 r/min, adjust the maximum speed setting screw until the terminal shaft angle is 30° for the RHD6 or 32° for the RHD10, and then fix the screw using the locknut.

Minimum speed setting screw adjustment (not necessary on PC, MC or MCL type governors)


1. With the governor stopped, move the speed control shaft as far as possible to the low speed side (0 or less on the scale), and then temporarily set the minimum speed setting screw.
2. Operate the governor at N_3 r/min and adjust the minimum speed setting screw so that the terminal shaft angle does not exceed 10° (RHD6) or 8° (RHD10). Then, fix the screw using the locknut.

Compensator chamber high pressure hydraulic fluid flow

The flow of a large quantity of hydraulic fluid to the compensator is not desirable.

To check for this, perform the following test.

1. Fully open the needle valve (approx 3 turns from the fully closed position) and maintain governor speed at approx 1,000 r/min.
2. Fix the speed control shaft so that the terminal shaft angle is approx 20° (4 on the scale).




3. Fully close the needle valve and check that the terminal shaft does not move more than 1° in the 0 direction.

Advice

If the terminal shaft moves more than 1° in the 0 direction, check for the following.

- Clearance between the sleeve and base.
- The base-housing contact surfaces may not be even, or may be scratched.
- The needle valve escape ports (ϕ 0.4 and ϕ 0.8) and the base escape ports (ϕ 1.5) may be blocked.
- The compensator bushing O-ring may be damaged.



Governor control confirmation

Under the following conditions, operate the speed control shaft to move the terminal shaft in the fuel increase direction (RHD6: 0° → 35°; RHD10: 0° → 40°) and in the fuel decrease direction (RHD6: 35° → 0°; RHD10: 40° → 0°) and check that the lever resistance is as specified.

Measurement conditions

Governor speed:	600 r/min
Needle valve position:	fully open
R (see fig at left):	100 mm

Note :

If the lever resistance is not as specified, replace the following parts.





- Regulating valve assembly
- Check for openings or leaks in the gear pump or hydraulic fluid system and replace faulty or damaged parts.

Reverse operation

The RHD governor is constructed so that identical performance is obtained whether it is operating clockwise or counterclockwise.

To confirm this, operate the governor in the reverse direction and check governor control as described above under the exact same conditions and procedures, and check that performance is as specified.

10 ADJUSTMENT



ADDITIONAL DEVICES

Pneumatic controller adjustment

1. Before adjustment, check that the outer and inner springs' distinguishing colors are as specified.
2. Temporarily position the manual knob as shown at left and connect a compressed air source capable of supplying 0 ~ 0.49 MPa {0 ~ 5 kgf/cm²} to the eye bolt.

Note :

Perform the following adjustments and confirmations based on the individual test standards.

3. Point I adjustment

Example:

1,680 ~ 0.37 MPa ~ 30±0.5

{3.8 kgf/cm²}

(speed) (air pressure) (terminal shaft angle)

Operate the governor at 1,680 r/min and adjust the spring seat so that the terminal shaft angle is 30±0.5° when when 0.37 MPa {3.8 kgf/cm²} air pressure is supplied. Then, secure the spring seat using the nut.

Advice

When adjusting point I, return the air pressure to 0 and the manual speed adjusting knob to its original position to prevent diaphragm damage.

4. Point II adjustment

Example:

1,055 ~ 0.16 MPa ~ (Approx 16.5)

{1.6 kgf/cm²}

(speed) (air pressure) (terminal shaft angle)

Operate the governor at 1,055 r/min and confirm that the terminal shaft angle is 16.5° when 0.16 MPa {1.6 kgf/cm²} air pressure is supplied.

5. Point III adjustment

Example:

700 ~ 0 ~ 8.5+1.5

(speed) (air pressure) (terminal shaft angle)


Operate the governor at 700 r/min and adjust the manual speed adjustment knob so that the terminal shaft angle is 8+1.5° at an air pressure of 0. Then, secure the knob using the wing nut.

Governor motor operation confirmation (MC type)

1. Specification confirmation


Confirm from the individual standards that the specifications of individual parts are correct.

 - Motor specification (voltage)
 - Condenser capacity
 - Speed reduction ratio




2. Operation confirmation (using speed adjustment knob)

Turn the knob manually, and confirm that the speed setting screw turns smoothly over the whole range by observing speed control shaft pointer movement. If it does not move smoothly over the whole range, loosen the friction coupling set screw, adjust the positions of the bevel gear teeth and recheck screw movement.




3. Operation confirmation (using the motor)

Connect the governor motor assembly to the electrical test circuit in accordance with the particular motor's specifications, as shown at left.




4. Operation test
 - Turn the governor motor's speed switch ON in the speed increase direction to operate the motor. Then, operate the motor until the fork contacts the maximum speed setting screw adjusted above and the friction coupling is rotating freely.


10 ADJUSTMENT



- Then, turn the switch OFF and then ON in the speed decrease direction, and confirm that the speed setting screw begins moving smoothly.



- Operate the governor motor until the speed setting screw contacts the stopper and the friction coupling is rotating freely.



- Then, turn the switch OFF and then ON in the speed increase direction and confirm that the speed setting screw moves smoothly.


Advice

During the above operation test, if the friction coupling rotates freely in other than the following two cases, check the alignment of the bevel gear teeth.


- When the maximum speed setting screw is contacting the fork
- When the speed setting screw is contacting the stopper

Governor motor operation test and limit switch adjustment (MCL type)


1. Specification confirmation
Confirm from the data sheet that the specifications of individual parts are correct.
- Motor specification (voltage)
 - Condenser capacity
 - Speed reduction ratio




2. Operation confirmation
(using the manual speed adjustment knob)
Confirm operation as described below before adjusting the terminal shaft side pointer.
Operate the knob manually and confirm that the speed setting screw rotates smoothly over the full range.
If it does not move smoothly in some places, check the installation of the holder or the speed setting screw.




3. Governor motor operation test
(limit switch adjustment)
Connect the governor motor assembly to the electrical test circuit in accordance with the particular motor's specifications, as shown at left.
Then, adjust each limit switch.



- Maximum speed limit switch adjustment
Operate the governor at the specified speed (N_1 r/min), and the governor motor in the speed increase direction.
Adjust the limit switch's upper limit position so that the governor motor stops at the terminal shaft angle of $30 \pm 3^\circ$ for the RHD6 or $32 \pm 3^\circ$ for the RHD10.



10 ADJUSTMENT



- **Minimum speed limit switch adjustment**
Operate the governor at the specified speed (N_3 r/min), and the governor motor in the speed decrease direction. Adjust the limit switch's lower limit position so that the governor motor stops at the terminal shaft angle of $10 \pm 3^\circ$ for the RHD6 or $8 \pm 3^\circ$ for the RHD10. Set the governor speed at 1,500 r/min and confirm that the governor motor operates correctly between the upper and lower operation limits and that the friction coupling does not rotate freely.

TROUBLESHOOTING

Of the phenomena listed below, some originate solely in the governor, and some solely in the engine.

- Faulty starting
- Hunting
- Insufficient engine output
- Engine will not operate at maximum speed
- Excessive momentary speed droop, or inability to control speed

First, check the engine for the following faults. If engine faults are found, perform repairs in accordance with the engine maker's instructions.

- Compression pressure of each cylinder is extremely uneven
- Excessive play in fuel control and speed adjustment linkage
- Excessive resistance in injection pump control rack and fuel control linkage
- Excessive play because of worn governor drive system gear or rubber damper
- Relative positions of linkages incorrect
- Dashpot spring in fuel control linkage bent or damaged

If no engine faults are found, check the governor.

As the governor uses many precision parts, there is a danger of the engine overrunning if these parts are incorrectly assembled.

CAUTION

Never attempt to repair the governor on-site.

Always consult your nearest Bosch Corporation representative.

12 PART NUMBER EXPLANATION

MODEL NUMBER

Example: RHD 6 L C
 (1) (2) (3) (4)

- (1) Independent type hydraulic governor, manufactured by Bosch Corporation
- (2) Control force (work load)
Indicates 10 times the controlling force (work load) in kgf·m.
- (3) L: lever type
M: with governor motor
P: with pneumatic controller
- (4) C: with compensator

Note:

No symbol 'C' indicates that a compensator is not used.

CODE NUMBER

Example: 10 58 5 6 - 0 000
 (1) (2) (3) (4) (5) (6)

- (1) 10: Assembly part number
- (2) 58: Hydraulic governor manufactured by Bosch Corporation
- (3) Type
5: RHD6 type
6: RHD10 type
- (4) Direction of pump rotation and governor installation position

	Direction of pump rotation	Governor installation position	Remarks
0	Clockwise	Right side	} For in-line pumps
1	Clockwise	Left side	
2	Counterclockwise	Right side	
3	Counterclockwise	Left side	
4	Clockwise	-	
5	Counterclockwise	-	
6	Reversible	-	

Note:

With in-line pumps, the direction of pump rotation is viewed from the pump's drive side.
 Governor installation position is viewed from the pump's cover plate side.

- (5) Remote control device installation
 - 3: LC type without remote control device
 - 4: PC type
 - 5: MC type
 - 6: MC type
 - 7: MCL type
 - 8: MCL type
 - 9: HC type, others
 } with remote control device
- (6) Characteristic number

Pub. No: EE74E-11016

GOVERNOR MODEL RHD (RHD6 & RHD10)
Service Manual
Operation & Maintenance
Printing: January 2006
Published by:
Bosch Corporation
Automotive Aftermarket Division
Printed in Japan
© Copyright 2006, Bosch Corporation

1000-24

WPGGS-01

· ZEXEL ·

Bosch Corporation
Marketing Automotive Aftermarket Japan
3-4-1, Kitano, Niiza-shi
Saitama, 352-8572
Japan
Tel: +81-48-475-2521
Fax: +81-48-475-2520